



Programming Guide

TR200



Table of Contents

Safety	1-1
High Voltage Warning.....	1-1
Before commencing repair work.....	1-4
Special conditions.....	1-4
IT line power.....	1-5
Introduction	2-1
Copyright, limitation of liability and revision rights	2-1
Abbreviations	2-2
Definitions	2-3
How to Program	3-1
Local Control Panel	3-1
How to operate the Graphical keypad	3-1
Quick Menu mode.....	3-8
Function Set-ups	3-10
Main Menu Mode	3-15
Parameter Description	4-1
Parameter Selection.....	4-1
Main Menu Structure.....	4-1
Main Menu - Operation and Display - Group 0.....	4-1
Main Menu - Load and Motor - Group 1.....	4-22
Main Menu - Brakes - Group 2.....	4-34
Main Menu - Reference/Ramps - Group 3.....	4-37
Main Menu - Limits/Warnings - Group 4.....	4-46
Main Menu - Digital In/Out - Group 5.....	4-51
Digital Inputs, 5-1* continued.....	4-57
5-3* Digital Outputs.....	4-66

Main Menu - Analog In/Out - Group 6.....	4-83
Main Menu - Communications and Options - Group 8.....	4-92
Main Menu - LonWorks - Group 11.....	4-102
Main Menu - Smart Logic - Group 13.....	4-104
Main Menu - Special Functions -Group 14.....	4-120
Main Menu - Adjustable Frequency Drive Information - Group 15.....	4-130
Main Menu - Data Readouts - Group 16.....	4-140
Main Menu - Data Readouts 2 - Group 18.....	4-151
Main Menu - Adjustable Frequency Drive Closed-loop - Group 20.....	4-153
Main Menu - Extended Closed-loop - TR200 - Group 21.....	4-169
Main Menu - Application Functions - TR200 - Group 22.....	4-184
Main Menu - Time-based Functions - TR200 - Group 23.....	4-192
Main Menu - Application Functions 2 - Group 24.....	4-209
Troubleshooting.....	5-1
Troubleshooting.....	5-1
Alarms and Warnings.....	5-1
Alarm Words.....	5-5
Warning Words.....	5-6
Extended Status Words.....	5-7
Fault messages.....	5-8
Parameter Lists.....	6-1
Parameter Lists TR200.....	6-1
Default settings	6-1
0-** Operation and Display.....	6-2
1-** Load / Motor.....	6-3
2-** Brakes.....	6-4

3-** Reference / Ramps.....	6-4
4-** Limits / Warnings.....	6-5
5-** Digital In / Out.....	6-6
6-** Analog In / Out.....	6-7
8-** Communication and Options.....	6-8
11-** LonWorks.....	6-9
13-** Smart Logic Controller.....	6-9
14-** Special Functions.....	6-10
15-** Adjustable Frequency Drive Information.....	6-11
16-** Data Readouts.....	6-12
18-** Info & Readouts.....	6-13
20-** FC Closed-loop.....	6-14
21-** Ext. Closed-loop.....	6-15
22-** Application Functions.....	6-16
23-** Time-based Functions.....	6-17
24-** Application Functions 2.....	6-18

Index.....	7-1
------------	-----



Safety

Warnings, cautions and notices

Note that warnings, cautions and notices appear at appropriate intervals throughout this manual. Warnings are provide to alert installing contractors to potential hazards that could result in personal injury or death. Cautions are designed to alert personnel to hazardous situations that could result in personal injury, while notices indicate a situation that could result in equipment or property-damage-only accidents.

Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

Warnings, Cautions and Notices appear at appropriate sections throughout this literature. Read these carefully.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It could also be used to alert against unsafe practices.

NOTE

Indicates a situation that could result in equipment or property-damage only accidents.

 Indicates default setting

High Voltage Warning

WARNING

The voltage of the adjustable frequency drive and the MCO 101 option card is dangerous whenever it is connected to line power. Incorrect installation of the motor or adjustable frequency drive may cause damage to the equipment, serious injury or death. Consequently, it is essential to comply with the instructions in this manual as well as local and national rules and safety regulations.

Safety Note

WARNING

The voltage of the adjustable frequency drive is dangerous whenever connected to line power. Incorrect installation of the motor, adjustable frequency drive or serial communication bus could result in death, serious personal injury or damage to the equipment. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

WARNING

Failure to follow instructions below could result in death or serious injury.

Safety Regulations

1. The adjustable frequency drive must be disconnected from line power if repair work is to be carried out. Make sure that the line power supply has been disconnected and that the necessary time has passed before removing motor and line power plugs.
2. The [STOP/RESET] key on the keypad of the adjustable frequency drive does not disconnect the equipment from line power and is thus not to be used as a safety switch.
3. Correct protective grounding of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The ground leakage currents are higher than 3.5 mA.
5. Protection against motor overload is set by par.1-90 [Motor Thermal Protection](#). If this function is desired, set par.1-90 [Motor Thermal Protection](#) to data value [ETR trip] (default value) or data value [ETR warning]. Note: The function is initialized at 1.16 x rated motor current and rated motor frequency. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.
6. Do not remove the plugs for the motor and line power supply while the adjustable frequency drive is connected to line power. Make sure that the line power supply has been disconnected and that the necessary time has passed before removing motor and line power plugs.
7. Please note that the adjustable frequency drive has more voltage inputs than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) and external 24 Vdc have been installed. Make sure that all voltage inputs have been disconnected and that the necessary time has passed before commencing repair work.

Installation at high altitudes **WARNING**

Installation at high altitude:

380–500 V, enclosure A, B and C: At altitudes above 6,561 ft [2 km], please contact Trane regarding PELV/Class II.

380–500 V, enclosure D, E and F: At altitudes above 9,842 ft [3 km], please contact Trane regarding PELV/Class II.

If the drive is to be installed over 6,561 ft, [2 km] altitude, then the PELV specifications are not fulfilled anymore, i.e., the distances between components and critical parts become too small. To maintain the clearance for functional insulation anyway, the risk for overvoltage must be reduced by means of external protective devices or some kind of galvanic isolation. De-rating should also be taken into consideration, since cooling the drive is more difficult at high altitude.

Please contact Trane in such cases.

 WARNING

Warning against Unintended Start

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the adjustable frequency drive is connected to line power. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stop functions are not sufficient.
2. While parameters are being changed, the motor may start. Consequently, the stop key [STOP/RESET] must always be activated, following which data can be modified.
3. A motor that has been stopped may start if faults occur in the electronics of the adjustable frequency drive, or if a temporary overload or a fault in the supply line power or the motor connection ceases.

 WARNING

Touching the electrical parts could result in death or serious injury - even after the equipment has been disconnected from line power.

Also make sure that other voltage inputs have been disconnected, such as external 24 VDC, load sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic backup. Refer to the Instruction Manual for further safety guidelines.

Failure to follow recommendations could result in death or serious injury.

⚠️ WARNING

The adjustable frequency drive DC link capacitors remain charged after power has been disconnected. To avoid an electrical shock hazard, disconnect the adjustable frequency drive from line power before carrying out maintenance.

Wait at least as follows before doing service on the adjustable frequency drive:

Failure to follow recommendations could result in death or serious injury.

Voltage (V)	Min. Waiting Time (Minutes)				
	4	15	20	30	40
200 - 240	1.5–5 hp [1.1–3.7 kW] 7.5–60 hp [5.5–45 kW]				
380 - 480	1.5–10 hp [1.1–7.5 kW]	15–125 hp [11–90 kW]	150–350 hp [110–250 kW]		450–1350 hp [315–1000 kW]
525–600	1.5–10 hp [1.1–7.5 kW]	15–125 hp [11–90 kW]			
525–690		15–125 hp [11–90 kW]	60–550 hp [45–400 kW]	600–1875 hp [450–1400 kW]	

Be aware that there may be high voltage on the DC link even when the LEDs are turned off.

Before commencing repair work

WARNING

Hazardous Voltage!

1. Disconnect the adjustable frequency drive from line power.
2. Disconnect DC bus terminals 88 and 89
3. Wait at least the time mentioned above in the section General Warning.
4. Remove motor cable

Failure to follow recommendations could result in death or serious injury.

Special conditions

Electrical ratings:

The rating indicated on the nameplate of the adjustable frequency drive is based on a typical 3-phase line power supply within the specified voltage, current and temperature ranges, which are expected to be used in most applications.

The adjustable frequency drives also support other special applications, which affect the electrical ratings of the adjustable frequency drive.

Special conditions that affect the electrical ratings might be:

- Single phase applications.
- High temperature applications that require derating of the electrical ratings.
- Marine applications with more severe environmental conditions.

Other applications might also affect the electrical ratings.

Consult the relevant sections in this manual and in the for information about the electrical ratings.

Installation requirements:

The overall electrical safety of the adjustable frequency drive requires special installation considerations regarding:

- Fuses and circuit breakers for overcurrent and short-circuit protection
- Selection of power cables (line power, motor, brake, load sharing and relay)
- Grid configuration (grounded delta transformer leg, IT, TN, etc.)
- Safety of low-voltage ports (PELV conditions).

Consult the relevant clauses in these instructions and in the for information about the installation requirements.

IT line power

WARNING

Do not connect adjustable frequency drives with RFI filters to line power supplies with a voltage between phase and ground of more than 440 V for 400 V drives and 760 V for 690 V drives.
For 400 VT IT line power and delta ground (grounded leg), AC line voltage may exceed 440 V between phase and ground.
For 690 VT IT line power and delta ground (grounded leg), AC line voltage may exceed 760 V between phase and ground.
Failure to follow recommendations could result in death or serious injury.

par.14-50 [RFI 1](#) can be used to disconnect the internal RFI capacitors from the RFI filter to ground.

Software Version and Approvals: TR200

TR200
Software version: 1.1.x





This manual can be used with all TR200 adjustable frequency drives with software version 1.1.x.
The software version number can be seen from par.15-43 [Software Version](#).

Disposal instructions



Equipment containing electrical components may not be disposed of together with domestic waste.
It must be separately collected with electrical and electronic waste according to local and currently valid legislation.



Introduction

Copyright, limitation of liability and revision rights

This publication contains information proprietary to Trane. By accepting and using this manual, the user agrees that the information contained herein will be used solely for operating equipment from Trane or equipment from other vendors provided that such equipment is intended for communication with Trane equipment over a serial communication link. This publication is protected under the copyright laws of most countries.

Trane does not warrant that a software program produced according to the guidelines provided in this manual will function properly in every physical, hardware or software environment.

Although Trane has tested and reviewed the documentation within this manual, Trane makes no warranty or representation, neither expressed nor implied, with respect to this documentation, including its quality, performance, or fitness for a particular purpose.

In no event shall Trane be liable for direct, indirect, special, incidental, or consequential damages arising out of the use, or the inability to use information contained in this manual, even if advised of the possibility of such damages. In particular, Trane is not responsible for any costs, including but not limited to those incurred as a result of lost profits or revenue, loss or damage of equipment, loss of computer programs, loss of data, the costs to substitute these, or any claims by third parties.

Trane reserves the right to revise this publication at any time and to make changes to its contents without prior notice or any obligation to notify former or present users of such revisions or changes.

Abbreviations

Alternating current	AC
American wire gauge	AWG
Ampere/AMP	A
Automatic Motor Adaptation	AMA
Current limit	I _{LIM}
Degrees Celsius	°C
Direct current	DC
Drive Dependent	D-TYPE
Electro Magnetic Compatibility	EMC
Electronic Thermal Relay	ETR
Adjustable Frequency Drive	FC
Gram	g
Hertz	Hz
Kilohertz	kHz
Local Control Panel	keypad
Meter	m
Millihenry Inductance	mH
Milliampere	mA
Millisecond	ms
Minute	min
Trane Drive Utility	TDU
Nanofarad	nF
Newton Meters	Nm
Nominal motor current	I _{M,N}
Nominal motor frequency	f _{M,N}
Nominal motor power	P _{M,N}
Nominal motor voltage	U _{M,N}
Parameter	par.
Protective Extra Low Voltage	PELV
Printed Circuit Board	PCB
Rated Inverter Output Current	I _{INV}
Revolutions Per Minute	RPM
Regenerative terminals	Regen
Second	s
Synchronous Motor Speed	n _s
Torque limit	T _{LIM}
Volt	V
The maximum output current	I _{DRIVE,MAX}
The rated output current supplied by the adjustable frequency drive	I _{DRIVE,N}

Available literature for TR200

x = Revision number

yy = Language code

Trane technical literature is available in print from your local Trane Sales Office or online at:
www.danfoss.com/BusinessAreas/DrivesSolutions/Documentations/Technical+Documentation.htm

Definitions

Adjustable frequency drive:

D-TYPE

Size and type of the connected adjustable frequency drive (dependencies).

I_{DRIVE,MAX}

The maximum output current.

I_{DRIVE,N}

The rated output current supplied by the adjustable frequency drive.

U_{DRIVE, MAX}

The maximum output voltage.

Input:

Control command

You can start and stop the connected motor by means of keypad and the digital inputs.

Functions are divided into two groups.

Functions in group 1 have higher priority than functions in group 2.

Group 1	Reset, Coasting stop, Reset and Coasting stop, Quick-stop, DC braking, Stop and the "Off" key.
Group 2	Start, Pulse start, Reversing, Start reversing, Jog and Freeze output

Motor:

f_{JOG}

The motor frequency when the jog function is activated (via digital terminals).

f_M

The motor frequency.

f_{MAX}

The maximum motor frequency.

f_{MIN}

The minimum motor frequency.

f_{M,N}

The rated motor frequency (nameplate data).

I_M

The motor current.

I_{M,N}

The rated motor current (nameplate data).

M-TYPE

Size and type of the connected motor (dependencies).

n_{M,N}

The rated motor speed (nameplate data).

n_s

Synchronous motor speed

$$n_s = \frac{2 \times \text{par. 1} - 23 \times 60 \text{ s}}{\text{par. 1} - 39}$$

P_{M,N}

The rated motor power (nameplate data).

$T_{M,N}$

The rated torque (motor).


U_M

The instantaneous motor voltage.

$U_{M,N}$

The rated motor voltage (nameplate data).

Break-away torque



DRIVE

The efficiency of the adjustable frequency drive is defined as the ratio between the power output and the power input.

Start-disable command

A stop command belonging to the group 1 control commands - see this group.

Stop command

See Control commands.

References:

Analog Reference

A signal transmitted to the analog inputs 53 or 54, can be voltage or current.

Binary Reference

A signal transmitted to the serial communication port.

Preset Reference

A defined preset reference to be set from -100% to +100% of the reference range. Selection of eight preset references via the digital terminals.

Pulse Reference

A pulse frequency signal transmitted to the digital inputs (terminal 29 or 33).

RefMAX

Determines the relationship between the reference input at 100% full scale value (typically 10 V, 20mA) and the resulting reference. The maximum reference value set in par.3-03 [Maximum Reference](#).

RefMIN

Determines the relationship between the reference input at 0% value (typically 0 V, 0 mA, 4 mA) and the resulting reference. The minimum reference value set in par.3-02 [Minimum Reference](#).

Miscellaneous:

Analog Inputs

The analog inputs are used for controlling various functions of the adjustable frequency drive.

There are two types of analog inputs:

Current input, 0–20 mA and 4–20 mA

Voltage input, 0–10 V DC (I)

Voltage input, -10–+10 V DC (TR200).

Analog Outputs

The analog outputs can supply a signal of 0–20 mA, 4–20 mA.

Automatic Motor Adaptation, AMA

AMA algorithm determines the electrical parameters for the connected motor at standstill.

Brake Resistor

The brake resistor is a module capable of absorbing the braking energy generated in regenerative braking. This regenerative braking energy increases the intermediate circuit voltage and a brake chopper ensures that the power is transmitted to the brake resistor.

CT Characteristics

Constant torque characteristics used for all applications such as conveyor belts, displacement pumps and cranes.

Digital Inputs

The digital inputs can be used for controlling various adjustable frequency drive functions.

Digital Outputs

The adjustable frequency drive features two solid state outputs that can supply a 24 V DC (max. 40 mA) signal.

DSP

Digital Signal Processor.

ETR

Electronic Thermal Relay is a thermal load calculation based on present load and time. Its purpose is to estimate the motor temperature.

Hiperface[®]

Hiperface[®] is a registered trademark by Stegmann.

Initializing

If initialization is carried out (par.14-22 [Operation Mode](#)), the adjustable frequency drive returns to the default setting.

Intermittent Duty Cycle

An intermittent duty rating refers to a sequence of duty cycles. Each cycle consists of an on-load and an off-load period. The operation can be either periodic duty or non-periodic duty.

keypad

The Local Control Panel (keypad) makes up a complete interface for control and programming of the adjustable frequency drive. The control panel is detachable and can be installed up to 10 ft [3 m] from the adjustable frequency drive, i.e., in a front panel by means of the installation kit option.

lsb

Least significant bit.

msb

Most significant bit.

MCM

Short for Mille Circular Mil, an American measuring unit for cable cross-sections. 1 MCM = 0.5067 mm².



Introduction

On-line/Off-line Parameters

Changes to on-line parameters are activated immediately after the data value is changed. Changes to off-line parameters are not activated until you enter [OK] on the keypad.

Process PID

The PID regulator maintains the desired speed, pressure, temperature, etc. by adjusting the output frequency to match the varying load.

PCD

Process Data

Pulse Input/Incremental Encoder

An external, digital pulse transmitter used for feeding back information on motor speed. The encoder is used in applications where great accuracy in speed control is required.

RCD

Residual Current Device.

Set-up

You can save parameter settings in four set-ups. Change between the four parameter set-ups, and edit one set-up, while another set-up is active.

SFAVM

Switching pattern called Stator Flux-oriented Aynchronous Vector Modulation (par.14-00 [Switching Pattern](#)).

Slip Compensation

The adjustable frequency drive compensates for the motor slip by giving the frequency a supplement that follows the measured motor load keeping the motor speed almost constant..

Smart Logic Control (SLC)

The SLC is a sequence of user defined actions executed when the associated user defined events are evaluated as true by the Smart Logic Controller. (Parameter group 13-xx [Smart Logic Control \(SLC\)](#)).

STW

Status Word

FC Standard Bus

Includes RS 485 bus with FC protocol or MC protocol. See par.8-30 [Protocol](#).

Thermistor:

A temperature-dependent resistor placed where the temperature is to be monitored (adjustable frequency drive or motor).

Trip

A state entered in fault situations, e.g., if the adjustable frequency drive is subject to an overtemperature or when the adjustable frequency drive is protecting the motor, process or mechanism. Restart is prevented until the cause of the fault has disappeared and the trip state is canceled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

Trip Locked

A state entered in fault situations when the adjustable frequency drive is protecting itself and requiring physical intervention, e.g., if the adjustable frequency drive is subject to a short circuit on the output. A locked trip can only be canceled by cutting off line power, removing the cause of the fault, and reconnecting the adjustable frequency drive. Restart is prevented until the trip state is canceled by activating reset or, in some cases, by being programmed to reset automatically. Trip may not be used for personal safety.

VT Characteristics

Variable torque characteristics used for pumps and fans.

VVC^{plus}

If compared with standard voltage/frequency ratio control, Voltage Vector Control (VVC^{plus}) improves the dynamics and the stability, both when the speed reference is changed and in relation to the load torque.

60° AVM

Switching pattern called 60° Asynchronous Vector Modulation (par.14-00 [Switching Pattern](#)).

Power Factor

The power factor is the relation between I_1 and I_{RMS} .

$$Power\ factor = \frac{\sqrt{3} \times U \times I_1 \cos\varphi}{\sqrt{3} \times U \times I_{RMS}}$$

The power factor for 3-phase control:

$$= \frac{I_1 \times \cos\varphi_1}{I_{RMS}} = \frac{I_1}{I_{RMS}} \text{ since } \cos\varphi_1 = 1$$

The power factor indicates to which extent the adjustable frequency drive imposes a load on the line power supply.

The lower the power factor, the higher the I_{RMS} for the same kW performance.

$$I_{RMS} = \sqrt{I_1^2 + I_5^2 + I_7^2 + \dots + I_n^2}$$

In addition, a high power factor indicates that the different harmonic currents are low.

The adjustable frequency drive's built-in DC coils produce a high power factor, which minimizes the imposed load on the line power supply.

Safety Precautions

WARNING

The voltage of the adjustable frequency drive is dangerous whenever connected to line power. Incorrect installation of the motor, adjustable frequency drive or serial communication bus may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

Safety Regulations

1. The line power supply to the adjustable frequency drive must be disconnected whenever repair work is to be carried out. Make sure that the line power supply has been disconnected and that the necessary time has elapsed before removing motor and line power supply plugs.
2. The [OFF] button on the control panel of the adjustable frequency driver does not disconnect the line power supply and consequently it must not be used as a safety switch.
3. The equipment must be properly grounded, the user must be protected against supply voltage and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The ground leakage current exceeds 3.5 mA.
5. Protection against motor overload is not included in the factory setting. If this function is desired, set par. 1-90 [Motor Thermal Protection](#) to data value ETR trip 1 [4] or data value ETR warning 1 [3].
6. Do not remove the plugs for the motor and line power supply while the adjustable frequency drive is connected to line power. Make sure that the line power supply has been disconnected and that the necessary time has elapsed before removing motor and line power plugs.
7. Please note that the adjustable frequency drive has more voltage sources than L1, L2 and L3, when load sharing (linking of DC intermediate circuit) or external 24 V DC are installed. Make sure that all voltage sources have been disconnected and that the necessary time has elapsed before commencing repair work.

Warning against unintended start

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the adjustable frequency drive is connected to line power. If personal safety considerations (e.g., risk of personal injury caused by contact with moving machine parts following an unintentional start) make

it necessary to ensure that no unintended start occurs, these stop functions are not sufficient. In such cases, the line power supply must be disconnected or the *Safe Stop* function must be activated.

2. The motor may start while setting the parameters. If this means that personal safety may be compromised (e.g., personal injury caused by contact with moving machine parts), motor starting must be prevented, for instance by use of the *Safe Stop* function or secure disconnection of the motor connection.
3. A motor that has been stopped with the line power supply connected, may start if faults occur in the electronics of the adjustable frequency drive, through temporary overload or if a fault in the power supply grid or motor connection is remedied. If unintended start must be prevented for personal safety reasons (e.g., risk of injury caused by contact with moving machine parts), the normal stop functions of the adjustable frequency drive are not sufficient. In such cases, the line power supply must be disconnected or the *Safe Stop* function must be activated.

NOTE

When using the *Safe Stop* function, always follow the instructions in the *Safe Stop* section of the Design Guide.

4. Control signals from, or internally within, the adjustable frequency drive may in rare cases be activated in error, be delayed or fail to occur entirely. When used in situations where safety is critical, e.g., when controlling the electromagnetic brake function of a hoist application, these control signals must not be relied on exclusively.

WARNING

Touching the electrical parts may be fatal - even after the equipment has been disconnected from line power.

Also make sure that other voltage inputs have been disconnected, such as external 24 V DC, load sharing (linkage of DC intermediate circuit), as well as the motor connection for kinetic backup.

Systems where adjustable frequency drives are installed must, if necessary, be equipped with additional monitoring and protective devices according to the valid safety regulations, e.g., law on mechanical tools, regulations for the prevention of accidents, etc. Modifications on the adjustable frequency drives by means of the operating software are allowed.

Hoisting applications:

The adjustable frequency drive functions for controlling mechanical brakes cannot be considered as a primary safety circuit. There must always be a redundancy for controlling external brakes.

Protection Mode

Once a hardware limit on motor current or DC link voltage is exceeded, the drive will enter "Protection mode". "Protection mode" means a change of the PWM modulation strategy and a low switching frequency to minimize losses. This continues 10 sec after the last fault and increases the reliability and the robustness of the drive while re-establishing full control of the motor.

In hoist applications, "Protection mode" is not usable because the drive will usually not be able to leave this mode again, and therefore it will extend the time before activating the brake – which is not recommended.

"Protection mode" can be disabled by setting par.14-26 [Trip Delay at Inverter Fault](#) to zero, which means that the drive will trip immediately if one of the hardware limits is exceeded.

NOTE

It is recommended to disable protection mode in hoisting applications (par.14-26 [Trip Delay at Inverter Fault](#) = 0)

How to Program

Local Control Panel

How to operate the Graphical keypad

The keypad is divided into four functional groups:


1. Graphical display with Status lines.
2. Menu keys and LEDs - selecting mode, changing parameters and switching between display functions.
3. Navigation keys and LEDs (LEDs).
4. Operation keys and LEDs.

Graphical display:

The LCD display is back lit with a total of 6 alpha-numeric lines. All data is displayed on the keypad which can show up to five operating variables while in [Status] mode.

Display lines:

- a. **Status line:** Status messages displaying icons and graphics.
- b. **Line 1-2:** Operator data lines displaying data and variables defined or chosen by the user. By pressing the [Status] key, up to one extra line can be added.
- c. **Status line:** Status messages displaying text.



The display is divided into 3 sections:

The **top section** (a) shows the status when in status mode or up to 2 variables when not in status mode and in case of an alarm/warning.

The number of the Active Set-up (selected as the Active Set-up in par.0-10 [Active Set-up](#)) is shown. When programming in another set-up than the Active Set-up, the number of the set-up being programmed appears to the right in brackets.

The **Middle section** (b) shows up to 5 variables with related unit, regardless of status. In the case of an alarm/warning, the warning is shown instead of the variables.

The **bottom section** (c) always shows the state of the adjustable frequency drive in status mode.

It is possible to toggle between three status read-out displays by pressing the [Status] key.
Operating variables with different formatting are shown in each status screen - see below.

Several values or measurements can be linked to each of the displayed operating variables. The values / measurements to be displayed can be defined via par.0-20 [Display Line 1.1 Small](#), par.0-21 [Display Line 1.2 Small](#), par.0-22 [Display Line 1.3 Small](#), par.0-23 [Display Line 2 Large](#) and par.0-24 [Display Line 3 Large](#), which can be accessed via [QUICK MENU], "Q3 Function Set-ups", "Q3-1 General Settings", "Q3-13 Display Settings".

Each value/measurement readout parameter selected in par.0-20 [Display Line 1.1 Small](#) to par.0-24 [Display Line 3 Large](#) has its own scale and number of digits after a possible decimal point. Larger numeric values are displayed with few digits after the decimal point.


Ex.: Current readout
5.25 A; 15.2 A 105 A.

Status display I:

This readout state is standard after start-up or initialization.

Use [INFO] to obtain information about the value/measurement linked to the displayed operating variables (1.1, 1.2, 1.3, 2, and 3).

See the operating variables shown in the display in this figure. 1.1, 1.2 and 1.3 are shown in small size. 2 and 3 are shown in medium size.




Status display II:

See the operating variables (1.1, 1.2, 1.3, and 2) shown in the display in this illustration.


In the example, Speed, Motor current, Motor power and Frequency are selected as variables in the first and second lines.

1.1, 1.2 and 1.3 are shown in small size. 2 is shown in large size.



Status display III:


This state displays the event and action of the Smart Logic Control. For further information, see section *Smart Logic Control*.



Display Contrast Adjustment

Press [status] and [▲] for darker display

Press [status] and [▼] for brighter display




LEDs:

If certain threshold values are exceeded, the alarm and/or warning LED lights up. A status and alarm text appear on the control panel.

The On LED is activated when the adjustable frequency drive receives power from AC line voltage, a DC bus terminal, or an external 24 V supply. At the same time, the back light is on.

- Green LED/On: Control section is working.
- Yellow LED/Warn.: Indicates a warning.
- Flashing Red LED/Alarm: Indicates an alarm.



Keys

Menu keys

The menu keys are divided into functions. The keys below the display and indicator lamps are used for parameter set-up, including choice of display indication during normal operation.



[Status]

indicates the status of the adjustable frequency drive and/or the motor. Three different readouts can be chosen by pressing the [Status] key:

5 line readouts, 4 line readouts or Smart Logic Control.

Use [Status] for selecting the mode of display or for changing back to display mode from either the quick menu mode, main menu mode or alarm mode. Also use the [Status] key to toggle single or double readout mode.

[Quick Menu]

allows quick set-up of the adjustable frequency drive. **The most common TR200 functions can be programmed here.**

The [Quick Menu] consists of:

- **My Personal Menu**
- **Quick Set-up**
- **Function Set-up**
- **Changes Made**
- **Loggings**

The Function Set-up provides quick and easy access to all parameters required for the majority of TR200 applications including most VAV and CAV supply and return fans, cooling tower fans, primary, secondary and condenser water pumps and other pump, fan and compressor applications. Among other features, it also includes parameters for selecting which variables to display on the keypad, digital preset speeds, scaling of analog references, closed-loop single zone and multi-zone applications and specific functions related to fans, pumps and compressors.

The Quick Menu parameters can be accessed immediately unless a password has been created via par. 0-60 [Main Menu Password](#), par. 0-61 [Access to Main Menu w/o Password](#), par. 0-65 [Personal Menu Password](#) or par. 0-66 [Access to Personal Menu w/o Password](#).

It is possible to switch directly between Quick Menu mode and Main Menu mode.

[Main Menu]

is used for programming all parameters. The main menu parameters can be accessed immediately unless a password has been created via par. 0-60 [Main Menu Password](#), par. 0-61 [Access to Main Menu w/o Pass-](#)

[word, par.0-65 Personal Menu Password](#) or [par.0-66 Access to Personal Menu w/o Password](#). For the majority of TR200 applications, it is not necessary to access the Main Menu parameters but instead the Quick Menu, Quick Set-up and Function Set-up provide the simplest and quickest access to parameters that are typically required.

It is possible to switch directly between Main Menu mode and Quick Menu mode.

A parameter shortcut can be carried out by pressing the **[Main Menu]** key for 3 seconds. The parameter shortcut allows direct access to any parameter.

[Alarm Log]

displays an Alarm list of the five latest alarms (numbered A1-A5). To obtain additional details about an alarm, use the arrow keys to navigate to the alarm number and press **[OK]**. Information is displayed about the condition of the adjustable frequency drive before it enters alarm mode.

The alarm log button on the keypad allows access to both alarm log and maintenance log.

[Back]

reverts to the previous step or layer in the navigation structure.

[Cancel]

last change or command will be cancelled as long as the display has not been changed.

[Info]

displays information about a command, parameter, or function in any display window. **[Info]** provides detailed information when needed.


Exit Info mode by pressing either **[Info]**, **[Back]**, or **[Cancel]**.



Navigation Keys

The four navigation arrows are used to navigate between the different choices available in **[Quick Menu]**, **[Main Menu]** and **[Alarm Log]**. Use the keys to move the cursor.

[OK] is used for choosing a parameter marked by the cursor and for enabling the change of a parameter.



Operation Keys for local control are found at the bottom of the control panel.



[Hand On]

enables control of the adjustable frequency drive via the GLCP. [Hand On] also starts the motor, and it is now possible to enter the motor speed data by means of the arrow keys. The key can be selected as Enable [1] or Disable [0] via par.0-40 [\[Hand on\] Key on LCP](#).

The following control signals will still be active when [Hand On] is activated:

- [Hand On] - [Off] - [Auto on]
- Reset
- Coasting stop inverse
- Reversing
- Set-up select lsb - Set-up select msb
- Stop command from serial communication
- Quick stop
- DC brake

NOTE: External stop signals activated by means of control signals or a serial bus will override a "start" command via the keypad.

[Off]

stops the connected motor. The key can be selected as Enable [1] or Disable [0] via par.0-41 [\[Off\] Key on LCP](#). If no external stop function is selected and the [Off] key is inactive the motor can only be stopped by disconnecting the line power supply.

[Auto on]

enables the adjustable frequency drive to be controlled via the control terminals and/or serial communication. When a start signal is applied on the control terminals and/or the bus, the adjustable frequency drive will start. The key can be selected as Enable [1] or Disable [0] via par.0-42 [\[Auto on\] Key on LCP](#).

NOTE: An active HAND-OFF-AUTO signal via the digital inputs has higher priority than the control keys [Hand on] – [Auto on].


[Reset]

is used for resetting the adjustable frequency drive after an alarm (trip). It can be selected as *Enable* [1] or *Disable* [0] via par.0-43 [\[Reset\] Key on LCP](#).

The parameter shortcut can be carried out by holding down the [Main Menu] key for 3 seconds. The parameter shortcut allows direct access to any parameter.

Quick Transfer of Parameter Settings between Multiple Adjustable Frequency Drives

Once the set-up of an adjustable frequency drive is complete, we recommend that you store the data in the keypad or on a PC via MCT 10 Set-up Software Tool.



Data storage in keypad:

1. Go to par.0-50 [LCP Copy](#)
2. Press the [OK] key.
3. Select "All to keypad"
4. Press the [OK] key.

All parameter settings are now stored in the keypad indicated by the progress bar. When 100% is reached, press [OK].

NOTE

Stop the motor before performing this operation.

You can now connect the keypad to another adjustable frequency drive and copy the parameter settings to this adjustable frequency drive as well.

Data transfer from the keypad to the adjustable frequency drive:

1. Go to par.0-50 [LCP Copy](#)
2. Press the [OK] key.
3. Select "All from keypad"
4. Press the [OK] key.

The parameter settings stored in the keypad are now transferred to the adjustable frequency drive indicated by the progress bar. When 100% is reached, press [OK].

NOTE

Stop the motor before performing this operation.



Parameter Set-up

The adjustable frequency drive can be used for practically all assignments, thus offering a significant number of parameters. The series offers a choice between two programming modes - the Quick Menu mode and the Main Menu mode.

The latter provides access to all parameters. The former takes the user through a few parameters making it possible to **program the majority of TR200 applications**.

Regardless of the mode of programming, you can change a parameter both in quick menu mode and in main menu mode.

Quick Menu mode

Parameter data

The keypad provides access to all parameters listed under the quick menus. To set parameters using the [Quick Menu] button - enter or change parameter data or settings in accordance with the following procedure:

1. Press Quick Menu button
2. Use the [▲] and [▼] buttons to find the parameter you want to change
3. Press [OK]
4. Use [▲] and [▼] buttons to select the correct parameter setting
5. Press [OK]
6. To move to a different digit within a parameter setting, use the [◀] and [▶] buttons
7. Highlighted area indicates digit selected for change
8. Press [Cancel] button to disregard change, or press [OK] to accept change and enter the new setting

Example of changing parameter data

Assume parameter 22-60 is set to [Off]. However, you want to monitor the fan belt condition - non-broken or broken - according to the following procedure:

1. Press Quick Menu key
2. Choose Function Set-ups with the [▼] button
3. Press [OK]
4. Choose Application Settings with the [▼] button
5. Press [OK]
6. Press [OK] again for Fan Functions
7. Choose Broken Belt Function by pressing [OK]
8. With [▼] button, choose [2] Trip

The adjustable frequency drive will now trip if a broken fan belt is detected.

Select [My Personal Menu] to display personal parameters:

Select [My Personal Menu] to display only the parameters, which have been pre-selected and programmed as personal parameters. For example, you may have pre-programmed personal parameters to be in My Personal Menu during factory commissioning to make on-site commissioning/fine tuning simpler. These parameters are selected in par.0-25 [My Personal Menu](#). Up to 20 different parameters can be programmed in this menu.

Select [Changes Made] to get information about:

- The last 10 changes. Use the up/down navigation keys to scroll between the last 10 changed parameters.
- The changes made since default setting.

Select [Loggings]:

to get information about the display line readouts. The information is shown as graphs.

Only display parameters selected in par.0-20 [Display Line 1.1 Small](#) and par.0-24 [Display Line 3 Large](#) can be viewed. It is possible to store up to 120 samples in the memory for later reference.

Quick Setup

Efficient Parameter Set-up for TR200 Applications:

The parameters can easily be set up for the vast majority of the TR200 applications only by using the **[Quick Set-up]** option.

After pressing [Quick Menu], the different choices in the quick menu are listed. See also figure 6.1 below and tables Q3-1 to Q3-4 in the following Function Set-ups section.

Example of using the Quick Set-up option:

Assume you want to set the ramp-down time to 100 seconds!

1. Select [Quick Setup]. The first par.0-01 [Language](#) in Quick Set-up appears
2. Press [▼] repeatedly until par.3-42 [Ramp 1 Ramp-down Time](#) appears with the default setting of 20 seconds
3. Press [OK]
4. Use the [◀] button to highlight the third digit before the comma
5. Change '0' to '1' by using the [▲] button
6. Use the [▶] button to highlight the digit '2'
7. Change '2' to '0' with the [▼] button
8. Press [OK]

The new ramp-down time is now set to 100 seconds.

It is recommended to do the set-up in the order listed.

NOTE: A complete description of the function is found in the parameter sections of this manual.




Figure 3. 6: Quick Menu view.

The Quick Set-up menu gives access to the 18 most important set-up parameters of the adjustable frequency drive. After programming, the adjustable frequency drive will, in most cases, be ready for operation. The 18 Quick Set-up parameters are shown in the table below. A complete description of the function is given in the parameter description sections of this manual.

Parameter	[Units]
par.0-01 Language	
par.1-20 Motor Power [kW]	[kW]
par.1-21 Motor Power [HP]	[HP]
par.1-22 Motor Voltage*	[V]
par.1-23 Motor Frequency	[Hz]
par.1-24 Motor Current	[A]
par.1-25 Motor Nominal Speed	[RPM]
par.1-28 Motor Rotation Check	[Hz]
par.3-41 Ramp 1 Ramp-up Time	[s]
par.3-42 Ramp 1 Ramp-down Time	[s]
par.4-11 Motor Speed Low Limit [RPM]	[RPM]
par.4-12 Motor Speed Low Limit [Hz]*	[Hz]
par.4-13 Motor Speed High Limit [RPM]	[RPM]
par.4-14 Motor Speed High Limit [Hz]*	[Hz]
par.3-19 Jog Speed [RPM]	[RPM]
par.3-11 Jog Speed [Hz]*	[Hz]
Par.5-12 Terminal 27 Digital Input	
par.5-40 Function Relay**	

Table 3. 1: Quick Set-up parameters

*The display showing depends on choices made in par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#). The default settings of par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#) depend on which region of the world the adjustable frequency drive is supplied to but can be re-programmed as required.

For a detailed information about settings and programming, please see the *TR200 Programming Guide*

** par.5-40 [Function Relay](#), is an array, where one may choose between Relay1 [0] or Relay2 [1]. Standard setting is Relay1 [0] with the default choice Alarm [9].

See the parameter description in the section *Commonly Used Parameters*.

NOTE: If [No Operation] is selected in par.5-12 [Terminal 27 Digital Input](#), no connection to +24 V on terminal 27 is necessary to enable start.

If [Coast Inverse] (factory default value) is selected in par.5-12 [Terminal 27 Digital Input](#), a connection to +24 V is necessary to enable start.

Function Set-ups

The Function set-up provides quick and easy access to all parameters required for the majority of TR200 applications including most VAV and CAV supply and return fans, cooling tower fans, primary, secondary and condenser water pumps and other pump, fan and compressor applications.

How to access Function set-up - example



Figure 3.7: Step 1: Turn on the adjustable frequency drive (yellow LED lights)



Figure 3.8: Step 2: Press the [Quick Menus] button (quick menu choices appear).



Figure 3.9: Step 3: Use the up/down navigation keys to scroll down to Function set-ups. Press [OK].




Figure 3.10: Step 4: Function set-ups choices appear. Choose 03-1 *General Settings*. Press [OK].




Figure 3.11: Step 5: Use the up/down navigation keys to scroll down to i.e. 03-11 *Analog Outputs*. Press [OK].




Figure 3.12: Step 6: Choose par. 6-50. Press [OK].




Figure 3.13: Step 7: Use the up/down navigation keys to select between the different choices. Press [OK].

Function Set-ups parameters

The Function Set-ups parameters are grouped in the following way:

Q3-1 General Settings			
Q3-10 Adv. Motor Set-tings	Q3-11 Analog Output	Q3-12 Clock Settings	Q3-13 Display Settings
par.1-90 Motor Thermal Protection	par.6-50 Terminal 42 Out-put	par.0-70 Date and Time	par.0-20 Display Line 1.1 Small
par.1-93 Thermistor Source	par.6-51 Terminal 42 Out-put Min Scale	par.0-71 Date Format	Par.0-21 Display Line 1.2 Small
par.1-29 Automatic Mo-tor Adaptation (AMA)	par.6-52 Terminal 42 Out-put Max Scale	par.0-72 Time Format	Par.0-22 Display Line 1.3 Small
par.14-01 Switching Fre-quency		par.0-74 DST/Summer-time	Par.0-23 Display Line 2 Large
par.4-53 Warning Speed High		par.0-76 DST/Summer-time Start	Par.0-24 Display Line 3 Large
		par.0-77 DST/Summer-time End	par.0-37 Display Text 1
			par.0-38 Display Text 2
			par.0-39 Display Text 3

Q3-2 Open-loop Settings	
Q3-20 Digital Reference	Q3-21 Analog Reference
par.3-02 Minimum Reference	par.3-02 Minimum Reference
par.3-03 Maximum Reference	par.3-03 Maximum Reference
par.3-10 Preset Reference	par.6-10 Terminal 53 Low Voltage
par.5-13 Terminal 29 Digital Input	par.6-11 Terminal 53 High Voltage
par.5-14 Terminal 32 Digital Input	par.6-12 Terminal 53 Low Current
Par.5-15 Terminal 33 Digital Input	par.6-13 Terminal 53 High Current
	par.6-14 Terminal 53 Low Ref./Feedb. Value
	par.6-15 Terminal 53 High Ref./Feedb. Value

Q3-3 Closed-loop Settings

Q3-30 Single Zone Int. Setpoint	Q3-31 Single Zone Ext. Setpoint
par.1-00 Configuration Mode	par.1-00 Configuration Mode
Par.20-12 Reference/Feedback Unit	Par.20-12 Reference/Feedback Unit
par.20-13 Minimum Reference/Feedb.	par.20-13 Minimum Reference/Feedb.
par.20-14 Maximum Reference/Feedb.	par.20-14 Maximum Reference/Feedb.
par.6-22 Terminal 54 Low Current	par.6-10 Terminal 53 Low Voltage
par.6-24 Terminal 54 Low Ref./Feedb. Value	par.6-11 Terminal 53 High Voltage
par.6-25 Terminal 54 High Ref./Feedb. Value	par.6-12 Terminal 53 Low Current
par.6-26 Terminal 54 Filter Time Constant	par.6-13 Terminal 53 High Current
par.6-27 Terminal 54 Live Zero	par.6-14 Terminal 53 Low Ref./Feedb. Value
par.6-00 Live Zero Timeout Time	par.6-15 Terminal 53 High Ref./Feedb. Value
par.6-01 Live Zero Timeout Function	par.6-22 Terminal 54 Low Current
par.20-21 Setpoint 1	par.6-24 Terminal 54 Low Ref./Feedb. Value
par.20-81 PID Normal/ Inverse Control	par.6-25 Terminal 54 High Ref./Feedb. Value
par.20-82 PID Start Speed [RPM]	par.6-26 Terminal 54 Filter Time Constant
par.20-83 PID Start Speed [Hz]	par.6-27 Terminal 54 Live Zero
par.20-93 PID Proportional Gain	par.6-00 Live Zero Timeout Time
par.20-94 PID Integral Time	par.6-01 Live Zero Timeout Function
par.20-70 Closed-loop Type	par.20-81 PID Normal/ Inverse Control
par.20-71 PID Performance	par.20-82 PID Start Speed [RPM]
par.20-72 PID Output Change	par.20-83 PID Start Speed [Hz]
par.20-73 Minimum Feedback Level	par.20-93 PID Proportional Gain
par.20-74 Maximum Feedback Level	par.20-94 PID Integral Time
par.20-79 PID Autotuning	par.20-70 Closed-loop Type
	par.20-71 PID Performance
	par.20-72 PID Output Change
	par.20-73 Minimum Feedback Level
	par.20-74 Maximum Feedback Level
	par.20-79 PID Autotuning

Q3-32 Multi Zone / Adv


par.1-00	Configuration Mode
par.3-15	Reference 1 Source
par.3-16	Reference 2 Source
par.20-00	Feedback 1 Source
par.20-01	Feedback 1 Conversion
par.20-02	Feedback 1 Source Unit
par.20-03	Feedback 2 Source
par.20-04	Feedback 2 Conversion
par.20-05	Feedback 2 Source Unit
par.20-06	Feedback 3 Source
par.20-07	Feedback 3 Conversion
par.20-08	Feedback 3 Source Unit
Par.20-12	Reference/Feedback Unit
par.20-13	Minimum Reference/Feedb.
par.20-14	Maximum Reference/Feedb.
par.6-10	Terminal 53 Low Voltage
par.6-11	Terminal 53 High Voltage
par.6-12	Terminal 53 Low Current
par.6-13	Terminal 53 High Current
par.6-14	Terminal 53 Low Ref./Feedb. Value
par.6-15	Terminal 53 High Ref./Feedb. Value
par.6-16	Terminal 53 Filter Time Constant
par.6-17	Terminal 53 Live Zero
par.6-20	Terminal 54 Low Voltage
par.6-21	Terminal 54 High Voltage
par.6-22	Terminal 54 Low Current
par.6-23	Terminal 54 High Current
par.6-24	Terminal 54 Low Ref./Feedb. Value
par.6-25	Terminal 54 High Ref./Feedb. Value
par.6-26	Terminal 54 Filter Time Constant
par.6-27	Terminal 54 Live Zero
par.6-00	Live Zero Timeout Time
par.6-01	Live Zero Timeout Function
par.4-56	Warning Feedback Low
par.4-57	Warning Feedback High
par.20-20	Feedback Function
par.20-21	Setpoint 1
par.20-22	Setpoint 2
par.20-81	PID Normal/ Inverse Control
par.20-82	PID Start Speed [RPM]
par.20-83	PID Start Speed [Hz]
par.20-93	PID Proportional Gain
par.20-94	PID Integral Time
par.20-70	Closed-loop Type
par.20-71	PID Performance
par.20-72	PID Output Change
par.20-73	Minimum Feedback Level
par.20-74	Maximum Feedback Level
par.20-79	PID Autotuning

Q3-4 Application Settings		
Q3-40 Fan Functions	Q3-41 Pump Functions	Q3-42 Compressor Functions
par.22-60 Broken Belt Function	par.22-22 Low Speed Detection	par.1-03 Torque Characteristics
par.22-61 Broken Belt Torque	par.22-23 No-Flow Function	par.1-71 Start Delay
par.22-62 Broken Belt Delay	par.22-24 No-Flow Delay	par.22-75 Short Cycle Protection
par.4-64 Semi-Auto Bypass Set-up	par.22-40 Minimum Run Time	par.22-76 Interval between Starts
par.1-03 Torque Characteristics	par.22-41 Minimum Sleep Time	par.22-77 Minimum Run Time
par.22-22 Low Speed Detection	par.22-42 Wake-up Speed [RPM]	par.5-01 Terminal 27 Mode
par.22-23 No-Flow Function	par.22-43 Wake-up Speed [Hz]	par.5-02 Terminal 29 Mode
par.22-24 No-Flow Delay	par.22-44 Wake-up Ref./FB Difference	Par.5-12 Terminal 27 Digital Input
par.22-40 Minimum Run Time	par.22-45 Setpoint Boost	par.5-13 Terminal 29 Digital Input
par.22-41 Minimum Sleep Time	par.22-46 Maximum Boost Time	par.5-40 Function Relay
par.22-42 Wake-up Speed [RPM]		par.1-73 Flying Start
par.22-43 Wake-up Speed [Hz]		par.1-86 Trip Speed Low [RPM]
par.22-44 Wake-up Ref./FB Difference	par.1-03 Torque Characteristics	par.1-87 Trip Speed Low [Hz]
par.22-45 Setpoint Boost	par.1-73 Flying Start	
par.22-46 Maximum Boost Time		
par.2-10 Brake Function		
Par.2-16 AC Brake Max. Current		
par.2-17 Over-voltage Control		
par.1-73 Flying Start		
par.1-71 Start Delay		
par.1-80 Function at Stop		
par.2-00 DC Hold/Preheat Current		
par.4-10 Motor Speed Direction		

See also for a detailed description of the Function Setups parameter groups.

Main Menu Mode

Select main menu mode by pressing the [Main Menu] key. The readout below appears on the display. The middle and bottom sections on the display show a list of parameter groups which can be chosen by toggling the up and down buttons.



Each parameter has a name and number which remain the same regardless of the programming mode. In main menu mode, the parameters are divided into groups. The first digit of the parameter number (from the left) indicates the parameter group number.

All parameters can be changed in the main menu. However, depending on the choice of configuration (par. 1-00 [Configuration Mode](#)), some parameters can be hidden.

Parameter Selection


In main menu mode, the parameters are divided into groups. You select a parameter group by means of the navigation keys.

The following parameter groups are accessible:

Group no.	Parameter group:
0	Operation/Display
1	Load/Motor
2	Brakes
3	References/Ramps
4	Limits/Warnings
5	Digital In/Out
6	Analog In/Out
8	Comm. and Options
11	LonWorks
13	Smart Logic
14	Special Functions
15	Drive Information
16	Data Readouts
18	Data Readouts 2
20	Drive Closed-loop
21	Ext. Closed-loop
22	Application Functions
23	Time-based Functions
24	Application Functions 2

After selecting a parameter group, choose a parameter by means of the navigation keys.

The middle section on the display shows the parameter number and name as well as the selected parameter value.




Changing Data

The procedure for changing data is the same whether you select a parameter in the quick menu or the main menu mode. Press [OK] to change the selected parameter.

The procedure for changing data depends on whether the selected parameter represents a numerical data value or a text value.


Changing a Text Value

If the selected parameter is a text value, change the text value by means of the [▲] [▼] navigation keys. The up key increases the value, and the down key decreases the value. Place the cursor on the value you want to save and press [OK].




Changing a Group of Numeric Data Values

If the chosen parameter represents a numeric data value, change the chosen data value by means of the [◀] [▶] navigation keys as well as the [▲] [▼] navigation keys. Use the [◀] [▶] navigation keys to move the cursor horizontally.



Use the [▲] [▼] navigation keys to change the data value. The up key enlarges the data value, and the down key reduces the data value. Place the cursor on the value you want to save and press [OK].



Changing a Data Value, Step-by-Step

Certain parameters can be changed step by step or infinitely varying. This applies to par.1-20 [Motor Power \[kW\]](#), par.1-22 [Motor Voltage](#) and par.1-23 [Motor Frequency](#).

The parameters are changed both as a group of numeric data values and as numeric data values infinitely varying.

Readout and Programming of Indexed Parameters

Parameters are indexed when placed in a rolling stack.

par.15-30 [Alarm Log: Error Code](#) to par.15-33 [Alarm Log: Date and Time](#) contain a fault log which can be read out. Choose a parameter, press [OK], and use the up/down navigation keys to scroll through the value log.

Use par.3-10 [Preset Reference](#) as another example:

Choose the parameter, press [OK], and use the up/down navigation keys to scroll through the indexed values. To change the parameter value, select the indexed value and press [OK]. Change the value by using the up/down keys. Press [OK] to accept the new setting. Press [CANCEL] to abort. Press [Back] to leave the parameter.



How to Program

Initialization to Default Settings

Initialize the adjustable frequency drive to default settings in two ways:

Recommended initialization (via par.14-22 [Operation Mode](#))

1. Select par.14-22 [Operation Mode](#)
2. Press [OK]
3. Select "Initialization"
4. Press [OK]
5. Cut off the line power supply and wait until the display turns off.
6. Reconnect the line power supply - the adjustable frequency drive is now reset.
7. Change par.14-22 [Operation Mode](#) back to *Normal Operation*.

NOTE

Resets parameters selected in Personal Menu with default factory setting.

par.14-22 [Operation Mode](#) initializes all except:

par.14-50 RFI 1
par.8-30 Protocol
par.8-31 Address
par.8-32 Baud Rate
par.8-35 Minimum Response Delay
par.8-36 Maximum Response Delay
par.8-37 Maximum Inter-Char Delay
par.15-00 Operating Hours to par.15-05 Over Volts
par.15-20 Historic Log: Event to par.15-22 Historic Log: Time
par.15-30 Alarm Log: Error Code to par.15-32 Alarm Log: Time

Manual initialization

- | | |
|--|---|
| 1. | Disconnect from the line power and wait until the display turns off. |
| 2a. | Press [Status] - [Main Menu] - [OK] at the same time while powering up for LCP 102, Graphical Display |
| 2b. | Press [Menu] while powering up for LCP 101, Numerical Display |
| 3. | Release the keys after 5 s. |
| 4. | The adjustable frequency drive is now programmed according to default settings. |
| This procedure initializes all except: par.15-00 Operating Hours ; par.15-03 Power-ups ; par.15-04 Over Temps ; par.15-05 Over Volts . | |

NOTE

When you carry out manual initialization, you also reset serial communication, par.14-50 [RFI 1](#) and fault log settings. Removes parameters selected in par.25-00 [Cascade Controller](#).

NOTE

After initialization and power cycling, the display will not show any information until after a couple of minutes.

Parameter Description

Parameter Selection

Main Menu Structure

Parameters for the adjustable frequency drive are grouped into various parameter groups for easy selection of the correct parameters for optimized operation of the adjustable frequency drive.

The vast majority of TR200 applications can be programmed using the Quick Menu button and selecting the parameters under Quick Set-up and Function Set-ups.

Descriptions and default settings of parameters may be found under the section Parameter Lists at the back of this manual.

0-xx Operation/Display	10-xx CAN Serial Communication Bus
1-xx Load/Motor	11-xx LonWorks
2-xx Brakes	13-xx Smart Logic Controller
3-xx Reference/Ramps	14-xx Special Functions
4-xx Limits/ Warnings	15-xx Adjustable Frequency Drive Information
5-xx Digital In/Out	16-xx Data Readouts
6-xx Analog In/Out	18-xx Info & Readouts
8-xx Comm. and Options	20-xx Adjustable Frequency Drive Closed-loop
9-xx Profibus	21-xx Ext. Closed-loop
	22-xx Application Functions
	23-xx Time Based Functions
	24-xx Application Functions 2

Main Menu - Operation and Display - Group 0

0-** Operation / Display

Parameters related to the fundamental functions of the adjustable frequency drive, function of the keypad buttons and configuration of the keypad display.

0-0* Basic Settings

Parameter group for basic adjustable frequency drive settings.

0-01 Language

Option:		Function:
		Defines the language to be used in the display. The adjustable frequency drive can be delivered with 2 different language packages. English and German are included in both packages. English cannot be erased or manipulated.
[0] *	English	Part of Language packages 1 - 2
[1]	Deutsch	Part of Language packages 1 - 2
[2]	Francais	Part of Language package 1
[3]	Dansk	Part of Language package 1
[4]	Spanish	Part of Language package 1
[5]	Italiano	Part of Language package 1
[6]	Svenska	Part of Language package 1
[7]	Nederlands	Part of Language package 1
[10]	Chinese	Language package 2
[20]	Suomi	Part of Language package 1
[22]	English US	Part of Language package 1
[27]	Greek	Part of Language package 1
[28]	Bras.port	Part of Language package 1
[36]	Slovenian	Part of Language package 1
[39]	Korean	Part of Language package 2
[40]	Japanese	Part of Language package 2
[41]	Turkish	Part of Language package 1
[42]	Trad.Chinese	Part of Language package 2
[43]	Bulgarian	Part of Language package 1
[44]	Srpski	Part of Language package 1
[45]	Romanian	Part of Language package 1
[46]	Magyar	Part of Language package 1
[47]	Czech	Part of Language package 1
[48]	Polski	Part of Language package 1
[49]	Russian	Part of Language package 1
[50]	Thai	Part of Language package 2
[51]	Bahasa Indonesia	Part of Language package 2
[99]	Unknown	

0-02 Motor Speed Unit

Option:

Function:

This parameter cannot be adjusted while the motor is running. The display showing depends on settings in par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#). The default setting of par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#) depends on which region of the world the adjustable frequency drive is supplied to, but can be re-programmed as required.

NOTE

Changing the **Motor Speed Unit** will reset certain parameters to their initial value. It is recommended to select the motor speed unit first before modifying other parameters.

[0]	RPM	Selects display of motor speed variables and parameters (i.e. references, feedbacks and limits) in terms of motor speed (RPM).
-----	-----	--

[1] *	Hz	Selects display of motor speed variables and parameters (i.e., references, feedbacks and limits) in terms of output frequency to the motor (Hz).
-------	----	--

0-03 Regional Settings

Option:

Function:

This parameter cannot be adjusted while the motor is running. The display showing depends on settings in par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#). The default setting of par.0-02 [Motor Speed Unit](#) and par.0-03 [Regional Settings](#) depends on which region of the world the adjustable frequency drive is supplied to but can be re-programmed as required.

[0] *	International	Sets par.1-20 Motor Power [kW] units to [kW] and the default value of par.1-23 Motor Frequency [50 Hz].
-------	---------------	---

[1]	North America	Sets par.1-21 Motor Power [HP] units to HP and the default value of par.1-23 Motor Frequency to 60 Hz.
-----	---------------	--

The setting not used is made invisible.

0-04 Operating State at Power-up

Option:

Function:

Select the operating mode upon reconnection of the adjustable frequency drive to AC line voltage after power-down when operating in hand (local) mode.

[0] *	Resume	Resumes operation of the adjustable frequency drive maintaining the same local reference and the same start/stop condition (applied by [Hand On]/[Off] on the keypad or Hand Start via a digital input as before the adjustable frequency drive was powered down.
-------	--------	---

[1]	Forced stop, ref=old	Uses saved reference [1] to stop the adjustable frequency drive but at the same time retain in memory the local speed reference prior to power-down. After AC line voltage is reconnected and after receiving a start command (using the keypad [Hand On] button or Hand Start command via a digital input), the adjustable frequency drive restarts and operates at the retained speed reference.
-----	----------------------	--

0-05 Local Mode Unit

Option:

Function:

Defines if the local reference unit should be displayed in terms of the motor shaft speed (in RPM/Hz) or as percent.

[0] * As Motor Speed Unit

[1] %

0-1* Set-up Operations

Define and control the individual parameter set-ups.

The adjustable frequency drive has four parameter set-ups that can be programmed independently of each other. This makes the adjustable frequency drive very flexible and able to meet the requirements of many different TR200 system control schemes often saving the cost of external control equipment. For example, these can be used to program the adjustable frequency drive to operate according to one control scheme in one set-up (e.g., daytime operation) and another control scheme in another set-up (e.g., night set back). Alternatively, they can be used by an AHU or packaged unit OEM to identically program all their factory-fitted adjustable frequency drives to the same parameters on different equipment models within a range, and then during production/commissioning, only need a specific set-up selection depending on which model the adjustable frequency drive is installed on within that range.

The active set-up (i.e., the set-up in which the adjustable frequency drive is currently operating) can be selected in par.0-10 [Active Set-up](#) and is displayed in the keypad. Using Multi set-up, it is possible to switch between set-ups with the adjustable frequency drive running or stopped, via digital input or serial communication commands (e.g., for night set back). If it is necessary to change set-ups while running, ensure par.0-12 [This Set-up Linked to](#) is programmed as required. For the majority of TR200 applications, it will not be necessary to program par. 0-12 [This Set-up Linked to](#) even if a set-up must be changed while running. For very complex applications which use the full flexibility of the multiple set-ups, it may be required. Using par.0-11 [Programming Set-up](#), it is possible to edit parameters in any of the set-ups during adjustable frequency drive operation in its active set-up; this set-up can be different than the one being edited. Using par.0-51 [Set-up Copy](#), it is possible to copy parameter settings between the set-ups to enable quicker commissioning if similar parameter settings are required in different set-ups.

0-10 Active Set-up

Option:	Function:
	Select the set-up in which the adjustable frequency drive is to operate. Use par.0-51 Set-up Copy to copy a set-up to one or all other set-ups. To avoid conflicting settings of the same parameter within two different set-ups, link the set-ups together using par.0-12 This Set-up Linked to . Stop the adjustable frequency drive before switching between set-ups, where parameters marked 'not changeable during operation' have different values. Parameters that are 'not changeable during operation' are marked FALSE in the parameter lists in the section Parameter Lists.
[0] Factory setup	Cannot be changed. It contains the Trane data set, and can be used as a data source when returning the other set-ups to a known state.
[1] * Set-up 1	<i>Set-up 1 [1] to Set-up 4 [4]</i> are the four separate parameter set-ups within which all parameters can be programmed.
[2] Set-up 2	
[3] Set-up 3	
[4] Set-up 4	
[9] Multi setup	Is used for remote selection of set-ups using digital inputs and the serial communication port. This set-up uses the settings from par.0-12 This Set-up Linked to .

0-11 Programming Set-up

Option:	Function:
	Select the set-up to be edited (i.e., programmed) during operation; either the active set-up or one of the inactive set-ups. The set-up number being edited is displayed in the keypad in (brackets).
[0] Factory setup	cannot be edited, but it is useful as a data source to return the other set-ups to a known state.
[1] Set-up 1	<i>Set-up 1 [1] to Set-up 4 [4]</i> can be edited freely during operation, independently of the active set-up.
[2] Set-up 2	
[3] Set-up 3	
[4] Set-up 4	
[9] * Active Set-up	(i.e., the set-up in which the adjustable frequency drive is operating) can also be edited during operation. Editing parameters in the chosen set-up would normally be done from the keypad but it is also possible from any of the serial communication ports.

0-12 This Set-up Linked to


Option:	Function:
	This parameter only needs to be programmed if changing set-ups is required while the motor is running. It ensures that parameters that are 'not changeable during operation' have the same setting in all relevant set-ups.

To enable conflict-free changes from one set-up to another while the adjustable frequency drive is running, link set-ups containing parameters that are not changeable during operation. The link will ensure the proper synchronization of the 'not changeable during operation' parameter values when moving from one set-up to another during operation. 'Not changeable during operation' parameters can be identified by the label FALSE in the parameter lists in the section *Parameter Lists*.

The par.0-12 [This Set-up Linked to](#) feature is used when Multi set-up in par.0-10 [Active Set-up](#) is selected. Multi set-up can be used to move from one set-up to another during operation (i.e., while the motor is running). Example:


Use Multi set-up to shift from Set-up 1 to Set-up 2 while the motor is running. Program parameters in Set-up 1 first, then ensure that Set-up 1 and Set-up 2 are synchronized (or 'linked'). Synchronization can be performed in two ways:

1. Change the edit set-up to *Set-up 2* [2] in par.0-11 [Programming Set-up](#) and set par.0-12 [This Set-up Linked to](#) to *Set-up 1* [1]. This will start the linking (synchronizing) process.



OR

2. While still in Set-up 1, using par.0-50 [LCP Copy](#), copy Set-up 1 to Set-up 2. Then set par.0-12 [This Set-up Linked to](#) to *Set-up 2* [2]. This will start the linking process.



After the link is complete, par.0-13 [Readout: Linked Set-ups](#) will read {1,2} to indicate that all 'not changeable during operation' parameters are now the same in Set-up 1 and Set-up 2. If there are changes to a 'not changeable during operation' parameter, e.g. par.1-30 [Stator Resistance \(Rs\)](#) in Set-up 2, they will also be changed automatically in Set-up 1. A switch between Set-up 1 and Set-up 2 during operation is now possible.

[0] * Not linked

- [1] Set-up 1
- [2] Set-up 2
- [3] Set-up 3
- [4] Set-up 4

0-13 Readout: Linked Set-ups

Array [5]

Range:

0 N/A* [0 - 255 N/A]

Function:

View a list of all the set-ups linked by means of par.0-12 [This Set-up Linked to](#). The parameter has one index for each parameter set-up. The parameter value displayed for each index represents which set-ups are linked to that parameter set-up.

Index	keypad value
0	{0}
1	{1,2}
2	{1,2}
3	{3}
4	{4}

Table 4. 2: Example: Set-up 1 and Set-up 2 are linked

0-14 Readout: Prog. Set-ups / Channel

Range:

0 N/A* [-2147483648 -
2147483647 N/A]

Function:

View the setting of par.0-11 [Programming Set-up](#) for each of the four different communication channels. When the number is displayed in hex, as it is in the keypad, each number represents one channel. Numbers 1-4 represent a set-up number; 'F' means factory setting; and 'A' means active set-up. The channels are, from right to left: keypad, Adjustable Frequency Drive bus, USB, HPFB1.5.
Example: The number AAAAAA21h means that the Adjustable Frequency Drive bus selected Set-up 2 in par.0-11 [Programming Set-up](#), the keypad selected Set-up 1 and all others used the active set-up.

0-2* keypad Display

Define the variables displayed in the Graphical Local Control Panel.

NOTE

Refer to par.0-37 [Display Text 1](#), par.0-38 [Display Text 2](#) and par.0-39 [Display Text 3](#) for information on how to write display texts.

0-20 Display Line 1.1 Small

Option:

Function:

Select a variable for display in line 1, left position.

[0] None

No display value selected

Parameter Description

[37]	Display Text 1	Enables an individual text string to be written, for display in the keypad or to be read via serial communication.
[38]	Display Text 2	Enables an individual text string to be written, for display in the keypad or to be read via serial communication.
[39]	Display Text 3	Enables an individual text string to be written, for display in the keypad or to be read via serial communication.
[89]	Date and Time Readout	Displays the current date and time.
[953]	Profibus Warning Word	Displays Profibus communication warnings.
[1005]	Readout Transmit Error Counter	View the number of CAN control transmission errors since the last power-up.
[1006]	Readout Receive Error Counter	View the number of CAN control receipt errors since the last power-up.
[1007]	Readout Bus Off Counter	View the number of Bus Off events since the last power-up.
[1013]	Warning Parameter	View a DeviceNet-specific warning word. One separate bit is assigned to every warning.
[1115]	LON Warning Word	Shows the LON-specific warnings.
[1117]	XIF Revision	Shows the version of the external interface file of the Neuron C chip on the LON option.
[1118]	LonWorks Revision	Shows the software version of the application program of the Neuron C chip on the LON option.
[1501]	Running Hours	View the number of running hours of the motor.
[1502]	kWh Counter	View the line power consumption in kWh.
[1600]	Control Word	View the control word sent from the adjustable frequency drive via the serial communication port in hex code.
[1601]	Reference [Unit]	Total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down) in selected unit.
[1602]	* Reference %	Total reference (sum of digital/analog/preset/bus/freeze ref./catch up and slow-down) in percent.
[1603]	Status Word	Present status word
[1605]	Main Actual Value [%]	View the two-byte word sent with the status word to the bus master reporting the main actual value.
[1609]	Custom Readout	View the user-defined readouts as defined in par.0-30 Custom Readout Unit , par.0-31 Custom Readout Min Value and par.0-32 Custom Readout Max Value .
[1610]	Power [kW]	Actual power consumed by the motor in kW.
[1611]	Power [hp]	Actual power consumed by the motor in HP.
[1612]	Motor voltage	Voltage supplied to the motor.
[1613]	Frequency	Motor frequency, i.e., the output frequency from the adjustable frequency drive in Hz.

[1614]	Motor Current	Phase current of the motor measured as effective value.
[1615]	Frequency [%]	Motor frequency, i.e., the output frequency from the adjustable frequency drive in percent.
[1616]	Torque [Nm]	Present motor load as a percentage of the rated motor torque.
[1617]	Speed [RPM]	Motor speed reference. Actual speed will depend on slip compensation being used (compensation set in par.1-62 Slip Compensation). If not used, actual speed will be the value read in the display minus motor slip.
[1618]	Motor Thermal	Thermal load on the motor, calculated by the ETR function. See also parameter group 1-9* Motor Temperature.
[1622]	Torque [%]	Shows the actual torque produced, in percentage.
[1626]	Power Filtered [kW]	
[1627]	Power Filtered [hp]	
[1630]	DC Link Voltage	Intermediate circuit voltage in the adjustable frequency drive.
[1632]	Brake Energy /s	Present braking energy transferred to an external brake resistor. Stated as an instantaneous value.
[1633]	Brake Energy /2 min	Braking energy transferred to an external brake resistor. The mean power is calculated continuously for the most recent 120 seconds.
[1634]	Heatsink Temp.	Present heatsink temperature of the adjustable frequency drive. The cut-out limit is 203° ± 41°F [95° ± 5°C]; cutting back in occurs at 158° ± 41°F [70° ± 5°C].
[1635]	Inverter Thermal	Percentage load of the inverters
[1636]	Inv. Nom. Current	Nominal current of the adjustable frequency drive.
[1637]	Inv. Max. Current	Maximum current of the adjustable frequency drive.
[1638]	SL Controller State	State of the event executed by the control
[1639]	Control Card Temp.	Temperature of the control card.
[1650]	External Reference	Sum of the external reference as a percentage, i.e., the sum of analog/pulse/bus.
[1652]	Feedback [Unit]	Reference value from programmed digital input(s).
[1653]	Digi Pot Reference	View the contribution of the digital potentiometer to the actual reference Feedback.
[1654]	Feedback 1 [Unit]	View the value of Feedback 1. See also par. 20-0*.
[1655]	Feedback 2 [Unit]	View the value of Feedback 2. See also par. 20-0*.
[1656]	Feedback 3 [Unit]	View the value of Feedback 3. See also par. 20-0*.
[1658]	PID Output [%]	Returns the Drive Closed-loop PID controller output value in percent.
[1660]	Digital Input	Displays the status of the digital inputs. Signal low = 0; Signal high = 1. Regarding order, see par.16-60 Digital Input . Bit 0 is at the extreme right.
[1661]	Terminal 53 Switch Setting	Setting of input terminal 53. Current = 0; Voltage = 1.

Parameter Description

[1662]	Analog Input 53	Actual value at input 53 either as a reference or protection value.
[1663]	Terminal 54 Switch Setting	Setting of input terminal 54. Current = 0; Voltage = 1.
[1664]	Analog Input 54	Actual value at input 54 either as reference or protection value.
[1665]	Analog Output 42 [mA]	Actual value at output 42 in mA. Use par.6-50 Terminal 42 Output to select the variable to be represented by output 42.
[1666]	Digital Output [bin]	Binary value of all digital outputs.
[1667]	Pulse Input #29 [Hz]	Actual value of the frequency applied at terminal 29 as a pulse input.
[1668]	Pulse Input #33 [Hz]	Actual value of the frequency applied at terminal 33 as a pulse input.
[1669]	Pulse Output #27 [Hz]	Actual value of pulses applied to terminal 27 in digital output mode.
[1670]	Pulse Output #29 [Hz]	Actual value of pulses applied to terminal 29 in digital output mode.
[1671]	Relay Output [bin]	View the setting of all relays.
[1672]	Counter A	View the present value of Counter A.
[1673]	Counter B	View the present value of Counter B.
[1675]	Analog In X30/11	Actual value of the signal on input X30/11 (General Purpose I/O Card. Option)
[1676]	Analog In X30/12	Actual value of the signal on input X30/12 (General Purpose I/O Card. Optional)
[1677]	Analog Out X30/8 [mA]	Actual value at output X30/8 (General Purpose I/O Card. Optional) Use Par. 6-60 to select the variable to be shown.
[1680]	Fieldbus CTW 1	Control word (CTW) received from the bus master.
[1682]	Fieldbus REF 1	Main reference value sent with control word via the serial communications network, e.g., from the BMS, PLC or other master controller.
[1684]	Comm. Option Status	Extended serial communication option status word.
[1685]	FC Port CTW 1	Control word (CTW) received from the bus master.
[1686]	FC Port REF 1	Status word (STW) sent to the bus master.
[1690]	Alarm Word	One or more alarms in a Hex code (used for serial communications)
[1691]	Alarm word 2	One or more alarms in a Hex code (used for serial communications)
[1692]	Warning Word	One or more warnings in a Hex code (used for serial communications)
[1693]	Warning word 2	One or more warnings in a Hex code (used for serial communications)
[1694]	Ext. Status Word	One or more status conditions in a Hex code (used for serial communications)
[1695]	Ext. Status Word 2	One or more status conditions in a Hex code (used for serial communications)
[1696]	Maintenance Word	The bits reflect the status for the programmed preventive maintenance events in parameter group 23-1*

[1830]	Analog Input X42/1	Shows the value of the signal applied to terminal X42/1 on the Analog I/O card.
[1831]	Analog Input X42/3	Shows the value of the signal applied to terminal X42/3 on the Analog I/O card.
[1832]	Analog Input X42/5	Shows the value of the signal applied to terminal X42/5 on the Analog I/O card.
[1833]	Analog Out X42/7 [V]	Shows the value of the signal applied to terminal X42/7 on the Analog I/O card.
[1834]	Analog Out X42/9 [V]	Shows the value of the signal applied to terminal X42/9 on the Analog I/O card.
[1835]	Analog Out X42/11 [V]	Shows the value of the signal applied to terminal X42/11 on the Analog I/O card.
[1850]	Sensorless Readout [unit]	
[2117]	Ext. 1 Reference [Unit]	The value of the reference for extended Closed-loop Controller 1
[2118]	Ext. 1 Feedback [Unit]	The value of the feedback signal for extended Closed-loop Controller 1
[2119]	Ext. 1 Output [%]	The value of the output from extended Closed-loop Controller 1
[2137]	Ext. 2 Reference [Unit]	The value of the reference for extended Closed-loop Controller 2
[2138]	Ext. 2 Feedback [Unit]	The value of the feedback signal for extended Closed-loop Controller 2
[2139]	Ext. 2 Output [%]	The value of the output from extended Closed-loop Controller 2
[2157]	Ext. 3 Reference [Unit]	The value of the reference for extended Closed-loop Controller 3
[2158]	Ext. 3 Feedback [Unit]	The value of the feedback signal for extended Closed-loop Controller 3
[2159]	Ext. 3 Output [%]	The value of the output from extended Closed-loop Controller 3
[2230]	No-Flow Power	The calculated No-Flow Power for the actual operating speed
[2316]	Maintenance Text	
[2580]	Cascade Status	Status for the operation of the cascade controller
[2581]	Pump Status	Status for the operation of each individual pump controlled by the cascade controller
[3110]	Bypass Status Word	
[3111]	Bypass Running Hours	
[9913]		
[9914]		
[9920]	HS Temp. (PC1)	
[9921]	HS Temp. (PC2)	
[9922]	HS Temp. (PC3)	
[9923]	HS Temp. (PC4)	
[9924]	HS Temp. (PC5)	
[9925]	HS Temp. (PC6)	
[9926]	HS Temp. (PC7)	
[9927]	HS Temp. (PC8)	



Parameter Description

0-21 Display Line 1.2 Small

Select a variable for display in line 1, middle position.

Option:

Function:

[1614] * Motor Current

The options are the same as those listed in par.0-20 [Display Line 1.1 Small](#).

0-22 Display Line 1.3 Small

Option:

Function:

Select a variable for display in line 1, right position.

The options are the same as those listed under 0-20.

0-23 Display Line 2 Large

Option:

Function:

Select a variable for display in line 2.

The options are the same as those listed under 0-20.

0-24 Display Line 3 Large

Select a variable for display in line 3.

Option:

Function:

[1502] * kWh Counter

The options are the same as listed for par.0-20 [Display Line 1.1 Small](#).

0-25 My Personal Menu

Array [20]

Range:

Function:

Applica- [0 - 9999 N/A]
tion de-
pend-
ent*

Define up to 20 parameters to appear in the Q1 Personal Menu, accessible via the [Quick Menu] key on the keypad. The parameters will be displayed in the Q1 Personal Menu in the order they are programmed into this array parameter. Delete parameters by setting the value to '0000'.


For example, this can be used to provide quick, simple access to just one or up to 20 parameters which require changing on a regular basis (e.g., for plant maintenance reasons) or by an OEM to enable simple commissioning of their equipment.

0-3*keypad Custom Readout

It is possible to customize the display elements for various purposes: *Custom Readout. Value proportional to speed (linear, squared or cubed depending on unit selected in par.0-30 [Custom Readout Unit](#)) *Display Text. Text string stored in a parameter.

Custom Readout

The calculated value to be displayed is based on settings in par.0-30 [Custom Readout Unit](#), par.0-31 [Custom Readout Min Value](#) (linear only), par.0-32 [Custom Readout Max Value](#), par.4-13 [Motor Speed High Limit \[RPM\]](#), par.4-14 [Motor Speed High Limit \[Hz\]](#) and actual speed.



The relation will depend on the type of unit selected in par.0-30 [Custom Readout Unit](#):

Unit Type	Speed Relation
Dimensionless	Linear
Speed	
Flow, volume	
Flow, mass	
Velocity	
Length	
Temperature	
Pressure	Quadratic
Power	Cubic

0-30 Custom Readout Unit

Option:

Function:

Program a value to be shown in the display of the keypad. The value has a linear, squared or cubed relation to speed. This relation depends on the unit selected (see table above). The actual calculated value can be read in par.16-09 [Custom Readout](#), and/or shown in the display by selecting Custom Readout [16-09] in par.0-20 [Display Line 1.1 Small](#) to par.0-24 [Display Line 3 Large](#).

[0]

[1] * %

[5] PPM

[10] min

[11] RPM

[12] PULSE/s

[20] liter / sec.

[21] liter / min

[22] liter / hr.

[23] m³ / sec.



Parameter Description

[24]	m ³ /min
[25]	m ³ / hr.
[30]	kg / sec.
[31]	kg/min
[32]	kg / hr.
[33]	ton / min
[34]	ton / hr.
[40]	m / sec.
[41]	m/min
[45]	m
[60]	°C
[70]	mbar
[71]	bar
[72]	Pa
[73]	kPa
[74]	m WG
[75]	mm Hg
[80]	kW
[120]	GPM
[121]	gal / sec.
[122]	gal/min
[123]	gal / hr.
[124]	CFM
[125]	ft ³ /s
[126]	ft ³ /min
[127]	ft ³ /h
[130]	lbs / sec.
[131]	lbs / min.
[132]	lbs / hr.
[140]	ft/s
[141]	ft/min
[145]	ft
[160]	°F
[170]	psi
[171]	lb/in ²
[172]	in. wtr. gage
[173]	ft WG
[174]	in Hg
[180]	HP

0-31 Custom Readout Min Value

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

0-32 Custom Readout Max Value

Range: Function:

100.00 [Application dependant]
Custom-
Readou-
tUnit*

This parameter sets the max value to be shown when the speed of the motor has reached the set value for par.4-13 [Motor Speed High Limit \[RPM\]](#) or par.4-14 [Motor Speed High Limit \[Hz\]](#) (depends on setting in par.0-02 [Motor Speed Unit](#)).

0-37 Display Text 1

Range: Function:

0 N/A* [0 - 0 N/A]

In this parameter, it is possible to write an individual text string for display in the keypad or to be read via serial communication. If it is to be displayed permanently, select Display Text 1 in par.0-20 [Display Line 1.1 Small](#), par.0-21 [Display Line 1.2 Small](#), par.0-22 [Display Line 1.3 Small](#), par.0-23 [Display Line 2 Large](#) or par.0-24 [Display Line 3 Large](#). Use the ▲ or ▼ buttons on the keypad to change a character. Use the ◀ and ▶ buttons to move the cursor. When a character is highlighted by the cursor, it can be changed. Use the ▲ or ▼ buttons on the keypad to change a character. A character can be inserted by placing the cursor between two characters and pressing ▲ or ▼.

0-38 Display Text 2

Range: Function:

0 N/A* [0 - 0 N/A]

In this parameter, it is possible to write an individual text string for display in the keypad or to be read via serial communication. If to be displayed permanently select Display Text 2 in par.0-20 [Display Line 1.1 Small](#), par.0-21 [Display Line 1.2 Small](#), par.0-22 [Display Line 1.3 Small](#), par.0-23 [Display Line 2 Large](#) or par.0-24 [Display Line 3 Large](#). Use the ▲ or ▼ buttons on the keypad to change a character. Use the ◀ and ▶ buttons to move the cursor. When a character is highlighted by the cursor, this character can be changed. A character can be inserted by placing the cursor between two characters and pressing ▲ or ▼.

0-39 Display Text 3

Range:

0 N/A* [0 - 0 N/A]

Function:

In this parameter, it is possible to write an individual text string for display in the keypad or to be read via serial communication. If it is to be displayed permanently, select Display Text 3 in par.0-20 [Display Line 1.1 Small](#), par.0-21 [Display Line 1.2 Small](#), par.0-22 [Display Line 1.3 Small](#), par.0-23 [Display Line 2 Large](#) or par.0-24 [Display Line 3 Large](#). Use the ▲ or ▼ buttons on the keypad to change a character. Use the ◀ and ▶ buttons to move the cursor. When a character is highlighted by the cursor, this character can be changed. A character can be inserted by placing the cursor between two characters and pressing ▲ or ▼.

keypad, 0-4*

Enable, disable and password-protect individual keys on the keypad.

0-40 [Hand on] Key on LCP

Option:

[0] Disabled

Function:

No function

[1] * Enabled

[Hand on] Key enabled

[2] Password

Avoid unauthorized start in hand mode. If par.0-40 [\[Hand on\] Key on LCP](#) is included in the My Personal Menu, then define the password in par.0-65 [Personal Menu Password](#). Otherwise, define the password in par.0-60 [Main Menu Password](#).

[3]

[4]

[5]

[6]

0-41 [Off] Key on LCP

Option:

[0] Disabled

Function:

No function

[1] * Enabled

[Off] Key is enabled

[2] Password

Avoid unauthorized stop. If par.0-41 [\[Off\] Key on LCP](#) is included in the My Personal Menu, then define the password in par.0-65 [Personal Menu Password](#). Otherwise, define the password in par.0-60 [Main Menu Password](#).

[3]

[4]

[5]

[6]

0-42 [Auto on] Key on LCP

Option:	Function:
[0] Disabled	No function
[1] * Enabled	[Auto on] Key is enabled
[2] Password	Avoid unauthorized start in auto mode. If par.0-42 [Auto on] Key on LCP is included in the My Personal Menu, then define the password in par.0-65 Personal Menu Password . Otherwise, define the password in par.0-60 Main Menu Password .
[3]	
[4]	
[5]	
[6]	

0-43 [Reset] Key on LCP

Option:	Function:
[0] Disabled	No function
[1] * Enabled	[Reset] Key is enabled
[2] Password	Avoid unauthorized resetting. If par.0-43 [Reset] Key on LCP is included in the par.0-25 My Personal Menu , then define the password in par. 0-65 Personal Menu Password . Otherwise, define the password in par. 0-60 Main Menu Password .
[3]	
[4]	
[5]	
[6]	

0-44 [Off/Reset] Key on LCP

Option:	Function:
	Press [Off] and select Disabled [0] to avoid accidental stop of the drive. Press [Off] and select Password [2] to avoid unauthorized stop and reset of the drive. If par.0-44 [Off/Reset] Key on LCP is included in the quick menu, define the password in par.0-65 Personal Menu Password .
[0] Disabled	No function
[1] * Enabled	[Off/Reset] Key is enabled
[2] Password	
[3]	
[4]	
[5]	
[6]	

0-45 [Drive Bypass] Key on LCP

Option:		Function:
		Press [Off] and select Disabled [0] to avoid accidental stop of the drive. Press [Off] and select Password [2] to avoid unauthorized stop and reset of the drive. If par.0-45 [Drive Bypass] Key on LCP is included in the quick menu, define the password in par.0-65 Personal Menu Password .
[0]	Disabled	No function
[1] *	Enabled	[Off/Reset] Key is enabled
[2]	Password	
[3]		
[4]		
[5]		
[6]		

0-5* Copy / Save

Copy parameter settings between set-ups and to/from the keypad.

0-50 LCP Copy

Option:		Function:
[0] *	No copy	No function
[1]	All to LCP	Copies all parameters in all set-ups from the adjustable frequency drive memory to the keypad memory. For service purposes, it is recommended to copy all parameters to the keypad after commissioning.
[2]	All from LCP	Copies all parameters in all set-ups from the keypad memory to the adjustable frequency drive memory.
[3]	Size indep. of LCP	Copies only the parameters that are independent of the motor size. The latter selection can be used to program several adjustable frequency drives with the same function without disturbing motor data which are already set.

This parameter cannot be adjusted while the motor is running.

0-51 Set-up Copy

Option:	Function:
[0] * No copy	No function
[1] Copy to set-up 1	Copies all parameters in the present Programming Set-up (defined in par.0-11 Programming Set-up) to Set-up 1.
[2] Copy to set-up 2	Copies all parameters in the present Programming Set-up (defined in par.0-11 Programming Set-up) to Set-up 2.
[3] Copy to set-up 3	Copies all parameters in the present Programming Set-up (defined in par.0-11 Programming Set-up) to Set-up 3.
[4] Copy to set-up 4	Copies all parameters in the present Programming Set-up (defined in par.0-11 Programming Set-up) to Set-up 4.
[9] Copy to all	Copies the parameters in the present set-up over to each of the set-ups 1 to 4.

0-6* Password

Define password access to menus.

0-60 Main Menu Password

Range:	Function:
100 N/ [0 - 999 N/A] A*	Define the password for access to the main menu via the [Main Menu] key. If par.0-61 Access to Main Menu w/o Password is set to <i>Full access</i> [0], this parameter will be ignored.

0-61 Access to Main Menu w/o Password

Option:	Function:
[0] * Full access	Disables password defined in par.0-60 Main Menu Password .
[1] Read-only	Prevent unauthorized editing of main menu parameters.
[2] No access	Prevent unauthorized viewing and editing of main menu parameters.

If *Full access* [0] is selected then par.0-60 [Main Menu Password](#), par.0-65 [Personal Menu Password](#) and par.0-66 [Access to Personal Menu w/o Password](#) will be ignored.

0-65 Personal Menu Password

Range:	Function:
200 N/ [0 - 999 N/A] A*	Define the password for access to the My Personal Menu via the [Quick Menu] key. If par.0-66 Access to Personal Menu w/o Password is set to <i>Full access</i> [0], this parameter will be ignored.

0-66 Access to Personal Menu w/o Password

Option:	Function:
[0] * Full access	Disables password defined in par.0-65 Personal Menu Password .
[1] Read-only	Prevents unauthorized editing of My Personal Menu parameters.
[2] No access	Prevents unauthorized viewing and editing of My Personal Menu parameters.



Clock Settings, 0-7*

It is possible to program the clock for Daylight Saving Time/summertime, weekly working days/non-working days including 20 exceptions (holidays, etc.). Although the clock settings can be set via the keypad, they can also be set along with timed actions and preventative maintenance functions using the MCT10 software tool.

The adjustable frequency drive has no backup of the clock function and the set date/time will reset to default (2000-01-01 00:00) after a power-down unless a Real Time Clock module with backup is installed. If no module with backup is installed, it is recommended the clock function is only used if the adjustable frequency drive is integrated into the BMS using serial communications, with the BMS maintaining synchronization of control equipment clock times. In par. 0-79 [Clock Fault](#), it is possible to program for a warning in case the clock has not been set properly, e.g., after a power-down.

If mounting an Analog I/O MCB 109 option card, a battery backup of the date and time is included.

Applica- [Application dependant]
tion de-
pend-
ent*

Sets the date format to be used in the keypad.

[2] MM/DD/YYYY

Sets the time format to be used in the keypad.

[1] 12 h

Choose how Daylight Saving Time/Summertime should be handled. For manual DST/Summertime enter the start date and end date in par. 0-76 **DST/Summertime Start** and par.0-77 **DST/Summertime End**.

[2] Manual

0-76 DST/Summertime Start

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

0-77 DST/Summertime End

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

0-79 Clock Fault

Option: Function:

Enables or disables the clock warning when the clock has not been set, or has been reset due to a power-down and no backup is installed.

[0] * Disabled

[1] Enabled

0-81 Working Days

Array with 7 elements [0] - [6] displayed below parameter number in display. Press OK and step between elements by means of ▲ and ▼ buttons on the keypad.

Option: Function:

Specify whether each weekday is a workday or a non-workday. First element of the array is Monday. The workdays are used for timed actions.

[0] * No

[1] Yes

0-82 Additional Working Days

Array with 5 elements [0] - [4] displayed below parameter number in display. Press OK and step between elements by means of ▲ and ▼ buttons on the keypad.

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

0-83 Additional Non-Working Days

Array with 15 elements [0] - [14] displayed below parameter number in display. Press OK and step between elements by means of ▲ and ▼ buttons on the keypad.

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

0-89 Date and Time Readout

Range:	Function:
0 N/A* [0 - 0 N/A]	Displays the current date and time. The date and time is updated continuously. The clock will not begin counting until a setting different from default has been made in par.0-70 Date and Time .

Main Menu - Load and Motor - Group 1

General Settings, 1-0*

Define whether the adjustable frequency drive operates in open-loop or closed-loop.

1-00 Configuration Mode

Option:	Function:
[0] * Open-loop	Motor speed is determined by applying a speed reference or by setting desired speed when in Hand Mode. Open-loop is also used if the adjustable frequency drive is part of a closed-loop control system based on an external PID controller providing a speed reference signal as output.
[3] Closed-loop	Motor speed will be determined by a reference from the built-in PID controller varying the motor speed as part of a closed-loop control process (e.g., constant pressure or flow). The PID controller must be configured in par. 20-** or via the function set-ups accessed by pressing the [Quick Menu] button.

NOTE: This parameter cannot be changed when motor is running.

NOTE: When set for Closed-loop, the commands Reversing and Start Reversing will not reverse the direction of the motor.

1-03 Torque Characteristics

Option:	Function:
[0] * Compressor torque	<i>Compressor</i> [0]: For speed control of screw and scroll compressors. Provides a voltage which is optimized for a constant torque load characteristic of the motor in the entire range down to 10 Hz.
[1] Variable torque	<i>Variable Torque</i> [1]: For speed control of centrifugal pumps and fans. Also to be used when controlling more than one motor from the same adjustable frequency drive (e.g., multiple condenser fans or cooling tower fans). Provides a voltage which is optimized for a squared torque load characteristic of the motor.
[2] Auto Energy Optim. CT	<i>Auto Energy Optimization Compressor</i> [2]: For optimum energy-efficient speed control of screw and scroll compressors. Provides a voltage that is optimized for a constant torque load characteristic of the motor in the entire range down to 15 Hz. In addition, the AEO feature will adapt the voltage exactly to the current load situation, thereby reducing energy consumption and audible noise from the motor. To obtain optimal performance, the motor power factor cos phi must be set correctly. This value is set in par.14-43 Motor Cos-Phi . The parameter has a default value which is automatically adjusted when the motor data is programmed.

[3] * Auto Energy Optim. VT	<i>Auto Energy Optimization VT</i>[3]: For optimum energy efficient speed control of centrifugal pumps and fans. Provides a voltage which is optimized for a squared torque load characteristic of the motor but in addition the AEO feature will adapt the voltage exactly to the current load situation, thereby reducing energy consumption and audible noise from the motor. To obtain optimal performance, the motor power factor cos phi must be set correctly. This value is set in par.14-43 Motor Cos-Phi. The parameter has a default value and is automatically adjusted when the motor data is programmed. These settings will typically ensure optimum motor voltage but if the motor power factor cos phi requires tuning, an AMA function can be carried out using par.1-29 Automatic Motor Adaptation (AMA). It is very rarely necessary to adjust the motor power factor parameter manually.
---	--

Parameter group 1-2* comprises input data from the nameplate on the connected motor. Parameters in parameter group 1-2* cannot be adjusted while the motor is running.

Changing the value of these parameters affects the setting of other parameters.

Applica- [Application dependant]
tion de-
pend-
ent*

Applica- [Application dependant]
tion de-
pend-
ent*

Applica- [Application dependant]
tion de-
pend-
ent*

1-23 Motor Frequency

Range:	Function:
Applica- [20 - 1000 Hz] tion de- pend- ent*	Select the motor frequency value from the motor nameplate data. For 87 Hz operation with 230/400 V motors, set the nameplate data for 230 V/50 Hz. Adapt par.4-13 Motor Speed High Limit [RPM] and par.3-03 Maximum Reference to the 87 Hz application.

NOTE: This parameter cannot be adjusted while the motor is running.

1-24 Motor Current

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	

NOTE

This parameter cannot be adjusted while the motor is running.

1-25 Motor Nominal Speed

Range:	Function:
Applica- [100 - 60000 RPM] tion de- pend- ent*	Enter the nominal motor speed value from the motor nameplate data. This data is used for calculating automatic motor compensations.

NOTE

This parameter cannot be changed while the motor is running.

1-28 Motor Rotation Check

Option:	Function:
	Following installation and connection of the motor, this function allows the correct motor rotation direction to be verified. Enabling this function overrides any bus commands or digital inputs, except External Interlock and Safe Stop (if included).
[0] * OFF	Motor Rotation Check is not active.
[1] Enabled	Motor Rotation Check is enabled. Once enabled, display shows: "Please Note! Motor may run in wrong direction".

Pressing [OK], [Back] or [Cancel] will dismiss the message and display a new message: "Press [Hand on] to start the motor. Press [Cancel] to abort". Pressing [Hand on] starts the motor at 5 Hz in forward direction and the display shows: "Motor is running. Check if motor rotation direction is correct. Press [Off] to stop the motor". Pressing [Off] stops the motor and resets par.1-28 [Motor Rotation Check](#). If motor rotation direction is incorrect, two motor phase cables should be interchanged. IMPORTANT:

CAUTION

Line power must be removed before disconnecting motor phase cables.

1-29 Automatic Motor Adaptation (AMA)

Option:		Function:
		The AMA function optimizes dynamic motor performance by automatically optimizing the advanced motor parameters par.1-30 Stator Resistance (Rs) to par.1-35 Main Reactance (Xh) while the motor is stationary.
[0] *	Off	No function
[1]	Enable complete AMA	performs AMA of the stator resistance R_S , the rotor resistance R_r , the stator leakage reactance X_1 , the rotor leakage reactance X_2 and the main reactance X_H .
[2]	Enable reduced AMA	performs a reduced AMA of the stator resistance R_S in the system only. Select this option if an LC filter is used between the adjustable frequency drive and the motor.

Activate the AMA function by pressing [Hand on] after selecting [1] or [2]. See also the section *Automatic Motor Adaptation*. After a normal sequence, the display will read: "Press [OK] to finish AMA". After pressing the [OK] key, the adjustable frequency drive is ready for operation.

Note:

- For the best adaptation of the adjustable frequency drive, run AMA on a cold motor
- AMA cannot be performed while the motor is running.

NOTE

It is important to set motor par. 1-2* Motor Data correctly, since these form part of the AMA algorithm. An AMA must be performed to achieve optimum dynamic motor performance. It may take up to 10 min., depending on the motor power rating.

NOTE

Avoid generating external torque during AMA

NOTE

If one of the settings in par. 1-2* Motor Data is changed, par.1-30 [Stator Resistance \(Rs\)](#) to par.1-39 [Motor Poles](#), the advanced motor parameters, will return to the default setting. This parameter cannot be adjusted while the motor is running.

NOTE

Full AMA should be run without filter only while reduced AMA should be run with filter.

See section: *Application Examples > Automatic Motor Adaptation* in the Design Guide.


1-3* Adv. Motor Data

Parameters for advanced motor data. The motor data in par.1-30 [Stator Resistance \(Rs\)](#) to par.1-39 [Motor Poles](#) must match the relevant motor in order to run the motor optimally. The default settings are figures based on common motor parameter values from normal standard motors. If the motor parameters are not set correctly, a malfunction of the adjustable frequency drive system may occur. If the motor data is not known, running an

Parameter Description

AMA (Automatic Motor Adaptation) is recommended. See the *Automatic Motor Adaptation* section. The AMA sequence will adjust all motor parameters except the moment of inertia of the rotor and the iron loss resistance (par.1-36 [Iron Loss Resistance \(Rfe\)](#)).

Par. 1-3* and par. 1-4* cannot be adjusted while the motor is running.



130BA375.10

Figure 4. 1: **Motor equivalent diagram for an asynchronous motor**

1-30 Stator Resistance (Rs)

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

1-35 Main Reactance (Xh)

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE

This parameter cannot be adjusted while running.

1-36 Iron Loss Resistance (Rfe)

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE

This parameter cannot be adjusted while the motor is running.

1-39 Motor Poles

Range:

Applica- [2 - 100 N/A]
tion de-
pend-
ent*

Function:

Enter the number of motor poles.

Poles	$\sim n_n$ @ 50 Hz	$\sim n_n$ @ 60 Hz
2	2700 - 2880	3250 - 3460
4	1350 - 1450	1625 - 1730
6	700 - 960	840 - 1153

The table shows the number of poles for normal speed ranges of various motor types. Define motors designed for other frequencies separately. The motor pole value is always an even number, because it refers to the total number of poles, not pairs of poles. The adjustable frequency drive creates the initial setting of par.1-39 [Motor Poles](#) based on par.1-23 [Motor Frequency](#) and par.1-25 [Motor Nominal Speed](#).

This parameter cannot be adjusted while the motor is running.

1-5* Load Indep. Setting

Parameters for setting the load-independent motor settings.

1-50 Motor Magnetization at Zero Speed


Range:

100 %* [0 - 300 %]

Function:

Use this parameter along with par.1-51 [Min Speed Normal Magnetizing \[RPM\]](#) to obtain a different thermal load on the motor when running at low speed.

Enter a value which is a percentage of the rated magnetizing current. If the setting is too low, the torque on the motor shaft may be reduced.



1-51 Min Speed Normal Magnetizing [RPM]

Range:

Applica- [10 - 300 RPM]
tion de-
pend-
ent*

Function:

Set the required speed for normal magnetizing current. If the speed is set lower than the motor slip speed, par.1-50 [Motor Magnetization at Zero Speed](#) and par.1-51 [Min Speed Normal Magnetizing \[RPM\]](#) are of no significance.

Use this parameter along with par.1-50 [Motor Magnetization at Zero Speed](#). See drawing for par.1-50 [Motor Magnetization at Zero Speed](#).

1-52 Min Speed Normal Magnetizing [Hz]

Range:

Function:

Applica-
tion de-
pend-
ent*

1-6* Load Depend. Setting

Parameters for adjusting the load-dependent motor settings.

1-60 Low Speed Load Compensation


Range:

100 %* [0 - 300 %]

Function:

Enter the % value to compensate voltage in relation to load while the motor is running at low speed, and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Change-over
0.3–10 hp [0.25–7.5 kW]	< 10 Hz
15–60 hp [11–45 kW]	< 5 Hz
75–750 hp [55 kW–550 kW]	< 3–4 Hz



1-61 High Speed Load Compensation

Range:

100 %* [0 - 300 %]

Function:

Enter the % value to compensate voltage in relation to load while the motor is running at high speed, and obtain the optimum U/f characteristic. The motor size determines the frequency range within which this parameter is active.

Motor size	Change-over
0.3–10 hp [0.25–7.5 kW]	> 10 Hz
15–60 hp [11–45 kW]	< 5 Hz
75–750 hp [55 kW–550 kW]	< 3–4 Hz

1-62 Slip Compensation

Range:	Function:
0 %* [-500 - 500 %]	Enter the % value for slip compensation to compensate for tolerances in the value of $n_{M,N}$. Slip compensation is calculated automatically, i.e., on the basis of the rated motor speed $n_{M,N}$.

1-63 Slip Compensation Time Constant

Range:	Function:
Applica- [0.05 - 5.00 s] tion de- pend- ent*	Enter the slip compensation reaction speed. A high value results in slow reaction, and a low value results in quick reaction. If low-frequency resonance problems arise, use a longer time setting.

1-64 Resonance Dampening

Range:	Function:
100 %* [0 - 500 %]	Enter the resonance dampening value. Set par.1-64 Resonance Dampening and par.1-65 Resonance Dampening Time Constant to help eliminate high-frequency resonance problems. To reduce resonance oscillation, increase the value of par.1-64 Resonance Dampening .

1-65 Resonance Dampening Time Constant

Range:	Function:
5 ms* [5 - 50 ms]	Set par.1-64 Resonance Dampening and par.1-65 Resonance Dampening Time Constant to help eliminate high-frequency resonance problems. Enter the time constant that provides the best dampening.

1-7* Start Adjustments

Parameters for setting special motor start features.

1-71 Start Delay

Range:	Function:
0.0 s* [0.0 - 120.0 s]	The function selected in par.1-80 Function at Stop is active in the delay period. Enter the time delay required before commencing acceleration.

1-73 Flying Start

Option:	Function:
	This function makes it possible to catch a motor that is spinning freely due to a line drop-out. When par.1-73 Flying Start is enabled, par.1-71 Start Delay has no function. Search direction for flying start is linked to the setting in par.4-10 Motor Speed Direction. <i>Clockwise</i> [0]: Flying start search in clockwise direction. If not successful, a DC brake is carried out. <i>Both Directions</i> [2]: The flying start will first make a search in the direction determined by the last reference (direction). If unable to find the speed, it will search in the other direction. If not successful, a DC brake will be

		activated in the time set in par.2-02 DC Braking Time . Start will then take place from 0 Hz.
[0] *	Disabled	Select <i>Disable</i> [0] if this function is not required
[1]	Enabled	Select <i>Enable</i> [1] to enable the adjustable frequency drive to “catch” and control a spinning motor.

1-8* Stop Adjustments

Parameters for setting special stop features for the motor.

1-80 Function at Stop

Option:	Function:
	Select the adjustable frequency drive function after a stop command or after the speed is ramped down to the settings in par.1-81 Min Speed for Function at Stop [RPM] .
[0] * Coast	Leaves motor in free mode.
[1] DC Hold/Motor Preheat	Energizes motor with a DC holding current (see par.2-00 DC Hold/Preheat Current).

1-81 Min Speed for Function at Stop [RPM]

Range:	Function:
Applica- [0 - 600 RPM] tion de- pend- ent*	Set the speed at which to activate par.1-80 Function at Stop .

1-82 Min Speed for Function at Stop [Hz]

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	

Trip at Motor Speed Low Limit

In par.4-11 [Motor Speed Low Limit \[RPM\]](#) and par.4-12 [Motor Speed Low Limit \[Hz\]](#), it is possible to set a minimum speed for the motor in order to ensure proper oil distribution.

In some cases, e.g., if operating in current limit because of a defect in the compressor, the output motor speed can be suppressed below Motor Speed Low Limit. To prevent damage to the compressor, it is possible to set trip limit. If the motor speed drops below this limit, the adjustable frequency drive will trip and issue an alarm (A49).

Reset will take place according to the selected function in par.14-20 [Reset Mode](#).

If the trip must take place at a rather exact speed (RPM), it is recommended to set par.0-02 [Motor Speed Unit](#) for RPM and use slip compensation, which can be set in par.1-62 [Slip Compensation](#).

NOTE

To achieve the highest accuracy with the slip compensation, an Automatic Motor Adaptation (AMA) should be performed. To be enabled in par.1-29 [Automatic Motor Adaptation \(AMA\)](#).

NOTE

Trip will not be active when using a normal stop or coast command.

1-86 Trip Speed Low [RPM]

Range:	Function:
0 RPM* [Application dependant]	If the trip speed is set to 0, the function is not active. If the speed after the start (or during a stop) falls below the value in the parameter at any time, the drive will trip with an alarm [A49] Speed Limit. Function at stop.

NOTE: This parameter is only available if par.0-02 [Motor Speed Unit](#) is set to [RPM].

1-87 Trip Speed Low [Hz]

Range:	Function:
0.0 Hz* [Application dependant]	If the trip speed is set to 0, the function is not active. If the speed after the start (or during a stop) falls below the value in the parameter at any time, the drive will trip with an alarm [A49] Speed Limit. Function at stop.

NOTE: This parameter is only available if par.0-02 [Motor Speed Unit](#) is set to [Hz].

1-9* Motor Temperature


Parameters for setting the temperature protection features for the motor.

1-90 Motor Thermal Protection

Option:	Function:
	The adjustable frequency drive determines the motor temperature for motor protection in two different ways: - Via a thermistor sensor connected to one of the analog or digital inputs (par.1-93 Thermistor Source). - Via calculation (ETR = Electronic Thermal Relay) of the thermal load, based on the actual load and time. The calculated thermal load is compared with the rated motor current $I_{M,N}$ and the rated motor frequency $f_{M,N}$. The calculations estimate the need for a lower load at lower speed due to less cooling from the fan incorporated in the motor.
[0] No protection	If the motor is continuously overloaded and no warning or trip of adjustable frequency drive is wanted.
[1] Thermistor warning	Activates a warning when the connected thermistor in the motor reacts in the event of motor overtemperature.
[2] Thermistor trip	Stops (trips) the adjustable frequency drive when the connected thermistor in the motor reacts in the event of motor overtemperature.

[3]	ETR warning 1
[4] *	ETR trip 1
[5]	ETR warning 2
[6]	ETR trip 2
[7]	ETR warning 3
[8]	ETR trip 3
[9]	ETR warning 4
[10]	ETR trip 4


ETR (Electronic Thermal Relay) functions 1-4 will calculate the load when the set-up where they were selected is active. For example, ETR-3 starts calculating when Set-up 3 is selected. For the North American market: The ETR functions provide class 20 motor overload protection in accordance with NEC.



NOTE: Trane recommends using 24 VDC as thermistor supply voltage.

1-91 Motor External Fan

Option:	Function:
[0] * No	No external fan is required, i.e. the motor is derated at low speed.
[1] Yes	Applies an external motor fan (external ventilation), so that no derating of the motor is required at low speed. The graph below is followed if the motor current is lower than nominal motor current (see par.1-24 Motor Current). If the motor current exceeds nominal current, the operation time still decreases as if no fan were installed.



1-93 Thermistor Source

Option:

Function:

Select the input to which the thermistor (PTC sensor) should be connected. An analog input option [1] or [2] cannot be selected if the analog input is already in use as a reference source (selected in par.3-15 [Reference 1 Source](#), par.3-16 [Reference 2 Source](#) or par.3-17 [Reference 3 Source](#)).

When using MCB112, choice [0] *None* must always be selected.

- [0] * None
- [1] Analog input 53
- [2] Analog input 54
- [3] Digital input 18
- [4] Digital input 19
- [5] Digital input 32
- [6] Digital input 33

NOTE: This parameter cannot be adjusted while the motor is running.

Main Menu - Brakes - Group 2

2-0* DC Brakes

Parameter group for configuring the DC brake and DC hold functions.

2-00 DC Hold/Preheat Current

Range:	Function:
50 %* [Application dependant]	Enter a value for holding current as a percentage of the rated motor current $I_{M,N}$ set in par.1-24 Motor Current . 100% DC holding current corresponds to $I_{M,N}$. This parameter holds the motor (holding torque) or pre-heats the motor. This parameter is active if [1] DC hold/Preheat is selected in par. 1-80 Function at Stop .

NOTE

The maximum value depends on the rated motor current.

Avoid 100% current for too long. It may damage the motor.

2-01 DC Brake Current

Range:	Function:
50 %* [Application dependant]	Enter a value for current as a percentage of the rated motor current $I_{M,N}$, see par.1-24 Motor Current . 100% DC braking current corresponds to $I_{M,N}$. DC brake current is applied on a stop command, when the speed is lower than the limit set in par.2-03 DC Brake Cut-in Speed [RPM] ; when the DC Brake Inverse function is active; or via the serial communication port. The braking current is active during the time period set in par.2-02 DC Braking Time .

NOTE

The maximum value depends on the rated motor current.

Avoid 100% current for too long, as it may damage the motor. It may damage the motor.

2-02 DC Braking Time

Range:	Function:
10.0 s* [0.0 - 60.0 s]	Set the duration of the DC braking current set in par.2-01 DC Brake Current , once activated.

2-03 DC Brake Cut-in Speed [RPM]

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	

2-04 DC Brake Cut-in Speed [Hz]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

2-1 * Brake Energy Funct.

Parameter group for selecting dynamic braking parameters. Only valid for drives with brake chopper.

2-10 Brake Function

Option: Function:

[0] * Off No brake resistor installed.

[1] Resistor brake Brake resistor incorporated in the system, for dissipation of surplus braking energy as heat. Connecting a brake resistor allows a higher DC link voltage during braking (generating operation). The resistor brake function is only active in adjustable frequency drives with an integral dynamic brake.

[2] AC brake AC Brake will only work in Compressor Torque mode in par.1-03 [Torque Characteristics](#).

2-11 Brake Resistor (ohm)

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

2-12 Brake Power Limit (kW)

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

For 200–240 V units:

$$P_{resistor} = \frac{390^2 \times dutytime}{R \times 120}$$

For 380–480 V units

$$P_{resistor} = \frac{778^2 \times dutytime}{R \times 120}$$

For 380–500 V units

$$P_{resistor} = \frac{810^2 \times dutytime}{R \times 120}$$

For 575–600 V units

$$P_{resistor} = \frac{943^2 \times dutytime}{R \times 120}$$

This parameter is only active in adjustable frequency drives with an integral dynamic brake.

2-13 Brake Power Monitoring

Option:	Function:
	This parameter is only active in adjustable frequency drives with an integral dynamic brake. This parameter enables monitoring of the power to the brake resistor. The power is calculated on the basis of the resistance (par.2-11 Brake Resistor (ohm)), the DC-link voltage, and the resistor duty time.
[0] * Off	No braking energy monitoring is required.
[1] Warning	Activates a warning on the display when the power transmitted over 120 s exceeds 100% of the monitoring limit (par.2-12 Brake Power Limit (kW)). The warning disappears when the transmitted power falls below 80% of the monitoring limit.
[2] Trip	Trips the adjustable frequency drive and displays an alarm when the calculated power exceeds 100% of the monitoring limit.
[3] Warning and trip	Activates both of the above, including warning, trip and alarm.

If power monitoring is set to *Off*[0] or *Warning*[1], the brake function remains active even if the monitoring limit is exceeded. This may lead to thermal overload of the resistor. It is also possible to generate a warning via a relay/digital output. The measuring accuracy of the power monitoring depends on the accuracy of the resistance of the resistor (better than $\pm 20\%$).

2-15 Brake Check

Option:	Function:
	Select type of test and monitoring function to check the connection to the brake resistor, or whether a brake resistor is present, and then display a warning or an alarm in the event of a fault. The brake resistor disconnection function is tested during power-up. However, the brake IGBT test is performed when there is no braking. A warning or trip disconnects the brake function. The testing sequence is as follows: 1. The DC link ripple amplitude is measured for 300 ms without braking. 2. The DC link ripple amplitude is measured for 300 ms with the brake turned on. 3. If the DC link ripple amplitude while braking is lower than the DC link ripple amplitude before braking + 1%. Brake check failed, return a warning or alarm. 4. If the DC link ripple amplitude while braking is higher than the DC link ripple amplitude before braking + 1%. Brake check OK.
[0] * Off	Monitors brake resistor and brake IGBT for a short-circuit during operation. If a short-circuit occurs, a warning appears.
[1] Warning	Monitors brake resistor and brake IGBT for a short-circuit, and to run a test for brake resistor disconnection during power-up.
[2] Trip	Monitors for a short-circuit or disconnection of the brake resistor, or a short-circuit of the brake IGBT. If a fault occurs, the adjustable frequency drive cuts out while displaying an alarm (trip locked).

NOTE

2-16 AC Brake Max. Current

2-17 Over-voltage Control

NOTE: The ramp time is automatically adjusted to avoid tripping of the adjustable frequency drive.

Main Menu - Reference/Ramps - Group 3

3-0* Reference Limits

Parameters for setting the reference unit, limits and ranges.

Please also see par. 20-0* for information on settings in closed-loop.

3-02 Minimum Reference

3-03 Maximum Reference

Range:	Function:
Application dependent*	

3-04 Reference Function

Option:	Function:
[0] * Sum	Sums both external and preset reference sources.
[1] External/Preset	Use either the preset or the external reference source.

Shift between external and preset via a command on a digital input.

3-1* References

Parameters for setting up the reference sources.



Select the preset reference(s). *Select Preset ref. bit 0 / 1 / 2* [16], [17] or [18] for the corresponding digital inputs in par. group 5-1*.

3-10 Preset Reference

Array [8]

Range: Function:

0.00 %* [-100.00 - 100.00 %]



3-11 Jog Speed [Hz]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

3-13 Reference Site


Option:	Function:
	Select which reference site to activate.
[0] * Linked to Hand / Auto	Use local reference when in hand mode; or remote reference when in auto mode.
[1] Remote	Use remote reference in both hand mode and auto mode.
[2] Local	Use local reference in both hand mode and auto mode.

NOTE

When set to Local [2], the adjustable frequency drive will start with this setting again following a 'power-down'.

3-14 Preset Relative Reference

Range:	Function:
0.00 %* [-100.00 - 100.00 %]	



3-15 Reference 1 Source

Option:	Function:
	Select the reference input to be used for the first reference signal. par. 3-15 Reference 1 Source , par.3-16 Reference 2 Source and par.3-17 Reference 3 Source define up to three different reference signals. The sum of these reference signals defines the actual reference.
	This parameter cannot be adjusted while the motor is running.
[0] No function	
[1] * Analog input 53	
[2] Analog input 54	
[7] Pulse input 29	
[8] Pulse input 33	
[20] Digital pot.meter	
[21] Analog input X30/11	

Parameter Description

[22]	Analog input X30/12
[23]	Analog Input X42/1
[24]	Analog Input X42/3
[25]	Analog Input X42/5
[30]	Ext. Closed-loop 1
[31]	Ext. Closed-loop 2
[32]	Ext. Closed-loop 3

3-16 Reference 2 Source

Option:

Function:

Select the reference input to be used for the second reference signal. par.3-15 [Reference 1 Source](#), par.3-16 [Reference 2 Source](#) and par. 3-17 [Reference 3 Source](#) define up to three different reference signals. The sum of these reference signals defines the actual reference.
This parameter cannot be adjusted while the motor is running.

[0]	No function
[1]	Analog input 53
[2]	Analog input 54
[7]	Pulse input 29
[8]	Pulse input 33
[20] *	Digital pot.meter
[21]	Analog input X30/11
[22]	Analog input X30/12
[23]	Analog Input X42/1
[24]	Analog Input X42/3
[25]	Analog Input X42/5
[30]	Ext. Closed-loop 1
[31]	Ext. Closed-loop 2
[32]	Ext. Closed-loop 3

3-17 Reference 3 Source

Option:

Function:

Select the reference input to be used for the third reference signal. par. 3-15 [Reference 1 Source](#), par.3-16 [Reference 2 Source](#) and par.3-17 [Reference 3 Source](#) define up to three different reference signals. The sum of these reference signals defines the actual reference.

This parameter cannot be adjusted while the motor is running.

[0] * No function

[1] Analog input 53

[2] Analog input 54

[7] Pulse input 29

[8] Pulse input 33

[20] Digital pot.meter

[21] Analog input X30/11

[22] Analog input X30/12

[23] Analog Input X42/1

[24] Analog Input X42/3

[25] Analog Input X42/5

[30] Ext. Closed-loop 1

[31] Ext. Closed-loop 2

[32] Ext. Closed-loop 3

3-19 Jog Speed [RPM]


Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

3-4* Ramp 1

Configure the ramp parameter, ramping times, for each of the two ramps (par. 3-4* and par. 3-5*).



3-40 Ramp 1 Type

Option:	Function:
	Select the ramp type, depending on requirements for acceleration/deceleration. A linear ramp will give constant acceleration during ramping. An S-ramp will give non-linear acceleration, compensating for jerk in the application.
[0] * Linear	
[1] S-ramp	Acceleration with lowest possible jerk.
[2] S-ramp Const Time	S-ramp based on the values set in par.3-41 Ramp 1 Ramp-up Time and par.3-42 Ramp 1 Ramp-down Time .

NOTE

If S-ramp [1] is selected and the reference during ramping is changed, the ramp time may be prolonged in order to realize a jerk-free movement, which may result in a longer start or stop time. Additional adjustment of the S-ramp ratios or switching initiators may be necessary.

3-41 Ramp 1 Ramp-up Time

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

3-42 Ramp 1 Ramp-down Time

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

3-45 Ramp 1 S-ramp Ratio at Accel. Start

Range: Function:

50 %* [Application dependant] Enter the proportion of the total ramp-up time (par.3-41 [Ramp 1 Ramp-up Time](#)) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks occurring in the application.

3-46 Ramp 1 S-ramp Ratio at Accel. End

Range: Function:

50 %* [Application dependant] Enter the proportion of the total ramp-up time (par.3-41 [Ramp 1 Ramp-up Time](#)) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-47 Ramp 1 S-ramp Ratio at Decel. Start

Range:	Function:
50 %* [Application dependant]	Enter the proportion of the total ramp-down time (par.3-42 Ramp 1 Ramp-down Time) where the deceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-48 Ramp 1 S-ramp Ratio at Decel. End

Range:	Function:
50 %* [Application dependant]	Enter the proportion of the total ramp-down time (par.3-42 Ramp 1 Ramp-down Time) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-5* Ramp 2

Choosing ramp parameters, see 3-4*.

3-51 Ramp 2 Ramp-up Time

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	

3-52 Ramp 2 Ramp-down Time

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	

3-55 Ramp 2 S-ramp Ratio at Accel. Start

Range:	Function:
50 %* [Application dependant]	Enter the proportion of the total ramp-up time (par.3-51 Ramp 2 Ramp-up Time) in which the acceleration torque increases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-56 Ramp 2 S-ramp Ratio at Accel. End

Range:	Function:
50 %* [Application dependant]	Enter the proportion of the total ramp-up time (par.3-51 Ramp 2 Ramp-up Time) in which the acceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-57 Ramp 2 S-ramp Ratio at Decel. Start

Range:	Function:
50 %* [Application dependant]	Enter the proportion of the total ramp-down time (par.3-52 Ramp 2 Ramp-down Time) where the deceleration torque increases. The larger

the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-58 Ramp 2 S-ramp Ratio at Decel. End

Range:

50 %* [Application dependant]

Function:

Enter the proportion of the total ramp-down time (par.3-52 [Ramp 2 Ramp-down Time](#)) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-8* Other Ramps

Configure parameters for special ramps such as jog or quick stop, for example.

3-80 Jog Ramp Time

Range:


Applica- [1.00 - 3600.00 s]

tion de-
pend-
ent*

Function:

Enter the jog ramp time, i.e., the acceleration/deceleration time between 0 RPM and the rated motor speed ($n_{M,N}$) (set in par.1-25 [Motor Nominal Speed](#)). Ensure that the resultant output current required for the given jog ramp time does not exceed the current limit in par.4-18 [Current Limit](#). The jog ramp time starts upon activation of a jog signal via the control panel, a selected digital input, or the serial communication port.

$$par. 3 - 80 = \frac{t_{jog} \times n_{norm}[par. 1 - 25]}{jog\ speed[par. 3 - 19]} [s]$$



3-80 Jog Ramp Time

Range:

Applica- [1.00 - 3600.00 s]

tion de-
pend-
ent*

Function:

3-84 Quick Stop S-ramp Ratio at Decel. End

Range:

50 %* [Application dependant]

Function:

Enter the proportion of the total ramp-down time (par.3-42 [Ramp 1 Ramp-down Time](#)) where the deceleration torque decreases. The larger the percentage value, the greater the jerk compensation achieved, and thus the lower the torque jerks in the application.

3-9* Digital Pot.Meter

The digital potentiometer function allows the user to increase or decrease the actual reference by adjusting the set-up of the digital inputs using the functions INCREASE, DECREASE or CLEAR. To activate the function, at least one digital input must be set up to INCREASE or DECREASE.

3-90 Step Size

Range: Function:

0.10 %* [0.01 - 200.00 %]

3-91 Ramp Time

Range: Function:

1.00 s [0.00 - 3600.00 s]

Enter the ramp time, i.e., the time for adjustment of the reference from 0% to 100% of the specified digital potentiometer function (INCREASE, DECREASE or CLEAR).

If INCREASE / DECREASE is activated for longer than the ramp delay period specified in par.3-95 [Ramp Delay](#), the actual reference will be ramped up / down according to this ramp time. The ramp time is defined as the time used to adjust the reference by the step size specified in par. 3-90 [Step Size](#).

3-92 Power Restore

Option: Function:

[0] * Off

Resets the Digital Potentiometer reference to 0% after power-up.

[1] On

Restores the most recent Digital Potentiometer reference at power-up.

3-93 Maximum Limit

Range: Function:

100 %* [-200 - 200 %]

Set the maximum permissible value for the resultant reference. This is advisable if the Digital Potentiometer is used for fine tuning of the resulting reference.

3-94 Minimum Limit

Range: Function:


0 %* [-200 - 200 %]

Set the minimum permissible value for the resultant reference. This is advisable if the Digital Potentiometer is used for fine tuning of the resulting reference.

3-95 Ramp Delay

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*



Main Menu - Limits/Warnings - Group 4

4-** Limits and Warnings

Parameter group for configuring limits and warnings.

4-1* Motor Limits

Define torque, current and speed limits for the motor, and the reaction of the adjustable frequency drive when the limits are exceeded.

A limit may generate a message on the display. A warning will always generate a message on the display or on the serial communication bus. A monitoring function may initiate a warning or a trip, upon which the adjustable frequency drive will stop and generate an alarm message.

4-10 Motor Speed Direction

Option:

Function:

Selects the motor speed direction required.
Use this parameter to prevent unwanted reversing.

[0] Clockwise

Only operation in a clockwise direction will be allowed.

[2] * Both directions

Operation in both a clockwise and anti-clockwise direction will be allowed.

NOTE: The setting in par.4-10 [Motor Speed Direction](#) has impact on the Flying Start in par.1-73 [Flying Start](#).

4-11 Motor Speed Low Limit [RPM]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-12 Motor Speed Low Limit [Hz]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-13 Motor Speed High Limit [RPM]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE: Max. output frequency cannot exceed 10% of the inverter switching frequency (par.14-01 [Switching Frequency](#)).

NOTE: Any changes in par.4-13 [Motor Speed High Limit \[RPM\]](#) will reset the value in par.4-53 [Warning Speed High](#) to the same value as set in par.4-13 [Motor Speed High Limit \[RPM\]](#).

4-14 Motor Speed High Limit [Hz]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE: Max. output frequency cannot exceed 10% of the inverter switching frequency (par.14-01 [Switching Frequency](#)).

4-16 Torque Limit Motor Mode

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-17 Torque Limit Generator Mode

Range: Function:

100.0 [Application dependant]
%*

4-18 Current Limit

Range:

Function:

Application dependent*

4-19 Max Output Frequency

Range:

Function:

Application dependent* [1.0 - 1000.0 Hz]

Enter the maximum output frequency value. par.4-19 [Max Output Frequency](#) specifies the absolute limit on the adjustable frequency drive output frequency for improved safety in applications where accidental overspeeding must be avoided. This absolute limit applies to all configurations and is independent of the setting in par.1-00 [Configuration Mode](#). This parameter cannot be adjusted while the motor is running.


4-5* Adj. Warnings

Define adjustable warning limits for current, speed, reference and feedback.

NOTE

Not visible in display, only in Trane Drive Utility.

Warnings are shown on display, programmed output or serial bus.



4-50 Warning Current Low

Range:

Function:

0.00 A* [Application dependent]

Enter the I_{LOW} value. When the motor current falls below this limit (I_{LOW}), the display reads CURRENT LOW. The signal outputs can be programmed to produce a status signal on terminal 27 or 29, and on relay output 01 or 02. Refer to the drawing in this section.

4-51 Warning Current High

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-53 Warning Speed High

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE: Any changes in par.4-13 [Motor Speed High Limit \[RPM\]](#) will reset the value in par.4-53 [Warning Speed High](#) to the same value as set in par.4-13 [Motor Speed High Limit \[RPM\]](#).

If a different value is needed in par.4-53 [Warning Speed High](#), it must be set after programming of par. 4-13 [Motor Speed High Limit \[RPM\]](#)!

4-54 Warning Reference Low

Range: Function:

-999999. [Application dependant]
999 N/
A*

Enter the lower reference limit. When the actual reference falls below this limit, the display indicates Ref Low. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-55 Warning Reference High

Range: Function:

999999. [Application dependant]
999 N/
A*

Enter the upper reference limit. When the actual reference exceeds this limit, the display reads Ref High. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-56 Warning Feedback Low

Range: Function:

-999999. [Application dependant]
999
Proc-
essCtrlU-
nit*

Enter the lower feedback limit. When the feedback falls below this limit, the display reads Feedb Low. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-57 Warning Feedback High

Range: Function:

999999. [Application dependant]
999
Proc-
essCtrlU-
nit*

Enter the upper feedback limit. When the feedback exceeds this limit, the display reads Feedb High. The signal outputs can be programmed to produce a status signal on terminal 27 or 29 and on relay output 01 or 02.

4-58 Missing Motor Phase Function

Option:	Function:
	Displays an alarm in the event of a missing motor phase.
[0] Disabled	No alarm is displayed if a missing motor phase occurs.
[2] * Trip 1000 ms	

NOTE

This parameter cannot be adjusted while the motor is running.

4-6* Speed Bypass

Define the speed bypass areas for the ramps.

Some systems call for avoiding certain output frequencies or speeds due to resonance problems in the system. A maximum of four frequency or speed ranges can be avoided.

4-60 Bypass Speed From [RPM]

Array [4]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-61 Bypass Speed From [Hz]

Array [4]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-62 Bypass Speed to [RPM]

Array [4]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

4-63 Bypass Speed To [Hz]

Array [4]

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

Semi-Automatic Bypass Speed Set-up

The Semi-Automatic Bypass Speed Set-up can be used to facilitate the programming of the frequencies to be skipped due to resonances in the system.

The following process is to be carried out:

1. Stop the motor.
2. Select Enabled in par.4-64 [Semi-Auto Bypass Set-up](#).
3. Press *Hand On* on the keypad to start the search for frequency bands causing resonances. The motor will ramp up according to the ramp set.
4. When sweeping through a resonance band, press *OK* on the keypad when leaving the band. The current frequency will be stored as the first element in par.4-62 [Bypass Speed to \[RPM\]](#) or par.4-63 [Bypass Speed To \[Hz\]](#) (array). Repeat this for each resonance band identified at the ramp-up (maximum four can be adjusted).
5. When maximum speed has been reached, the motor will automatically begin to ramp-down. Repeat the above procedure when speed is leaving the resonance bands during the deceleration. The current frequencies registered when pressing *OK* will be stored in par.4-60 [Bypass Speed From \[RPM\]](#) or par.4-61 [Bypass Speed From \[Hz\]](#).
6. When the motor has ramped down to stop, press *OK*. The par.4-64 [Semi-Auto Bypass Set-up](#) will automatically reset to Off. The adjustable frequency drive will stay in *Hand* mode until *Off* or *Auto On* are pressed on the keypad.

If the frequencies for a certain resonance band are not registered in the right order (frequency values stored in *By Pass Speed To* are higher than those in *By Pass Speed From*) or if they do not have the same numbers of registrations for the *By Pass From* and *By Pass To*, all registrations will be canceled and the following message is displayed: *Collected speed areas overlapping or not completely determined. Press [Cancel] to abort.*

4-64 Semi-Auto Bypass Set-up

Option:	Function:
[0] * OFF	No function
[1] Enabled	Starts the semi-automatic bypass set-up and continue with the procedure described above.

Main Menu - Digital In/Out - Group 5

5-** Digital In/Out

Parameter group for configuring the digital input and output.

5-0* Digital I/O Mode

Parameters for configuring the input and output using NPN and PNP.

5-01 Terminal 27 Mode

Option:	Function:
[0] * Input	Defines terminal 27 as a digital input.
[1] Output	Defines terminal 27 as a digital output.

Please note that this parameter cannot be adjusted while the motor is running.



Parameter Description

5-02 Terminal 29 Mode

Option:		Function:
[0] *	Input	Defines terminal 29 as a digital input.
[1]	Output	Defines terminal 29 as a digital output.

This parameter cannot be adjusted while the motor is running.

5-1* Digital Inputs

Parameters for configuring the input functions for the input terminals.

The digital inputs are used for selecting various functions in the adjustable frequency drive. All digital inputs can be set to the following functions:

Digital input function	Select	Terminal
No operation	[0]	All *terminal 19, 32, 33
Reset	[1]	All
Coast inverse	[2]	27
Coast and reset inverse	[3]	All
DC brake inverse	[5]	All
Stop inverse	[6]	All
External interlock	[7]	All
Start	[8]	All *terminal 18
Latched start	[9]	All
Reversing	[10]	All
Start reversing	[11]	All
Jog	[14]	All *terminal 29
Preset reference on	[15]	All
Preset ref bit 0	[16]	All
Preset ref bit 1	[17]	All
Preset ref bit 2	[18]	All
Freeze reference	[19]	All
Freeze output	[20]	All
Speed up	[21]	All
Slow	[22]	All
Set-up select bit 0	[23]	All
Set-up select bit 1	[24]	All
Pulse input	[32]	terminal 29, 33
Ramp bit 0	[34]	All
Mains failure inverse	[36]	All
Fire mode	[37]	All
Run Permissive	[52]	All
Hand start	[53]	All
Auto-start	[54]	All
DigiPot Increase	[55]	All
DigiPot Decrease	[56]	All
DigiPot Clear	[57]	All
Counter A (up)	[60]	29, 33
Counter A (down)	[61]	29, 33
Reset Counter A	[62]	All
Counter B (up)	[63]	29, 33
Counter B (down)	[64]	29, 33
Reset Counter B	[65]	All
Sleep Mode	[66]	All
Reset Maintenance Word	[78]	All
Lead Pump Start	[120]	All
Lead Pump Alternation	[121]	All
Pump 1 Interlock	[130]	All
Pump 2 Interlock	[131]	All
Pump 3 Interlock	[132]	All

Digital Inputs, 5-1* continued

All = Terminals 18, 19, 27, 29, 32, 33, X30/2, X30/3, X30/4. X30/ are the terminals on MCB 101.

Functions dedicated to only one digital input are stated in the associated parameter.

All digital inputs can be programmed to these functions:

[0]	No operation	No reaction to signals transmitted to terminal.
[1]	Reset	Resets adjustable frequency drive after a TRIP/ALARM. Not all alarms can be reset.
[2]	Coast inverse	Leaves motor in free mode. Logic '0' => coasting stop. (Default Digital input 27): Coasting stop, inverted input (NC).
[3]	Coast and reset inverse	Reset and coasting stop Inverted input (NC). Leaves motor in free mode and resets the adjustable frequency drive. Logic '0' => coasting stop and reset.
[5]	DC brake inverse	Inverted input for DC braking (NC). Stops motor by energizing it with a DC current for a certain time period. See par.2-01 DC Brake Current to par.2-03 DC Brake Cut-in Speed [RPM] . The function is only active when the value in par.2-02 DC Braking Time is different from 0. Logic '0' => DC braking.
[6]	Stop inverse	Stop Inverted function. Generates a stop function when the selected terminal goes from logical level '1' to '0'. The stop is performed according to the selected ramp time (par.3-42 Ramp 1 Ramp-down Time , par. 3-52 Ramp 2 Ramp-down Time , par.3-62 Ramp 3 Ramp-down Time , par. 3-72 Ramp 4 Ramp-down Time).
 WARNING When the adjustable frequency drive is at the torque limit and has received a stop command, it may not stop by itself. To ensure that the adjustable frequency drive stops, configure a digital output to Torque limit & stop [27] and connect this digital output to a digital input that is configured as coast.		
[7]	External Interlock	Same function as Coasting stop, inverse, but External Interlock generates the alarm message 'external fault' on the display when the terminal which is programmed for Coast Inverse is logic '0'. The alarm message will also be active via digital outputs and relay outputs, if programmed for External Interlock. The alarm can be reset using a digital input or the [RESET] key if the cause for the External Interlock has been removed. A delay can be programmed in par.22-00 External Interlock Delay , External Interlock Time. After applying a signal to the input, the reaction described above will be delayed with the time set in par.22-00 External Interlock Delay .
[8]	Start	Select start for a start/stop command. Logic '1' = start, logic '0' = stop. (Default Digital input 18)
[9]	Latched start	Motor starts, if a pulse is applied for min. 2 ms. Motor stops when Stop inverse is activated
[10]	Reversing	Changes direction of motor shaft rotation. Select Logic '1' to reverse. The reversing signal only changes the direction of rotation. It does not activate the start function. Select both directions in par.4-10 Motor Speed Direction .

		(Default Digital input 19).
[11]	Start reversing	Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.
[14]	Jog	Used for activating jog speed. See par.3-11 Jog Speed [Hz] . (Default Digital input 29)
[15]	Preset reference on	Used for shifting between external reference and preset reference. It is assumed that <i>External/preset</i> [1] has been selected in par.3-04 Reference Function . Logic '0' = external reference active; logic '1' = one of the eight preset references is active.
[16]	Preset ref bit 0	Enables a choice between one of the eight preset references according to the table below.
[17]	Preset ref bit 1	Enables a choice between one of the eight preset references according to the table below.
[18]	Preset ref bit 2	Enables a choice between one of the eight preset references according to the table below.

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

[19]	Freeze ref	Freezes actual reference. The frozen reference is now the point of enable/condition for Speed up and Slow to be used. If Speed up/down is used, the speed change always follows ramp 2 (par.3-51 Ramp 2 Ramp-up Time and par.3-52 Ramp 2 Ramp-down Time) in the range 0 - par.3-03 Maximum Reference . (For closed-loop, see par.20-14 Maximum Reference/Feedb.).
[20]	Freeze output	Freezes actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Slow to be used. If Speed up/down is used, the speed change always follows ramp 2 (par.3-51 Ramp 2 Ramp-up Time and par.3-52 Ramp 2 Ramp-down Time) in the range 0 - par.1-23 Motor Frequency .

WARNING

When Freeze output is active, the adjustable frequency drive cannot be stopped via a low 'start [13]' signal. Stop the adjustable frequency drive via a terminal programmed for Coasting inverse [2] or Coast and reset, inverse [3].

[21]	Speed up	For digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed up is activated for less than 400 msec., the resulting reference will be increased by 0.1%. If Speed up is activated for more than 400 msec., the resulting reference will ramp according to Ramp 1 in par.3-41 Ramp 1 Ramp-up Time .
[22]	Slow	Same as Speed up [21].

Parameter Description

[23]	Set-up select bit 0	Selects one of the four set-ups. Set par. 0-10 to Multi Set-up.
[24]	Set-up select bit 1	Same as Set-up select bit 0 [23]. (Default Digital input 32)
[32]	Pulse input	Select Pulse input when using a pulse sequence as either reference or feedback. Scaling is done in par. group 5-5*.
[34]	Ramp bit 0	Select which ramp to use. Logic "0" will select ramp 1 while logic "1" will select ramp 2.
[36]	Mains failure inverse	Select to activate function selected in par.14-10 Mains Failure . Line failure is active in the Logic "0" situation.
[37]	Fire mode	A signal applied will put the adjustable frequency drive into fire mode and all other commands will be disregarded. See 24-0* <i>Fire Mode</i> .
[52]	Run Permissive	The input terminal, for which the Run permissive has been programmed must be logic "1" before a start command can be accepted. Run permissive has a logic 'AND' function related to the terminal which is programmed for <i>START</i> [8], <i>Jog</i> [14] or <i>Freeze Output</i> [20], which means that in order to start running the motor, both conditions must be fulfilled. If Run Permissive is programmed on multiple terminals, Run permissive needs only be logic '1' on one of the terminals for the function to be carried out. The digital output signal for Run Request (<i>Start</i> [8], <i>Jog</i> [14] or <i>Freeze output</i> [20]) programmed in par. 5-3*, or par. 5-4*, will not be affected by Run Permissive. NOTE: If no Run Permissive signal is applied but either Run, Jog or Freeze commands is activated, the status line in the display will show either Run Requested, Jog Requested or Freeze Requested.
[53]	Hand start	A signal applied will put the adjustable frequency drive into hand mode as if button <i>Hand On</i> on the keypad has been pressed and a normal stop command will be overridden. If disconnecting the signal, the motor will stop. To make any other start commands valid, another digital input must be assign to <i>Auto Start</i> and a signal applied to this. The <i>Hand On</i> and <i>Auto On</i> buttons on the keypad has no impact. The <i>Off</i> button on the keypad will override <i>Hand Start</i> and <i>Auto-Start</i> . Press either the <i>Hand On</i> or <i>Auto On</i> button to make <i>Hand Start</i> and <i>Auto Start</i> active again. If no signal on neither <i>Hand Start</i> nor <i>Auto-Start</i> , the motor will stop regardless of any normal Start command applied. If signal applied to both <i>Hand Start</i> and <i>Auto-Start</i> , the function will be <i>Auto-Start</i> . If pressing the <i>Off</i> button on the keypad, the motor will stop regardless of signals on <i>Hand Start</i> and <i>Auto-Start</i> .
[54]	Auto-start	A signal applied will put the adjustable frequency drive into auto mode as if the keypad button <i>Auto On</i> has been pressed. See also <i>Hand Start</i> [53]
[55]	DigiPot Increase	Uses the input as an INCREASE signal to the Digital Potentiometer function described in parameter group 3-9*
[56]	DigiPot Decrease	Uses the input as a DECREASE signal to the Digital Potentiometer function described in parameter group 3-9*
[57]	DigiPot Clear	Uses the input to CLEAR the Digital Potentiometer reference described in parameter group 3-9*
[60]	Counter A (up)	(Terminal 29 or 33 only) Input for increment counting in the SLC counter.
[61]	Counter A (down)	(Terminal 29 or 33 only) Input for decrement counting in the SLC counter.
[62]	Reset Counter A	Input for reset of counter A.

[63]	Counter B (up)	(Terminal 29 and 33 only) Input for increment counting in the SLC counter.
[64]	Counter B (down)	(Terminal 29 and 33 only) Input for decrement counting in the SLC counter.
[65]	Reset Counter B	Input for reset of counter B.
[66]	Sleep Mode	Forces the adjustable frequency drive into sleep mode (see par. 22-4*). Reacts on the rising edge of signal applied!
[78]	Reset Preventive Maintenance Word	Resets all data in par.16-96 Maintenance Word to 0.

Digital Inputs, 5-1* continued

All = Terminals 18, 19, 27, 29, 32, 33, X30/2, X30/3, X30/4. X30/ are the terminals on MCB 101.

Functions dedicated to only one digital input are stated in the associated parameter.

All digital inputs can be programmed to these functions:

[0]	No operation	No reaction to signals transmitted to terminal.
[1]	Reset	Resets adjustable frequency drive after a TRIP/ALARM. Not all alarms can be reset.
[2]	Coast inverse	Leaves motor in free mode. Logic '0' => coasting stop. (Default Digital input 27): Coasting stop, inverted input (NC).
[3]	Coast and reset inverse	Reset and coasting stop Inverted input (NC). Leaves motor in free mode and resets the adjustable frequency drive. Logic '0' => coasting stop and reset.
[5]	DC brake inverse	Inverted input for DC braking (NC). Stops motor by energizing it with a DC current for a certain time period. See par.2-01 DC Brake Current to par.2-03 DC Brake Cut-in Speed [RPM] . The function is only active when the value in par.2-02 DC Braking Time is different from 0. Logic '0' => DC braking.
[6]	Stop inverse	Stop Inverted function. Generates a stop function when the selected terminal goes from logical level '1' to '0'. The stop is performed according to the selected ramp time (par.3-42 Ramp 1 Ramp-down Time , par. 3-52 Ramp 2 Ramp-down Time , par.3-62 Ramp 3 Ramp-down Time , par. 3-72 Ramp 4 Ramp-down Time). NOTE: When the adjustable frequency drive is at the torque limit and has received a stop command, it may not stop by itself. To ensure that the adjustable frequency drive stops, configure a digital output to <i>Torque limit & stop</i> [27] and connect this digital output to a digital input that is configured as coast.
[7]	External Interlock	Same function as Coasting stop, inverse, but External Interlock generates the alarm message 'external fault' on the display when the terminal which is programmed for Coast Inverse is logic '0'. The alarm message will also be active via digital outputs and relay outputs, if programmed for External Interlock. The alarm can be reset using a digital input or the [RESET] key if the cause for the External Interlock has been removed. A delay can be programmed in par.22-00 External Interlock Delay , External Interlock Time. After applying a signal to the input, the reaction described

		above will be delayed with the time set in par.22-00 External Interlock Delay .
[8]	Start	Select start for a start/stop command. Logic '1' = start, logic '0' = stop. (Default Digital input 18)
[9]	Latched start	Motor starts, if a pulse is applied for min. 2 ms. Motor stops when Stop inverse is activated
[10]	Reversing	Changes direction of motor shaft rotation. Select Logic '1' to reverse. The reversing signal only changes the direction of rotation. It does not activate the start function. Select both directions in par.4-10 Motor Speed Direction . (Default Digital input 19).
[11]	Start reversing	Used for start/stop and for reversing on the same wire. Signals on start are not allowed at the same time.
[14]	Jog	Used for activating jog speed. See par.3-11 Jog Speed [Hz] . (Default Digital input 29)
[15]	Preset reference on	Used for shifting between external reference and preset reference. It is assumed that <i>External/preset</i> [1] has been selected in par.3-04 Reference Function . Logic '0' = external reference active; logic '1' = one of the eight preset references is active.
[16]	Preset ref bit 0	Enables a choice between one of the eight preset references according to the table below.
[17]	Preset ref bit 1	Enables a choice between one of the eight preset references according to the table below.
[18]	Preset ref bit 2	Enables a choice between one of the eight preset references according to the table below.

Preset ref. bit	2	1	0
Preset ref. 0	0	0	0
Preset ref. 1	0	0	1
Preset ref. 2	0	1	0
Preset ref. 3	0	1	1
Preset ref. 4	1	0	0
Preset ref. 5	1	0	1
Preset ref. 6	1	1	0
Preset ref. 7	1	1	1

[19]	Freeze ref	Freezes actual reference. The frozen reference is now the point of enable/condition for Speed up and Slow to be used. If Speed up/down is used, the speed change always follows ramp 2 (par.3-51 Ramp 2 Ramp-up Time and par.3-52 Ramp 2 Ramp-down Time) in the range 0 - par. 3-03 Maximum Reference . (For closed-loop, see par.20-14 Maximum Reference/Feedb.).
[20]	Freeze output	Freezes actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Slow to be used. If Speed up/down is used, the speed change always follows ramp 2 (par. 3-51 Ramp 2 Ramp-up Time and par.3-52 Ramp 2 Ramp-down Time) in the range 0 - par.1-23 Motor Frequency . NOTE: When Freeze output is active, the adjustable frequency drive cannot be stopped via a low 'start [13]' signal. Stop the adjustable frequency

drive via a terminal programmed for Coasting inverse [2] or Coast and reset, inverse [3].

[21]	Speed up	For digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed up is activated for less than 400 msec., the resulting reference will be increased by 0.1%. If Speed up is activated for more than 400 msec., the resulting reference will ramp according to Ramp 1 in par.3-41 Ramp 1 Ramp-up Time .
[22]	Slow	Same as Speed up [21].
[23]	Set-up select bit 0	Selects one of the four set-ups. Set par. 0-10 to Multi Set-up.
[24]	Set-up select bit 1	Same as Set-up select bit 0 [23]. (Default Digital input 32)
[32]	Pulse input	Select Pulse input when using a pulse sequence as either reference or feedback. Scaling is done in par. group 5-5*.
[34]	Ramp bit 0	Select which ramp to use. Logic "0" will select ramp 1 while logic "1" will select ramp 2.
[36]	Mains failure inverse	Select to activate function selected in par.14-10 Mains Failure . Line failure is active in the Logic "0" situation.
[37]	Fire mode	A signal applied will put the adjustable frequency drive into fire mode and all other commands will be disregarded. See 24-0* <i>Fire Mode</i> .
[52]	Run Permissive	The input terminal, for which the Run permissive has been programmed must be logic "1" before a start command can be accepted. Run permissive has a logic 'AND' function related to the terminal which is programmed for <i>START</i> [8], <i>Jog</i> [14] or <i>Freeze Output</i> [20], which means that in order to start running the motor, both conditions must be fulfilled. If Run Permissive is programmed on multiple terminals, Run permissive needs only be logic '1' on one of the terminals for the function to be carried out. The digital output signal for Run Request (<i>Start</i> [8], <i>Jog</i> [14] or <i>Freeze output</i> [20]) programmed in par. 5-3*, or par. 5-4*, will not be affected by Run Permissive. NOTE: If no Run Permissive signal is applied but either Run, Jog or Freeze commands is activated, the status line in the display will show either Run Requested, Jog Requested or Freeze Requested.
[53]	Hand start	A signal applied will put the adjustable frequency drive into hand mode as if button <i>Hand On</i> on the keypad has been pressed and a normal stop command will be overridden. If disconnecting the signal, the motor will stop. To make any other start commands valid, another digital input must be assigned to <i>Auto-Start</i> and a signal applied to this. The <i>Hand On</i> and <i>Auto On</i> buttons on the keypad has no impact. The <i>Off</i> button on the keypad will override <i>Hand Start</i> and <i>Auto-Start</i> . Press either the <i>Hand On</i> or <i>Auto On</i> button to make <i>Hand Start</i> and <i>Auto-Start</i> active again. If no signal on neither <i>Hand Start</i> nor <i>Auto-Start</i> , the motor will stop regardless of any normal Start command applied. If signal applied to both <i>Hand Start</i> and <i>Auto-Start</i> , the function will be <i>Auto-Start</i> . If pressing the <i>Off</i> button on the keypad, the motor will stop regardless of signals on <i>Hand Start</i> and <i>Auto-Start</i> .
[54]	Auto start	A signal applied will put the adjustable frequency drive into auto mode as if the keypad button <i>Auto On</i> has been pressed. See also <i>Hand Start</i> [53]



5-10 Terminal 18 Digital Input

5-11 Terminal 19 Digital Input

Option: _____ Function: _____

5-12 Terminal 27 Digital Input

Option: _____ Function: _____

5-13 Terminal 29 Digital Input

[0]	No operation
[1]	Reset
[2]	Coast inverse
[3]	Coast and Reset Inv
[5]	DC brake inverse
[6]	Stop inverse
[7]	External interlock
[8]	Start
[9]	Latched start
[10]	Reverse
[11]	Start reverse
[14] *	Jog
[15]	Preset reference on
[16]	Preset ref bit 0
[17]	Preset ref bit 1
[18]	Preset ref bit 2



5-14 Terminal 32 Digital Input

TR200 Programming Guide

5-15 Terminal 33 Digital Input

Option: _____ Function: _____

5-16 Terminal X30/2 Digital Input

[0] *	No operation
[1]	Reset
[2]	Coast inverse
[3]	Coast and Reset Inv
[5]	DC brake inverse
[6]	Stop inverse
[7]	External interlock

Parameter Description

[8]	Start
[9]	Latched start
[10]	Reverse
[11]	Start reverse
[14]	Jog
[15]	Preset reference on
[16]	Preset ref bit 0
[17]	Preset ref bit 1
[18]	Preset ref bit 2
[19]	Freeze reference
[20]	Freeze output
[21]	Speed up
[22]	Slow
[23]	Set-up select bit 0
[24]	Set-up select bit 1
[34]	Ramp bit 0
[36]	Mains failure inverse
[37]	Fire Mode
[52]	Run permissive
[53]	Hand start
[54]	Auto-start
[55]	DigiPot increase
[56]	DigiPot decrease
[57]	DigiPot clear
[62]	Reset Counter A
[65]	Reset Counter B
[66]	Sleep Mode
[78]	Reset Maint. Word
[120]	Lead Pump Start
[121]	Lead Pump Alternation
[130]	Pump 1 Interlock
[131]	Pump 2 Interlock
[132]	Pump 3 Interlock

5-17 Terminal X30/3 Digital Input

Option:	Function:
[0] *	No operation
[1]	Reset
[2]	Coast inverse
[3]	Coast and Reset Inv
[5]	DC brake inverse
[6]	Stop inverse
[7]	External interlock
[8]	Start

5-18 Terminal X30/4 Digital Input

4-65

Parameter Description

[10]	Reverse
[11]	Start reverse
[14]	Jog
[15]	Preset reference on
[16]	Preset ref bit 0
[17]	Preset ref bit 1
[18]	Preset ref bit 2
[19]	Freeze reference
[20]	Freeze output
[21]	Speed up
[22]	Slow
[23]	Set-up select bit 0
[24]	Set-up select bit 1
[34]	Ramp bit 0
[36]	Mains failure inverse
[37]	Fire Mode
[52]	Run permissive
[53]	Hand start
[54]	Auto-start
[55]	DigiPot increase
[56]	DigiPot decrease
[57]	DigiPot clear
[62]	Reset Counter A
[65]	Reset Counter B
[66]	Sleep Mode
[78]	Reset Maint. Word
[120]	Lead Pump Start
[121]	Lead Pump Alternation
[130]	Pump 1 Interlock
[131]	Pump 2 Interlock
[132]	Pump 3 Interlock

5-3* Digital Outputs

Parameters for configuring the output functions for the output terminals. The 2 solid-state digital outputs are common for terminals 27 and 29. Set the I/O function for terminal 27 in par.5-01 [Terminal 27 Mode](#) and set the I/O function for terminal 29 in par.5-02 [Terminal 29 Mode](#). These parameters cannot be adjusted while the motor is running.


		The digital outputs can be programmed with these functions:
[0]	No operation	<i>Default for all digital outputs and relay outputs</i>
[1]	Control ready	The control board receives supply voltage.
[2]	Drive ready	The adjustable frequency drive is ready for operation and applies a supply signal on the control board.

[3]	Drive ready / remote control	The adjustable frequency drive is ready for operation and is in Auto On mode.
[4]	Stand-by / no warning	The adjustable frequency drive is ready for operation. No start or stop command is been given (start/disable). There are no warnings.
[5]	Running	The motor is running.
[6]	Running / no warning	The output speed is higher than the speed set in par.1-81 Min Speed for Function at Stop [RPM] . The motor is running and there are no warnings.
[8]	Run on reference / no warning	The motor runs at reference speed.
[9]	Alarm	An alarm activates the output. There are no warnings.
[10]	Alarm or warning	An alarm or a warning activates the output.
[11]	At torque limit	The torque limit set in par.4-16 Torque Limit Motor Mode or par. 1-17 has been exceeded.
[12]	Out of current range	The motor current is outside the range set in par.4-18 Current Limit .
[13]	Below current, low	The motor current is lower than set in par.4-50 Warning Current Low .
[14]	Above current, high	The motor current is higher than set in par.4-51 Warning Current High .
[15]	Out of speed range	The output speed is outside the range set in par.4-52 Warning Speed Low and par.4-53 Warning Speed High .
[16]	Below speed, low	The output speed is lower than the setting in par.4-52 Warning Speed Low .
[17]	Above speed, high	The output speed is higher than the setting in par.4-53 Warning Speed High .
[18]	Out of feedback range	The feedback is outside the range set in par.4-56 Warning Feedback Low and par.4-57 Warning Feedback High .
[19]	Below feedback low	The feedback is below the limit set in par.4-56 Warning Feedback Low .
[20]	Above feedback high	The feedback is above the limit set in par.4-57 Warning Feedback High .
[21]	Thermal warning	The thermal warning turns on when the temperature exceeds the limit in the motor, the adjustable frequency drive, the brake resistor, or the thermistor.
[25]	Reverse	<i>Reversing. Logic '1' = relay activated, 24 V DC when CW rotation of the motor. Logic '0' = relay not activated, no signal, when CCW rotation of the motor.</i>
[26]	Bus OK	Active communication (no timeout) via the serial communication port.
[27]	Torque limit and stop	Use in performing a coasting stop and in torque limit condition. If the adjustable frequency drive has received a stop signal and is at the torque limit, the signal is Logic '0'.
[28]	Brake, no warning	The brake is active and there are no warnings.
[29]	Brake ready, no fault	The brake is ready for operation and there are no faults.
[30]	Brake fault (IGBT)	The output is Logic '1' when the brake IGBT is short-circuited. Use this function to protect the adjustable frequency drive if there is a fault on the brake modules. Use the output/relay to cut out the AC line voltage from the adjustable frequency drive.
[35]	External Interlock	External Interlock function has been activated via one of the digital inputs.
[40]	Out of ref range	
[41]	Below reference low	
[42]	Above reference high	

Parameter Description

[45]	Bus Ctrl	
[46]	Bus Ctrl 1 if timeout	
[47]	Bus Ctrl 0 if timeout	
[55]	Pulse output	
[60]	Comparator 0	See par. group 13-1*. If Comparator 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[61]	Comparator 1	See par. group 13-1*. If Comparator 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[62]	Comparator 2	See par. group 13-1*. If Comparator 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[63]	Comparator 3	See par. group 13-1*. If Comparator 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[64]	Comparator 4	See par. group 13-1*. If Comparator 4 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[65]	Comparator 5	See par. group 13-1*. If Comparator 5 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[70]	Logic Rule 0	See par. group 13-4*. If Logic Rule 0 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[71]	Logic Rule 1	See par. group 13-4*. If Logic Rule 1 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[72]	Logic Rule 2	See par. group 13-4*. If Logic Rule 2 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[73]	Logic Rule 3	See par. group 13-4*. If Logic Rule 3 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[74]	Logic Rule 4	See par. group 13-4*. If Logic Rule 4 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[75]	Logic Rule 5	See par. group 13-4*. If Logic Rule 5 is evaluated as TRUE, the output will go high. Otherwise, it will be low.
[80]	SL Digital Output A	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [38] <i>Set dig. out. A high</i> is executed. The input will go low whenever the Smart Logic Action [32] <i>Set dig. out. A low</i> is executed.
[81]	SL Digital Output B	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [39] <i>Set dig. out. B high</i> is executed. The input will go low whenever the Smart Logic Action [33] <i>Set dig. out. B low</i> is executed.
[82]	SL Digital Output C	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [40] <i>Set dig. out. C high</i> is executed. The input will go low whenever the Smart Logic Action [34] <i>Set dig. out. C low</i> is executed.
[83]	SL Digital Output D	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [41] <i>Set dig. out. D high</i> is executed. The input will go low whenever the Smart Logic Action [35] <i>Set dig. out. D low</i> is executed.
[84]	SL Digital Output E	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [42] <i>Set dig. out. E high</i> is executed. The input will go low whenever the Smart Logic Action [36] <i>Set dig. out. E low</i> is executed.
[85]	SL Digital Output F	See par.13-52 SL Controller Action . The input will go high whenever the Smart Logic Action [43] <i>Set dig. out. F high</i> is executed. The input will go low whenever the Smart Logic Action [37] <i>Set dig. out. F low</i> is executed.
[160]	No alarm	The output is high when no alarm is present.

[161]	Running reverse	The output is high when the adjustable frequency drive is running counter-clockwise (the logical product of the status bits 'running' AND 'reverse').
[165]	Local reference active	The output is high when par.3-13 Reference Site = [2] Local or when par. 3-13 Reference Site = [0] <i>Linked to hand auto</i> at the same time as the keypad is in [Hand on] mode.
[166]	Remote reference active	The output is high when par.3-13 Reference Site [1] or <i>Linked to hand/ auto</i> [0] while the keypad is in [Auto on] mode.
[167]	Start command active	The output is high when there is an active start command (i.e., via digital input bus connection or [Hand on] or [Auto on], and no stop command is active.
[168]	Drive in hand mode	The output is high when the adjustable frequency drive is in Hand on mode (as indicated by the LED light above [Hand on].
[169]	Drive in auto mode	The output is high when the adjustable frequency drive is in Hand on mode (as indicated by the LED light above [Auto on].
[180]	Clock Fault	The clock function has been reset to default (2000-01-01) because of a power failure.
[181]	Preventive Maintenance	One or more of the preventive maintenance events programmed in par. 23-10 Maintenance Item has passed the time for the specified action in par.23-11 Maintenance Action .
[190]	No-Flow	A No-Flow situation or Minimum Speed situation has been detected if enabled in par.22-22 Low Speed Detection .
[191]	Dry Pump	A dry pump condition has been detected.
[192]	End of Curve	A pump running with max. speed for a period of time without reaching the set pressure has been detected. To enable this function, see par. 22-50 End of Curve Function .
[193]	Sleep Mode	The adjustable frequency drive/system has set to sleep mode. See par. 22-4*.
[194]	Broken Belt	A broken belt condition has been detected. This function must be enabled in par.22-60 Broken Belt Function .
[195]	Bypass Valve Control	The bypass valve control (digital/relay output in the adjustable frequency drive) is used for compressor systems to unload the compressor during start-up by using a bypass valve. After the start command is given, the bypass valve will be open until the adjustable frequency drive reaches par.4-11 Motor Speed Low Limit [RPM] . After the limit has been reached the bypass valve will be closed, allowing the compressor to operate normally. This procedure will not be activated again before a new start is initiated and the adjustable frequency drive speed is zero during the receiving of start signal. par.1-71 Start Delay can be used in order to delay the motor start. The bypass valve control principle:



- [196] Fire Mode The adjustable frequency drive is operating in fire mode. See parameter group 24-0* *Fire Mode*.
- [197] Fire Mode was act. The adjustable frequency drive has been operating in fire mode, but is now back in normal operation.
- [198] Drive Bypass To be used as signal for activating an external electromechanical bypass switching the motor direct on line. See 24-1* *Drive Bypass*.

CAUTION

If enabling the Drive Bypass function, the adjustable frequency drive is no longer Safety Certified (for using the Safe Stop in versions where included).

The setting options below are all related to the cascade controller.
Wiring diagrams and settings for parameter, see group 25-** for more details.

- [200] Full Capacity All pumps running and at full speed
- [201] Pump1 Running One or more of the pumps controlled by the cascade controller are running. The function will also depend on the setting of in par. 25-06 [Number Of Pumps](#). If set to *No* [0] Pump 1 refers to the pump controlled by relay RELAY1 etc. If set to *Yes* [1], Pump 1 refers to the pump controlled by the adjustable frequency drive only (without any of the built-in relays involved) and Pump 2 to the pump controlled by the relay RELAY1. See the table below:
- [202] Pump2 Running See [201]
- [203] Pump3 Running See [201]

Setting in Par. 5-3*	Setting in par. 25-06 Number Of Pumps	
	[0] No	[1] Yes
[200] Pump 1 Running	Controlled by RELAY1	Adjustable frequency drive controlled
[201] Pump 2 Running	Controlled by RELAY2	Controlled by RELAY1
[203] Pump 3 Running	Controlled by RELAY3	Controlled by RELAY2

5-30 Terminal 27 Digital Output

Option:

Function:

Same options and functions as par. 5-3*.

[0] * No operation

5-31 Terminal 29 Digital Output

Same options and functions as par. 5-3*.

Option:

Function:

[0] * No operation

5-32 Term X30/6 Digi Out (MCB 101)

Option:

Function:

[0] * No operation

[1] Control ready

[2] Drive ready

[3] Drive rdy/rem ctrl

[4] Standby / no warning

[5] Running

[6] Running / no warning

[8] Run on ref/no warn

[9] Alarm

[10] Alarm or warning

[11] At torque limit

[12] Out of current range

[13] Below current, low

[14] Above current, high

[15] Out of speed range

[16] Below speed, low

[17] Above speed, high

[18] Out of feedb. range

[19] Below feedback, low

[20] Above feedback, high

[21] Thermal warning

[25] Reverse

[26] Bus OK

[27] Torque limit stop

[28] Brake: No Brake War

[29] Brake ready, no fault

[30] Brake fault (IGBT)

[35] External Interlock

[40] Out of ref range

[41] Below reference, low

[42] Above ref, high

[45] Bus ctrl.



Parameter Description

[46]	Bus ctrl, 1 if timeout
[47]	Bus ctrl, 0 if timeout
[55]	Pulse output
[60]	Comparator 0
[61]	Comparator 1
[62]	Comparator 2
[63]	Comparator 3
[64]	Comparator 4
[65]	Comparator 5
[70]	Logic rule 0
[71]	Logic rule 1
[72]	Logic rule 2
[73]	Logic rule 3
[74]	Logic rule 4
[75]	Logic rule 5
[80]	SL digital output A
[81]	SL digital output B
[82]	SL digital output C
[83]	SL digital output D
[84]	SL digital output E
[85]	SL digital output F
[160]	No alarm
[161]	Running reverse
[165]	Local ref active
[166]	Remote ref active
[167]	Start command act.
[168]	Hand mode
[169]	Auto mode
[180]	Clock Fault
[181]	Prev. Maintenance
[190]	No-Flow
[191]	Dry Pump
[192]	End Of Curve
[193]	Sleep Mode
[194]	Broken Belt
[195]	Bypass Valve Control
[196]	Fire Mode
[197]	Fire Mode was Act.
[198]	Drive Bypass
[200]	Full capacity
[201]	Pump 1 running
[202]	Pump 2 running
[203]	Pump 3 running

Option:	Function:
1. Option 1: <i>Standard</i> (100%) 2. Option 2: <i>Standard</i> (100%) 3. Option 3: <i>Standard</i> (100%) 4. Option 4: <i>Standard</i> (100%) 5. Option 5: <i>Standard</i> (100%) 6. Option 6: <i>Standard</i> (100%) 7. Option 7: <i>Standard</i> (100%) 8. Option 8: <i>Standard</i> (100%) 9. Option 9: <i>Standard</i> (100%) 10. Option 10: <i>Standard</i> (100%)	1. Function 1: <i>Standard</i> (100%) 2. Function 2: <i>Standard</i> (100%) 3. Function 3: <i>Standard</i> (100%) 4. Function 4: <i>Standard</i> (100%) 5. Function 5: <i>Standard</i> (100%) 6. Function 6: <i>Standard</i> (100%) 7. Function 7: <i>Standard</i> (100%) 8. Function 8: <i>Standard</i> (100%) 9. Function 9: <i>Standard</i> (100%) 10. Function 10: <i>Standard</i> (100%)

[0] *	No operation
[1]	Control ready
[2]	Drive ready
[3]	Drive rdy/rem ctrl
[4]	Standby / no warning
[5]	Running
[6]	Running / no warning
[8]	Run on ref/no warn
[9]	Alarm
[10]	Alarm or warning
[11]	At torque limit
[12]	Out of current range
[13]	Below current, low
[14]	Above current, high
[15]	Out of speed range
[16]	Below speed, low
[17]	Above speed, high
[18]	Out of feedb. range
[19]	Below feedback, low
[20]	Above feedback, high
[21]	Thermal warning
[25]	Reverse
[26]	Bus OK
[27]	Torque limit stop
[28]	Brake: No Brake War
[29]	Brake ready, no fault
[30]	Brake fault (IGBT)
[35]	External Interlock
[40]	Out of ref range
[41]	Below reference, low
[42]	Above ref, high
[45]	Bus ctrl.
[46]	Bus ctrl, 1 if timeout
[47]	Bus ctrl, 0 if timeout
[60]	Comparator 0
[61]	Comparator 1
[62]	Comparator 2
[63]	Comparator 3
[64]	Comparator 4
[65]	Comparator 5
[70]	Logic rule 0

Parameter Description

[71]	Logic rule 1
[72]	Logic rule 2
[73]	Logic rule 3
[74]	Logic rule 4
[75]	Logic rule 5
[80]	SL digital output A
[81]	SL digital output B
[82]	SL digital output C
[83]	SL digital output D
[84]	SL digital output E
[85]	SL digital output F
[160]	No alarm
[161]	Running reverse
[165]	Local ref active
[166]	Remote ref active
[167]	Start command act.
[168]	Hand mode
[169]	Auto mode
[180]	Clock Fault
[181]	Prev. Maintenance
[190]	No-Flow
[191]	Dry Pump
[192]	End Of Curve
[193]	Sleep Mode
[194]	Broken Belt
[195]	Bypass Valve Control
[200]	Full capacity
[201]	Pump 1 running
[202]	Pump 2 running
[203]	Pump 3 running

5-4* Relays

Parameters for configuring the timing and the output functions for the relays.

5-40 Function Relay

Array [8]

(Relay 1 [0], Relay 2 [1]

Option MCB 105: Relay 7 [6], Relay 8 [7] and Relay 9 [8]).

Select options to define the function of the relays.

The selection of each mechanical relay is realized in an array parameter.

Option:

Function:

[0] * No operation

[1] Control ready

[2] Drive ready

[3]	Drive rdy/rem ctrl	
[4]	Standby / no warning	
[5] *	Running	Default setting for relay 2.
[6]	Running / no warning	
[8]	Run on ref/no warn	
[9] *	Alarm	Default setting for relay 1.
[10]	Alarm or warning	
[11]	At torque limit	
[12]	Out of current range	
[13]	Below current, low	
[14]	Above current, high	
[15]	Out of speed range	
[16]	Below speed, low	
[17]	Above speed, high	
[18]	Out of feedb. range	
[19]	Below feedback, low	
[20]	Above feedback, high	
[21]	Thermal warning	
[25]	Reverse	
[26]	Bus OK	
[27]	Torque limit stop	
[28]	Brake: No Brake War	
[29]	Brake ready, no fault	
[30]	Brake fault (IGBT)	
[35]	External Interlock	
[36]	Control word bit 11	
[37]	Control word bit 12	
[40]	Out of ref range	
[41]	Below reference, low	
[42]	Above ref, high	
[45]	Bus ctrl.	
[46]	Bus ctrl, 1 if timeout	
[47]	Bus ctrl, 0 if timeout	
[60]	Comparator 0	
[61]	Comparator 1	
[62]	Comparator 2	
[63]	Comparator 3	
[64]	Comparator 4	
[65]	Comparator 5	
[70]	Logic rule 0	
[71]	Logic rule 1	
[72]	Logic rule 2	
[73]	Logic rule 3	

Parameter Description

[74]	Logic rule 4
[75]	Logic rule 5
[80]	SL digital output A
[81]	SL digital output B
[82]	SL digital output C
[83]	SL digital output D
[84]	SL digital output E
[85]	SL digital output F
[160]	No alarm
[161]	Running reverse
[165]	Local ref active
[166]	Remote ref active
[167]	Start command act.
[168]	Hand mode
[169]	Auto mode
[180]	Clock Fault
[181]	Prev. Maintenance
[190]	No-Flow
[191]	Dry Pump
[192]	End Of Curve
[193]	Sleep Mode
[194]	Broken Belt
[195]	Bypass Valve Control
[196]	Fire Mode
[197]	Fire Mode was Act.
[198]	Drive Bypass
[211]	Cascade Pump 1
[212]	Cascade Pump 2
[213]	Cascade Pump 3

5-41 On Delay, Relay


Array [8](Relay 1 [0], Relay 2 [1], Relay 3 [2], Relay 4 [3], Relay 5 [4], Relay 6 [5], Relay 7 [6], Relay 8 [7], Relay 9 [8])

Range:

0.01 s* [0.01 - 600.00 s]

Function:

Enter the delay of the relay cut-in time. Select one of available mechanical relays and MCB 105 in an array function. See par.5-40 [Function Relay](#). Relay 3-6 are included in MCB 113.



5-42 Off Delay, Relay


Array [8] (Relay 1 [0], Relay 2 [1], Relay 3 [2], Relay 4 [3], Relay 5 [4], Relay 6 [5], Relay 7 [6], Relay 8 [7], Relay 9 [8])

Range:

0.01 s* [0.01 - 600.00 s]

Function:


Enter the delay of the relay cut-out time. Select one of available mechanical relays and MCB 105 in an array function. See par.5-40 [Function Relay](#).



If the selected event condition changes before the on or off delay timer expires, the relay output is unaffected.

5-5* Pulse Input

The pulse input parameters are used to define an appropriate window for the impulse reference area by configuring the scaling and filter settings for the pulse inputs. Input terminals 29 or 33 act as frequency reference inputs. Set terminal 29 (par.5-13 [Terminal 29 Digital Input](#)) or terminal 33 (par.5-15 [Terminal 33 Digital Input](#)) to *Pulse input* [32]. If terminal 29 is used as an input, then set par.5-02 [Terminal 29 Mode](#) to *Input* [0].



5-50 Term. 29 Low Frequency

Range:

100 Hz* [0 - 110000 Hz]

Function:

Enter the low frequency limit corresponding to the low motor shaft speed (i.e., low reference value) in par.5-52 [Term. 29 Low Ref./Feedb. Value](#). Refer to the diagram in this section.

5-51 Term. 29 High Frequency

Range:

100 Hz* [0 - 110000 Hz]

Function:

Enter the high frequency limit corresponding to the high motor shaft speed (i.e. high reference value) in par.5-53 [Term. 29 High Ref./Feedb. Value](#).

5-52 Term. 29 Low Ref./Feedb. Value

Range:

0.000 N/ [-999999.999 - 999999.999
A* N/A]

Function:

Enter the low reference value limit for the motor shaft speed [RPM]. This is also the lowest feedback value, see also par.5-57 [Term. 33 Low Ref./Feedb. Value](#).

5-53 Term. 29 High Ref./Feedb. Value

Range:

100.000 [-999999.999 - 999999.999
N/A* N/A]

Function:

Enter the high reference value [RPM] for the motor shaft speed and the high feedback value, see also par.5-58 [Term. 33 High Ref./Feedb. Value](#).

5-54 Pulse Filter Time Constant #29

Range:

100 ms* [1 - 1000 ms]

Function:

Enter the pulse filter time constant. The pulse filter dampens oscillations of the feedback signal, which is an advantage if there is a lot of noise in the system. A high time constant value results in better damping, but also increases the time delay through the filter.
This parameter cannot be adjusted while the motor is running.

5-55 Term. 33 Low Frequency

Range:

100 Hz* [0 - 110000 Hz]

Function:

Enter the low frequency corresponding to the low motor shaft speed (i.e., low reference value) in par.5-57 [Term. 33 Low Ref./Feedb. Value](#).

5-56 Term. 33 High Frequency

Range:	Function:
100 Hz* [0 - 110000 Hz]	Enter the high frequency corresponding to the high motor shaft speed (i.e., high reference value) in par.5-58 Term. 33 High Ref./Feedb. Value .

5-57 Term. 33 Low Ref./Feedb. Value

Range:	Function:
0.000 N/ [-999999.999 - 999999.999 A* N/A]	Enter the low reference value [RPM] for the motor shaft speed. This is also the low feedback value, see also par.5-52 Term. 29 Low Ref./Feedb. Value .

5-58 Term. 33 High Ref./Feedb. Value


Range:	Function:
100.000 [-999999.999 - 999999.999 N/A* N/A]	Enter the high reference value [RPM] for the motor shaft speed. See also par.5-53 Term. 29 High Ref./Feedb. Value .

5-59 Pulse Filter Time Constant #33

Range:	Function:
100 ms* [1 - 1000 ms]	Enter the pulse filter time constant. The low-pass filter reduces the influence on, and dampens oscillations in, the feedback signal from the control. This is an advantage, if, for example, there is a great amount of noise in the system. This parameter cannot be adjusted while the motor is running.

5-6* Pulse Outputs

Parameters for configuring the scaling and output functions of pulse outputs. The pulse outputs are designated for terminals 27 or 29. Select terminal 27 output in par.5-01 [Terminal 27 Mode](#) and terminal 29 output in par. 5-02 [Terminal 29 Mode](#).



Options for readout output variables:



[0]	No operation
[45]	Bus ctrl.
[48]	Bus ctrl., timeout
[100]	Output frequency
[101]	Reference
[102]	Feedback
[103]	Motor current
[104]	Torque relative to limit
[105]	Torque relative to rated
[106]	Power
[107]	Speed
[108]	Torque
[109]	Max Out Freq
[113]	Ext. Closed-loop
[114]	Ext. Closed-loop
[115]	Ext. Closed-loop

Option:	Function:
---------	-----------

5-62 Pulse Output Max Freq #27

This parameter cannot be adjusted while the motor is running.

Range:

Function:

5-63 Terminal 29 Pulse Output Variable

Option: _____ Function: _____

TR200 Programming Guide

5-65 Pulse Output Max Freq #29

This parameter cannot be adjusted while the motor is running.

5000 [0 - 32000 Hz]
Hz*

Option:	Function:
---------	-----------

5-68 Pulse Output Max Freq #X30/6

This parameter is active when option module MCB 101 is mounted in the adjustable frequency drive.

Applica- [0 - 32000 Hz]
tion de-
pend-
ent*

5-9*Bus Controlled

This parameter group selects digital and relay outputs via a serial communication bus setting.

5-90 Digital & Relay Bus Control

Range:

0 N/A* [0 - 2147483647 N/A]

Function:

This parameter holds the state of the digital outputs and relays that is controlled by bus.

A logical '1' indicates that the output is high or active.

A logical '0' indicates that the output is low or inactive.

Bit 0	CC Digital Output Terminal 27
Bit 1	CC Digital Output Terminal 29
Bit 2	GPIO Digital Output Terminal X 30/6
Bit 3	GPIO Digital Output Terminal X 30/7
Bit 4	CC Relay 1 output terminal
Bit 5	CC Relay 2 output terminal
Bit 6	Option B Relay 1 output terminal
Bit 7	Option B Relay 2 output terminal
Bit 8	Option B Relay 3 output terminal
Bit 9-15	Reserved for future terminals
Bit 16	Option C Relay 1 output terminal
Bit 17	Option C Relay 2 output terminal
Bit 18	Option C Relay 3 output terminal
Bit 19	Option C Relay 4 output terminal
Bit 20	Option C Relay 5 output terminal
Bit 21	Option C Relay 6 output terminal
Bit 22	Option C Relay 7 output terminal
Bit 23	Option C Relay 8 output terminal
Bit 24-31	Reserved for future terminals

5-93 Pulse Out #27 Bus Control

Range:

0.00 %* [0.00 - 100.00 %]

Function:

5-94 Pulse Out #27 Timeout Preset

Range:

0.00 %* [0.00 - 100.00 %]

Function:

5-95 Pulse Out #29 Bus Control

Range:

0.00 %* [0.00 - 100.00 %]

Function:

5-96 Pulse Out #29 Timeout Preset

Range:

0.00 %* [0.00 - 100.00 %]

Function:

5-97 Pulse Out #X30/6 Bus Control

Range:

0.00 %* [0.00 - 100.00 %]

Function:

5-98 Pulse Out #X30/6 Timeout Preset

Range:

0.00 %* [0.00 - 100.00 %]

Function:

Main Menu - Analog In/Out - Group 6

6-** Analog In/Out

Parameter group for configuring the analog input and output.

6-0* Analog I/O Mode

Parameter group for setting up the analog I/O configuration.

The adjustable frequency drive is equipped with 2 analog inputs: Terminal 53 and 54. The analog inputs can freely be allocated to either voltage (0–10 V) or current input (0/4–20 mA)

NOTE

Thermistors may be connected to either an analog or a digital input.

6-00 Live Zero Timeout Time

Range:

10 s* [1 - 99 s]

Function:

Enter the Live Zero Timeout time period. Live Zero Timeout Time is active for analog inputs, i.e., terminal 53 or terminal 54, used as reference or feedback sources. If the reference signal value associated with the selected current input falls below 50% of the value set in par.6-10 [Terminal 53 Low Voltage](#), par.6-12 [Terminal 53 Low Current](#), par.6-20 [Terminal 54 Low Voltage](#) or par.6-22 [Terminal 54 Low Current](#) for a time period longer than the time set in par.6-00 [Live Zero Timeout Time](#), the function selected in par.6-01 [Live Zero Timeout Function](#) will be activated.

6-01 Live Zero Timeout Function

Option:

Function:

Select the timeout function. The function set in par.6-01 [Live Zero Timeout Function](#) will be activated if the input signal on terminal 53 or 54 is below 50% of the value in par.6-10 [Terminal 53 Low Voltage](#), par.6-12 [Terminal 53 Low Current](#), par.6-20 [Terminal 54 Low Voltage](#) or par.6-22 [Terminal 54 Low Current](#) for a time period defined in par.6-00 [Live Zero Timeout Time](#). If several timeouts occur simultaneously, the adjustable frequency drive prioritizes the timeout functions as follows:

1. par.6-01 [Live Zero Timeout Function](#)
2. par.8-04 [Control Timeout Function](#)

The output frequency of the adjustable frequency drive can be:

- [1] frozen at the present value
- [2] overruled to stop
- [3] overruled to jog speed
- [4] overruled to max. speed
- [5] overruled to stop with subsequent trip


[0] * Off

[1] Freeze output

[2] Stop

[3] Jogging

- [4] Max. speed
- [5] Stop and trip



6-02 Fire Mode Live Zero Timeout Function

Option:

Function:

The function set in par.6-01 [Live Zero Timeout Function](#) will be activated if the input signal on analog inputs is below 50% of the value defined in parameter group 6-1* to 6-6* "Terminal xx Low Current" or "Terminal xx Low Voltage" for a time period defined in par.6-00 [Live Zero Timeout Time](#).

- [0] * Off
- [1] Freeze output
- [2] Stop
- [3] Jogging
- [4] Max. speed

6-1* Analog Input 1

Parameters for configuring the scaling and limits for analog input 1 (terminal 53).

6-10 Terminal 53 Low Voltage

Range:

Function:

0.07 V* [Application dependant]

Enter the low voltage value. This analog input scaling value should correspond to the low reference/feedback value set in par.6-14 [Terminal 53 Low Ref./Feedb. Value](#).

6-11 Terminal 53 High Voltage

Range:

Function:

10.00 V* [Application dependant]

Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in par.6-15 [Terminal 53 High Ref./Feedb. Value](#).

6-12 Terminal 53 Low Current

Range:

Function:

4.00 mA* [Application dependant]

Enter the low current value. This reference signal should correspond to the low reference/feedback value, set in par.6-14 [Terminal 53 Low Ref./Feedb. Value](#). The value must be set at >2 mA in order to activate the Live Zero Timeout Function in par.6-01 [Live Zero Timeout Function](#).

6-13 Terminal 53 High Current

Range:	Function:
20.00 [Application dependant] mA*	Enter the high current value corresponding to the high reference/feed-back set in par.6-15 Terminal 53 High Ref./Feedb. Value .

6-14 Terminal 53 Low Ref./Feedb. Value

Range:	Function:
0.000 N/ [-999999.999 - 999999.999] A* N/A]	Enter the analog input scaling value that corresponds to the low voltage/low current set in par.6-10 Terminal 53 Low Voltage and par.6-12 Terminal 53 Low Current .

6-15 Terminal 53 High Ref./Feedb. Value

Range:	Function:
Applica- [-999999.999 - 999999.999] tion de- N/A] pend- ent*	Enter the analog input scaling value that corresponds to the high voltage/high current value set in par.6-11 Terminal 53 High Voltage and par.6-13 Terminal 53 High Current .

6-16 Terminal 53 Filter Time Constant

Range:	Function:
0.001 s* [0.001 - 10.000 s]	Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal 53. A high time constant value improves dampening but also increases the time delay through the filter. This parameter cannot be adjusted while the motor is running.

6-17 Terminal 53 Live Zero

Option:	Function:
	This parameter makes it possible to disable the Live Zero monitoring. For example, this is to be used if the analog outputs are used as part of a decentral I/O system (e.g., when not used as part of any adjustable frequency drive related control functions, but for feeding a building management system with data).
[0] Disabled	
[1] * Enabled	

6-2* Analog Input 2

Parameters for configuring the scaling and limits for analog input 2 (terminal 54).

6-20 Terminal 54 Low Voltage

Range:	Function:
0.07 V* [Application dependant]	Enter the low voltage value. This analog input scaling value should correspond to the low reference/feedback value, set in par.6-24 Terminal 54 Low Ref./Feedb. Value .

6-21 Terminal 54 High Voltage

Range:	Function:
10.00 V* [Application dependant]	Enter the high voltage value. This analog input scaling value should correspond to the high reference/feedback value set in par.6-25 Terminal 54 High Ref./Feedb. Value .

6-22 Terminal 54 Low Current

Range:	Function:
4.00 [Application dependant] mA*	Enter the low current value. This reference signal should correspond to the low reference/feedback value, set in par.6-24 Terminal 54 Low Ref./Feedb. Value . The value must be set at >2 mA in order to activate the Live Zero Timeout Function in par.6-01 Live Zero Timeout Function .

6-23 Terminal 54 High Current

Range:	Function:
20.00 [Application dependant] mA*	Enter the high current value corresponding to the high reference/feedback value set in par.6-25 Terminal 54 High Ref./Feedb. Value .

6-24 Terminal 54 Low Ref./Feedb. Value

Range:	Function:
0.000 N/ [-999999.999 - 999999.999 A* N/A]	Enter the analog input scaling value that corresponds to the low voltage/low current value set in par.6-20 Terminal 54 Low Voltage and par.6-22 Terminal 54 Low Current .

6-25 Terminal 54 High Ref./Feedb. Value

Range:	Function:
100.000 [-999999.999 - 999999.999 N/A* N/A]	Enter the analog input scaling value that corresponds to the high voltage/high current value set in par.6-21 Terminal 54 High Voltage and par.6-23 Terminal 54 High Current .

6-26 Terminal 54 Filter Time Constant

Range:	Function:
0.001 s* [0.001 - 10.000 s]	Enter the time constant. This is a first-order digital low pass filter time constant for suppressing electrical noise in terminal 54. A high time constant value improves dampening but also increases the time delay through the filter. This parameter cannot be adjusted while the motor is running.

6-27 Terminal 54 Live Zero

Option:	Function:
	This parameter makes it possible to disable the Live Zero monitoring. For example, this to be used if the analog outputs are used as part of a decentral I/O system (e.g., when used not as part of any adjustable frequency drive related control functions, but for feeding a building management system with data).
[0] Disabled	
[1] * Enabled	

6-3* Analog Input 3 MCB 101

Parameter group for configuring the scale and limits for analog input 3 (X30/11) placed on option module MCB 101.

6-30 Terminal X30/11 Low Voltage

Range:

Function:

0.07 V* [Application dependant]

Sets the analog input scaling value to correspond to the low reference/feedback value (set in par.6-34 [Term. X30/11 Low Ref./Feedb. Value](#)).

6-31 Terminal X30/11 High Voltage

Range:

Function:

10.00 V* [Application dependant]

Sets the analog input scaling value to correspond to the high reference/feedback value (set in par.6-35 [Term. X30/11 High Ref./Feedb. Value](#)).

6-34 Term. X30/11 Low Ref./Feedb. Value

Range:

Function:

0.000 N/ [-999999.999 - 999999.999
A* N/A]

Sets the analog input scaling value to correspond to the low voltage value (set in par.6-30 [Terminal X30/11 Low Voltage](#)).

6-35 Term. X30/11 High Ref./Feedb. Value

Range:

Function:

100.000 [-999999.999 - 999999.999
N/A* N/A]

Sets the analog input scaling value to correspond to the high voltage value (set in par.6-31 [Terminal X30/11 High Voltage](#)).

6-36 Term. X30/11 Filter Time Constant

Range:

Function:

0.001 s* [0.001 - 10.000 s]

A 1st order digital low pass filter time constant for suppressing electrical noise on terminal X30/11.
par.6-36 [Term. X30/11 Filter Time Constant](#) cannot be changed while the motor is running.

6-37 Term. X30/11 Live Zero

Option:

Function:

This parameter makes it possible to disable Live Zero monitoring. For example, this may be used if the analog outputs are used as part of a decentral I/O system (e.g., when not part of any adjustable frequency drive-related control functions, but feeding a building management system with data).

[0] * Disabled

[1] * Enabled

6-4* Analog Input 4 MCB 101

Parameter group for configuring the scale and limits for analog input 4 (X30/12) placed on option module MCB 101.

6-40 Terminal X30/12 Low Voltage

Range:	Function:
0.07 V* [Application dependant]	Sets the analog input scaling value to correspond to the low reference/feedback value set in par.6-44 Term. X30/12 Low Ref./Feedb. Value .

6-41 Terminal X30/12 High Voltage

Range:	Function:
10.00 V* [Application dependant]	Sets the analog input scaling value to correspond to the high reference/feedback value set in par.6-45 Term. X30/12 High Ref./Feedb. Value .

6-44 Term. X30/12 Low Ref./Feedb. Value

Range:	Function:
0.000 N/ [-999999.999 - 999999.999 A* N/A]	Sets the analog output scaling value to correspond to the low voltage value set in par.6-40 Terminal X30/12 Low Voltage .

6-45 Term. X30/12 High Ref./Feedb. Value

Range:	Function:
100.000 [-999999.999 - 999999.999 N/A* N/A]	Sets the analog input scaling value to correspond to the high voltage value set in par.6-41 Terminal X30/12 High Voltage .

6-46 Term. X30/12 Filter Time Constant

Range:	Function:
0.001 s* [0.001 - 10.000 s]	A 1 st order digital low pass filter time constant for suppressing electrical noise on terminal X30/12. par.6-46 Term. X30/12 Filter Time Constant cannot be changed while the motor is running.

6-47 Term. X30/12 Live Zero

Option:	Function:
	This parameter makes it possible to disable Live Zero monitoring. For example, this may be used if the analog outputs are used as part of a decentral I/O system (e.g., when not part of any adjustable frequency drive-related control functions, but feeding a building management system with data).

[0] * Disabled

[1] * Enabled

6-5* Analog Output 1

Parameters for configuring the scaling and limits for analog output 1, i.e., Terminal 42. Analog outputs are current outputs: 0/4–20 mA. Common terminal (terminal 39) is the same terminal and has the same electrical potential for analog common and digital common connection. Resolution on analog output is 12 bit.

6-50 Terminal 42 Output

Option:

Function:

Select the function of Terminal 42 as an analog current output. A motor current of 20 mA corresponds to I_{max} .

[0] *	No operation	
[100]	Output freq. 0-100	: 0–100 Hz, (0–20 mA)
[101]	Reference Min-Max	: Minimum reference - Maximum reference, (0–20 mA)
[102]	Feedback +-200%	: -200% to +200% of par.20-14 Maximum Reference/Feedb. , (0–20 mA)
[103]	Motor cur. 0-Imax	: 0 - Inverter Max. Current (par.16-37 Inv. Max. Current), (0–20 mA)
[104]	Torque 0-Tlim	: 0 - Torque limit (par.4-16 Torque Limit Motor Mode), (0–20 mA)
[105]	Torque 0-Tnom	: 0 - Motor rated torque, (0–20 mA)
[106]	Power 0-Pnom	: 0 - Motor rated power, (0–20 mA)
[107] *	Speed 0-HighLim	: 0 - Speed High Limit (par.4-13 Motor Speed High Limit [RPM] and par. 4-14 Motor Speed High Limit [Hz]), (0–20 mA)
[113]	Ext. Closed-loop 1	: 0–100%, (0–20 mA)
[114]	Ext. Closed-loop 2	: 0–100%, (0–20 mA)
[115]	Ext. Closed-loop 3	: 0–100%, (0–20 mA)
[130]	Out fr 0-100 4-20	: 0–100 Hz
[131]	Reference 4-20mA	: Minimum Reference - Maximum Reference
[132]	Feedback 4-20mA	: -200% to +200% of par.20-14 Maximum Reference/Feedb.
[133]	Motor cur. 4-20mA	: 0 - Inverter Max. Current (par.16-37 Inv. Max. Current)
[134]	Torq.0-lim 4-20mA	: 0 - Torque limit (par.4-16 Torque Limit Motor Mode)
[135]	Torq.0-nom 4-20mA	: 0 - Motor rated torque
[136]	Power 4-20mA	: 0 - Motor rated power
[137]	Speed 4-20mA	: 0 - Speed High Limit (4-13 and 4-14)
[139]	Bus ctrl.	: 0–100%, (0–20 mA)
[140]	Bus ctrl. 4-20 mA	: 0 - 100%
[141]	Bus ctrl t.o.	: 0–100%, (0–20 mA)
[142]	Bus ctrl 4-20mA t.o.	: 0 - 100%
[143]	Ext. CL 1 4-20 mA	: 0 - 100%
[144]	Ext. CL 2 4-20 mA	: 0 - 100%
[145]	Ext. CL 3 4-20 mA	: 0 - 100%




6-51 Terminal 42 Output Min Scale

0.00 %* [0.00 - 200.00 %]

100.00 [0.00 - 200.00 %]

%*

Output signal 20 mA is needed at 50 Hz (50% of range) - set par.6-52 [Terminal 42 Output Max Scale](#) to 50%




EXAMPLE 3:

Variable value= REFERENCE, range= Min ref - Max ref

Range needed for output= Min ref (0%) - Max ref (100%), 0–10 mA

Output signal 0 or 4 mA is needed at Min ref - set par.6-51 [Terminal 42 Output Min Scale](#) to 0%

Output signal 10 mA is needed at Max ref (100% of range) - set par.6-52 [Terminal 42 Output Max Scale](#) to 200% (20 mA / 10 mA x 100%=200%).



6-53 Terminal 42 Output Bus Control

Range:

Function:

0.00 %* [0.00 - 100.00 %]

6-54 Terminal 42 Output Timeout Preset

Range:

Function:

0.00 %* [0.00 - 100.00 %]

6-6* Analog Output 2 MCB 101

Analog outputs are current outputs: 0/4–20 mA. Common terminal (terminal X30/8) is the same terminal and electrical potential for analog common connection. Resolution on analog output is 12 bit.

6-60 Terminal X30/8 Output

6-60 Terminal X30/8 Output

Option:

Function:

[0] * No operation

[100] Output freq. 0-100

[101] Reference Min-Max

[102] Feedback +-200%

[103] Motor cur. 0-I_{max}

[104] Torque 0-T_{lim}

[105] Torque 0-T_{nom}

[106] Power 0-P_{nom}

[107] Speed 0-HighLim

[113] Ext. Closed-loop 1

[114] Ext. Closed-loop 2

[115] Ext. Closed-loop 3

[130] Out fr 0-100 4-20

Parameter Description

[131]	Reference 4-20mA
[132]	Feedback 4-20mA
[133]	Motor cur. 4-20mA
[134]	Torq.0-lim 4-20mA
[135]	Torq.0-nom 4-20mA
[136]	Power 4-20mA
[137]	Speed 4-20mA
[139]	Bus ctrl.
[140]	Bus ctrl. 4-20 mA
[141]	Bus ctrl t.o.
[142]	Bus ctrl 4-20mA t.o.
[143]	Ext. CL 1 4-20 mA
[144]	Ext. CL 2 4-20 mA
[145]	Ext. CL 3 4-20 mA

6-61 Terminal X30/8 Min. Scale

Range: Function:

0.00 %* [0.00 - 200.00 %]

6-62 Terminal X30/8 Max. Scale

Range: Function:

100.00 [0.00 - 200.00 %]
%*

6-63 Terminal X30/8 Output Bus Control

Range: Function:

0.00 %* [0.00 - 100.00 %]

6-64 Terminal X30/8 Output Timeout Preset

Range: Function:

0.00 %* [0.00 - 100.00 %]

Main Menu - Communications and Options - Group 8

8-** Comm. and Options

Parameter group for configuring communications and options.

8-0* General Settings

General settings for communications and options.

8-01 Control Site

Option: Function:

The setting in this parameter overrides the settings in par.8-50 [Coasting Select](#) to par.8-56 [Preset Reference Select](#).

[0] *	Digital and ctrl. word	Control by using both digital input and control word.
[1]	Digital only	Control by using digital inputs only.

[2] Control word only Control by using control word only.

8-02 Control Source

Option:

Function:

Select the source of the control word: one of two serial interfaces or four installed options. During initial power-up, the adjustable frequency drive automatically sets this parameter to *Option A* [3] if it detects a valid serial communication bus option installed in slot A. If the option is removed, the adjustable frequency drive detects a change in the configuration, sets par.8-02 [Control Source](#) back to default setting *Adjustable Frequency Drive Port*, and the adjustable frequency drive then trips. If an option is installed after initial power-up, the setting of par.8-02 [Control Source](#) will not change but the adjustable frequency drive will trip and display: Alarm 67 *Option Changed*.

[0] None

[1] FC RS-485

[2] FC USB

[3] * Option A

[4] Option B

[5] Option C0

[6] Option C1

[30] External Can

NOTE: This parameter cannot be adjusted while the motor is running.

8-03 Control Timeout Time

Range:

Function:

Applica- [1.0 - 18000.0 s]
tion de-
pend-
ent*

Enter the maximum time expected to pass between the reception of two consecutive messages. If this time is exceeded, it indicates that the serial communication has stopped. The function selected in par.8-04 [Control Timeout Function](#) *Control Timeout Function* will then be carried out.

In LonWorks, the following variables will trigger the Control Word Time parameter:

nviStartStop
nviReset Fault
nviControlWord
nviDrvSpeedStpt
nviRefPcnt
nviRefHz

8-04 Control Timeout Function

Option:

Function:

Select the timeout function. The timeout function is activated when the control word fails to be updated within the time period specified in par. 8-03 [Control Timeout Time](#). Choice [20] only appears after setting the Metasys N2 protocol.

[0] * Off

Parameter Description

[1]	Freeze output
[2]	Stop
[3]	Jogging
[4]	Max. speed
[5]	Stop and trip
[7]	Select setup 1
[8]	Select setup 2
[9]	Select setup 3
[10]	Select setup 4
[20]	N2 Override Release

In LonWorks, the timeout function is also activated when the following SNVTs fail to be updated within the time period specified in par.8-03 [Control Timeout Time](#):

nviStartStop	nviDrvSpeedStpt
nviReset Fault	nviRefPcnt
nviControlWord	nviRefHz

8-05 End-of-Timeout Function

Option:	Function:
	Select the action after receiving a valid control word following a timeout. This parameter is active only when par.8-04 Control Timeout Function is set to [Set-up 1-4].
[0] Hold set-up	Retains the set-up selected in par.8-04 Control Timeout Function and displays a warning, until par.8-06 Reset Control Timeout toggles. Then the adjustable frequency drive resumes its original set-up.
[1] * Resume set-up	Resumes the set-up active prior to the timeout.

8-06 Reset Control Timeout

Option:	Function:
	This parameter is active only when the choice <i>Hold set-up</i> [0] has been selected in par.8-05 End-of-Timeout Function .
[0] * Do not reset	Retains the set-up specified in par.8-04 Control Timeout Function , [Select set-up 1-4] following a control timeout.
[1] Do reset	Returns the adjustable frequency drive to the original set-up following a control word timeout. When the value is set to <i>Do reset</i> [1], the adjustable frequency drive performs the reset and then immediately reverts to the <i>Do not reset</i> [0] setting.

8-07 Diagnosis Trigger

Option:	Function:
	This parameter has no function for LonWorks.
[0] * Disable	
[1] Trigger on alarms	
[2] Trigger alarm/warn.	

8-1* Ctrl. Word Settings

Parameters for configuring the option control word profile.

8-10 Control Profile

Option:	Function:
	Select the interpretation of the control and status words corresponding to the installed serial communication bus. Only the selections valid for the serial communication bus installed in slot A will be visible in the keypad display.
[0] * FC profile	
[1] PROFIdrive profile	
[5] ODVA	
[7] CANopen DSP 402	

8-13 Configurable Status Word STW

Option:	Function:
	This parameter enables configuration of bits 12 – 15 in the status word.
[0] No function	
[1] * Profile Default	Function corresponds to the profile default selected in par.8-10 Control Profile .
[2] Alarm 68 Only	Only set in the event of Alarm 68.
[3] Trip excl Alarm 68	Set in the event of a trip, except if the trip is executed by Alarm 68.
[16] T37 DI status	The bit indicates the status of terminal 37. "0" indicates T37 is low (safe stop) "1" indicates T37 is high (normal)

8-3* Adjustable Frequency Drive Port Settings

Parameters for configuring the Adjustable Frequency Drive Port.

8-30 Protocol

Option:	Function:
	Protocol selection for the integrated FC (standard) Port (RS485) on the control card. Parameter group 8-7* is only visible when Adjustable Frequency Drive Option [9] is chosen.
[0] * FC	Communication according to the FC protocol as described in the TR200 <i>Design Guide, RS 485 Installation and Set-up</i> .
[1] FC MC	Same as FC [0] but to be used when downloading SW to the adjustable frequency drive or uploading dll file (covering information regarding parameters available in the adjustable frequency drive and their inter-dependencies) to Trane Drive Utility, TDU.
[2] Modbus RTU	Communication according to the Modbus RTU protocol as described in the TR200 <i>Design Guide, RS 485 Installation and Set-up</i> .
[3] Metasys N2	Communication protocol. The N2 software protocol is designed to be general in nature in order to accommodate the unique properties each

device may have. Please see separate manual *TR200 MetasysMG. 12.NX.YY.*

[4] FLN

[9] FC Option

To be used when a gateway is connected to the integrated RS 485 port, e.g., the BACnet gateway.
The following changes will take place:
-The address for the adjustable frequency drive port will be set to 1 and par.8-31 [Address](#), is now used to set the address for the gateway on the network, e.g., BACnet.
-Baud rate for the Drive port will be set to a fixed value (115,200 Baud) and par.8-32 [Baud Rate](#) is now used to set the baud rate for the network port (e.g., BACnet) on the gateway.

[20] LEN

NOTE: Further details can be found in the Metasys manual.

8-31 Address

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

8-33 Parity / Stop Bits

Option:

Function:

Parity and Stop Bits for the protocol par.8-30 [Protocol](#) using the Adjustable Frequency Drive Port. For some of the protocols, not all options will be visible. Default depends on the protocol selected.

[0] * Even Parity, 1 Stop Bit

[1] Odd Parity, 1 Stop Bit

[2] No Parity, 1 Stop Bit

[3] No Parity, 2 Stop Bits

8-35 Minimum Response Delay

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

8-36 Maximum Response Delay

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

Range: _____ Function: _____

Applica- [Application dependant]
tion de-
pend-
ent*

Option:	Function:
1. Option 1: <i>Standard</i> 2. Option 2: <i>Standard</i> 3. Option 3: <i>Standard</i> 4. Option 4: <i>Standard</i> 5. Option 5: <i>Standard</i> 6. Option 6: <i>Standard</i> 7. Option 7: <i>Standard</i> 8. Option 8: <i>Standard</i> 9. Option 9: <i>Standard</i> 10. Option 10: <i>Standard</i>	1. Function 1: <i>Standard</i> 2. Function 2: <i>Standard</i> 3. Function 3: <i>Standard</i> 4. Function 4: <i>Standard</i> 5. Function 5: <i>Standard</i> 6. Function 6: <i>Standard</i> 7. Function 7: <i>Standard</i> 8. Function 8: <i>Standard</i> 9. Function 9: <i>Standard</i> 10. Function 10: <i>Standard</i>

Enables use of freely configurable messages or standard messages for the adjustable frequency drive port.

- | | |
|-------|---------------------|
| [1] * | Standard telegram 1 |
| [101] | PPO 1 |
| [102] | PPO 2 |
| [103] | PPO 3 |
| [104] | PPO 4 |
| [105] | PPO 5 |
| [106] | PPO 6 |
| [107] | PPO 7 |
| [108] | PPO 8 |
| [200] | Custom telegram 1 |

Parameters for configuring the control word Digital/Bus merging.

Option: _____ Function: _____

Select control of the coasting function via the terminals (digital input) and/or via the bus.

- | | | |
|-------|---------------|---|
| [0] | Digital input | Activates Start command via a digital input. |
| [1] | Bus | Activates Start command via the serial communication port or serial communication option. |
| [2] | Logic AND | Activates Start command via the serial communication bus/serial communication port, AND additionally via one of the digital inputs. |
| [3] * | Logic OR | Activates Start command via the serial communication bus/serial communication port OR via one of the digital inputs. |

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

Option: _____ Function: _____

Select control of the DC brake via the terminals (digital input) and/or via the serial communication bus.

- | | | |
|-----|---------------|--|
| [0] | Digital input | Activates Start command via a digital input. |
|-----|---------------|--|

[1]	Bus	Activates Start command via the serial communication port or serial communication option.
[2]	Logic AND	Activates Start command via the serial communication bus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR	Activates Start command via the serial communication bus/serial communication port OR via one of the digital inputs.

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

8-53 Start Select

Option:	Function:
	Select control of the adjustable frequency drive start function via the terminals (digital input) and/or via the serial communication bus.
[0]	Digital input Activates Start command via a digital input.
[1]	Bus Activates Start command via the serial communication port or serial communication option.
[2]	Logic AND Activates Start command via the serial communication bus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR Activates Start command via the serial communication bus/serial communication port OR via one of the digital inputs.

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

8-54 Reverse Select

Option:	Function:
	Select control of the adjustable frequency drive reverse function via the terminals (digital input) and/or via the serial communication bus.
[0] *	Digital input Activates Reverse command via a digital input.
[1]	Bus Activates Reverse command via the serial communication port or serial communication option.
[2]	Logic AND Activates Reverse command via the serial communication bus/serial communication port, AND additionally via one of the digital inputs.
[3]	Logic OR Activates Reverse command via the serial communication bus/serial communication port OR via one of the digital inputs.

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

8-55 Set-up Select

Option:	Function:
	Select control of the adjustable frequency drive set-up selection via the terminals (digital input) and/or via the serial communication bus.
[0]	Digital input Activates the set-up selection via a digital input.
[1]	Bus Activates the set-up selection via the serial communication port or serial communication option.

[2]	Logic AND	Activates the set-up selection via the serial communication bus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR	Activate the set-up selection via the serial communication bus/serial communication port OR via one of the digital inputs.

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

8-56 Preset Reference Select

Option:	Function:
	Select control of the adjustable frequency drive Preset Reference selection via the terminals (digital input) and/or via the serial communication bus.
[0]	Digital input Activates Preset Reference selection via a digital input.
[1]	Bus Activates Preset Reference selection via the serial communication port or serial communication option.
[2]	Logic AND Activates Preset Reference selection via the serial communication bus/serial communication port, AND additionally via one of the digital inputs.
[3] *	Logic OR Activates the Preset Reference selection via the serial communication bus/serial communication port OR via one of the digital inputs.

NOTE: This parameter is active only when par.8-01 [Control Site](#) is set to [0] *Digital and control word*.

8-7* BACnet

BACnet configuration

8-70 BACnet Device Instance

Range:	Function:
1 N/A* [0 - 4194304 N/A]	Enter a unique ID number for the BACnet device.

NOTE: This parameter is active only when par.8-30 [Protocol](#) is set to [9] *Drive Option*.

8-72 MS/TP Max Masters

Range:	Function:
127 N/A* [0 - 127 N/A]	Define the address of the master which holds the highest address in this network. Decreasing this value optimizes polling for the token.

NOTE: This parameter is active only when par.8-30 [Protocol](#) is set to [9] *Option*.

8-73 MS/TP Max Info Frames

Range:	Function:
1 N/A* [1 - 65534 N/A]	Define how many info/data frames the device is allowed to send while holding the token.

NOTE: This parameter is active only when par.8-30 [Protocol](#) is set to [9] *Option*.

8-74 "I-Am" Service

Option:	Function:
[0] *	Send at power-up



Parameter Description

[1]	Continuously	Choose whether the device should send the "I-Am" service message only at power-up or continuously with an interval of approx. 1 min.
-----	--------------	--

NOTE: This parameter is active only when par.8-30 [Protocol](#) is set to [9] *Option*.

8-75 Initialization Password

Range:	Function:
Application de- pend- ent* [0 - 0 N/A]	Enter the password needed for execution of Drive Re-initialization from BACnet.

NOTE: This parameter is active only when par.8-30 [Protocol](#) is set to [9] *Drive Option*.

8-8* Adjustable Frequency Drive Port Diagnostics

These parameters are used for monitoring the bus communication via the Adjustable Frequency Drive Port.

8-80 Bus Message Count

Range:	Function:
0 N/A* [0 - 0 N/A]	This parameter shows the number of valid messages detected on the bus.

8-81 Bus Error Count

Range:	Function:
0 N/A* [0 - 0 N/A]	This parameter shows the number of messages with faults (e.g., CRC fault), detected on the bus.

8-82 Slave Messages Rcvd

Range:	Function:
0 N/A* [0 - 0 N/A]	This parameter shows the number of valid messages addressed to the slave, sent by the adjustable frequency drive.

8-83 Slave Error Count

Range:	Function:
0 N/A* [0 - 0 N/A]	This parameter shows the number of error messages, which could not be executed by the adjustable frequency drive.

8-84 Slave Messages Sent

Range:	Function:
0 N/A* [0 - 0 N/A]	

8-85 Slave Timeout Errors

Range:	Function:
0 N/A* [0 - 0 N/A]	

8-9* Bus Jog

Parameters for configuring the Bus Jog.

8-90 Bus Jog 1 Speed

Range:	Function:
100 [Application dependant] RPM*	Enter the jog speed. This is a fixed jog speed activated via the serial port or serial communication bus option.

8-91 Bus Jog 2 Speed

Range:	Function:
200 [Application dependant] RPM*	Enter the jog speed. This is a fixed jog speed activated via the serial port or serial communication bus option.

8-94 Bus Feedback 1

Range:	Function:
0 N/A* [-200 - 200 N/A]	Write a feedback to this parameter via the serial communication port or serial communication bus option. This parameter must be selected in par.20-00 Feedback 1 Source , par.20-03 Feedback 2 Source or par. 20-06 Feedback 3 Source as a feedback source.

8-95 Bus Feedback 2

Range:	Function:
0 N/A* [-200 - 200 N/A]	See par.8-94 Bus Feedback 1 for further details.

8-96 Bus Feedback 3

Range:	Function:
0 N/A* [-200 - 200 N/A]	See par.8-94 Bus Feedback 1 for further details.



Main Menu - LonWorks - Group 11

LonWorks, 11-**

Parameter group for all LonWorks specific parameters.
Parameters related to LonWorks ID.

11-00 Neuron ID

Range:	Function:
0 N/A* [0 - 0 N/A]	View the Neuron chip's unique Neuron ID number.

11-01 Domain

Range:	Function:
0 N/A* [0 - 0 N/A]	

11-02 Subnet ID

Range:	Function:
0 N/A* [0 - 255 N/A]	

11-03 Node ID

Range:	Function:
0 N/A* [0 - 255 N/A]	

11-10 Drive Profile

Option:	Function:
	This parameter allows selecting between LONMARK Functional Profiles.
[0] * VSD profile	The Trane Profile and the Node Object are common for all profiles.
[1] Pump controller	

11-15 LON Warning Word

Range:	Function:
0 N/A* [0 - 65535 N/A]	This parameter contains the LON specific warnings.

Bit	Status
0	Internal fault
1	Internal fault
2	Internal fault
3	Internal fault
4	Internal fault
5	Invalid type change for nvoAnIn1
6	Invalid type change for nvoAnIn2
7	Invalid type change for nvo109AnIn1
8	Invalid type change for nvo109AnIn2
9	Invalid type change for nvo109AnIn3
10	Initialization error
11	Internal communication error
12	Software revision mismatch
13	Bus not active
14	Option not present
15	LON input (nvi/nci) exceeds limits

11-17 XIF Revision

Range:

0 N/A* [0 - 0 N/A]

Function:

This parameter contains the version of the external interface file on the Neuron C chip on the LON option.

11-18 LonWorks Revision

Range:

0 N/A* [0 - 0 N/A]

Function:

This parameter contains the software version of the application program on the Neuron C chip on the LON option.

11-21 Store Data Values

Option:

[0] * Off

[2] Store all set-ups

Function:

This parameter is used to activate storing of data in non-volatile memory.

Store function is inactive.


Stores all parameter values in the E²PROM. The value returns to *Off* when all parameter values have been stored.

Main Menu - Smart Logic - Group 13

13-** Prog. Features Prog. Features

Smart Logic Control (SLC) is essentially a sequence of user defined actions (see par.13-52 [SL Controller Action](#) [x]) executed by the SLC when the associated user defined *event* (see par.13-51 [SL Controller Event](#) [x]) is evaluated as TRUE by the SLC. Events and *actions* are each numbered and linked together in pairs. This means that when *event* [0] is fulfilled (attains the value TRUE), *action* [0] is executed. After this, the conditions of *event* [1] will be evaluated and if evaluated TRUE, *action* [1] will be executed and so on. Only one *event* will be evaluated at any time. If an *event* is evaluated as FALSE, nothing happens (in the SLC) during the current scan interval and no other *events* will be evaluated. This means that when the SLC starts, it evaluates *event* [0] (and only *event* [0]) each scan interval. Only when *event* [0] is evaluated TRUE, will the SLC execute *action* [0] and start evaluating *event* [1]. It is possible to program from 1 to 20 *events* and *actions*.

When the last *event* / *action* has been executed, the sequence starts over again from *event* [0] / *action* [0]. The figure shows an example with three events/actions:



Starting and stopping the SLC:

Starting and stopping the SLC can be done by selecting *On* [1] or *Off* [0] in par.13-00 [SL Controller Mode](#). The SLC always starts in state 0 (where it evaluates *event* [0]). The SLC starts when the start event (defined in par. 13-01 [Start Event](#)) is evaluated as TRUE (provided that *On* [1] is selected in par.13-00 [SL Controller Mode](#)). The SLC stops when the *Stop Event* (par.13-02 [Stop Event](#)) is TRUE. par.13-03 [Reset SLC](#) resets all SLC parameters and starts programming from scratch.

13-0* SLC Settings

Use the SLC settings to activate, deactivate and reset the Smart Logic Control.

13-00 SL Controller Mode

Option:	Function:
[0] * Off	Disables the Smart Logic Controller.
[1] On	Enables the Smart Logic Controller.

13-01 Start Event

Option:		Function:
		Select the Boolean (TRUE or FALSE) input to activate Smart Logic Control.
[0] *	FALSE	Enters the fixed value of FALSE in the logic rule.
[1]	TRUE	Enters the fixed value TRUE in the logic rule.
[2]	Running	See parameter group 5-3* for further description.
[3]	In range	See parameter group 5-3* for further description.
[4]	On reference	See parameter group 5-3* for further description.
[5]	Torque limit	See parameter group 5-3* for further description.
[6]	Current limit	See parameter group 5-3* for further description.
[7]	Out of current range	See parameter group 5-3* for further description.
[8]	Below I low	See parameter group 5-3* for further description.
[9]	Above I high	See parameter group 5-3* for further description.
[10]	Out of speed range	
[11]	Below speed low	See parameter group 5-3* for further description.
[12]	Above speed high	See parameter group 5-3* for further description.
[13]	Out of feedb. range	
[14]	Below feedb. low	
[15]	Above feedb. high	
[16]	Thermal warning	See parameter group 5-3* for further description.
[17]	Mains out of range	See parameter group 5-3* for further description.
[18]	Reverse	See parameter group 5-3* for further description.
[19]	Warning	See parameter group 5-3* for further description.
[20]	Alarm (trip)	See parameter group 5-3* for further description.
[21]	Alarm (trip lock)	See parameter group 5-3* for further description.
[22]	Comparator 0	Use the result of comparator 0 in the logic rule.
[23]	Comparator 1	Use the result of comparator 1 in the logic rule.
[24]	Comparator 2	Use the result of comparator 2 in the logic rule.
[25]	Comparator 3	Use the result of comparator 3 in the logic rule.
[26]	Logic rule 0	Use the result of logic rule 0 in the logic rule.
[27]	Logic rule 1	Use the result of logic rule 1 in the logic rule.
[28]	Logic rule 2	Use the result of logic rule 2 in the logic rule.
[29]	Logic rule 3	Use the result of logic rule 3 in the logic rule.
[33]	Digital input DI18	Use the value of DI18 in the logic rule (High = TRUE).

Parameter Description

[34]	Digital input DI19	Use the value of DI19 in the logic rule (High = TRUE).
[35]	Digital input DI27	Use the value of DI27 in the logic rule (High = TRUE).
[36]	Digital input DI29	Use the value of DI29 in the logic rule (High = TRUE).
[37]	Digital input DI32	Use the value of DI32 in the logic rule (High = TRUE).
[38]	Digital input DI33	Use the value of DI33 in the logic rule (High = TRUE).
[39]	Start command	This event is TRUE if the adjustable frequency drive is started by any means (either via digital input, serial communication bus or other).
[40]	Drive stopped	This event is TRUE if the adjustable frequency drive is stopped or coasted by any means (either via digital input, serial communication bus or other).
[41]	Reset Trip	This event is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and the reset button is pressed.
[42]	Auto Reset Trip	This event is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and an automatic reset is issued.
[43]	OK Key	This event is TRUE if the OK key on the keypad is pressed.
[44]	Reset Key	This event is TRUE if the Reset key on the keypad is pressed.
[45]	Left Key	This event is TRUE if the Left key on the keypad is pressed.
[46]	Right Key	This event is TRUE if the Right key on the keypad is pressed.
[47]	Up Key	This event is TRUE if the Up key on the keypad is pressed.
[48]	Down Key	This event is TRUE if the Down key on the keypad is pressed.
[50]	Comparator 4	Use the result of comparator 4 in the logic rule.
[51]	Comparator 5	Use the result of comparator 5 in the logic rule.
[60]	Logic rule 4	Use the result of logic rule 4 in the logic rule.
[61]	Logic rule 5	Use the result of logic rule 5 in the logic rule.

13-02 Stop Event

Option:		Function:
		Select the Boolean (TRUE or FALSE) input to deactivate Smart Logic Control.
[0] *	FALSE	Enters the fixed value of FALSE in the logic rule.
[1]	TRUE	Enters the fixed value TRUE in the logic rule.
[2]	Running	See parameter group 5-3* for further description.
[3]	In range	See parameter group 5-3* for further description.
[4]	On reference	See parameter group 5-3* for further description.
[5]	Torque limit	See parameter group 5-3* for further description.
[6]	Current limit	See parameter group 5-3* for further description.
[7]	Out of current range	See parameter group 5-3* for further description.

[8]	Below I low	See parameter group 5-3* for further description.
[9]	Above I high	See parameter group 5-3* for further description.
[10]	Out of speed range	
[11]	Below speed low	See parameter group 5-3* for further description.
[12]	Above speed high	See parameter group 5-3* for further description.
[13]	Out of feedb. range	See parameter group 5-3* for further description.
[14]	Below feedb. low	See parameter group 5-3* for further description.
[15]	Above feedb. high	See parameter group 5-3* for further description.
[16]	Thermal warning	See parameter group 5-3* for further description.
[17]	Mains out of range	See parameter group 5-3* for further description.
[18]	Reverse	See parameter group 5-3* for further description.
[19]	Warning	See parameter group 5-3* for further description.
[20]	Alarm (trip)	See parameter group 5-3* for further description.
[21]	Alarm (trip lock)	See parameter group 5-3* for further description.
[22]	Comparator 0	Use the result of comparator 0 in the logic rule.
[23]	Comparator 1	Use the result of comparator 1 in the logic rule.
[24]	Comparator 2	Use the result of comparator 2 in the logic rule.
[25]	Comparator 3	Use the result of comparator 3 in the logic rule.
[26]	Logic rule 0	Use the result of logic rule 0 in the logic rule.
[27]	Logic rule 1	Use the result of logic rule 1 in the logic rule.
[28]	Logic rule 2	Use the result of logic rule 2 in the logic rule.
[29]	Logic rule 3	Use the result of logic rule 3 in the logic rule.
[30]	SL Timeout 0	Use the result of timer 0 in the logic rule.
[31]	SL Timeout 1	Use the result of timer 1 in the logic rule.
[32]	SL Timeout 2	Use the result of timer 2 in the logic rule.
[33]	Digital input DI18	Use the value of DI18 in the logic rule (High = TRUE).
[34]	Digital input DI19	Use the value of DI19 in the logic rule (High = TRUE).
[35]	Digital input DI27	Use the value of DI27 in the logic rule (High = TRUE).
[36]	Digital input DI29	Use the value of DI29 in the logic rule (High = TRUE).
[37]	Digital input DI32	Use the value of DI32 in the logic rule (High = TRUE).
[38]	Digital input DI33	Use the value of DI33 in the logic rule (High = TRUE).
[39]	Start command	This event is TRUE if the adjustable frequency drive is started by any means (either via digital input, serial communication bus or other).

Parameter Description

[40]	Drive stopped	This event is TRUE if the adjustable frequency drive is stopped or coasted by any means (either via digital input, serial communication bus or other).
[41]	Reset Trip	This event is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and the reset button is pressed.
[42]	Auto Reset Trip	This event is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and an automatic reset is issued.
[43]	OK Key	This event is TRUE if the OK key on the keypad is pressed.
[44]	Reset Key	This event is TRUE if the Reset key on the keypad is pressed.
[45]	Left Key	This event is TRUE if the Left key on the keypad is pressed.
[46]	Right Key	This event is TRUE if the Right key on the keypad is pressed.
[47]	Up Key	This event is TRUE if the Up key on the keypad is pressed.
[48]	Down Key	This event is TRUE if the Down key on the keypad is pressed.
[50]	Comparator 4	Use the result of comparator 4 in the logic rule.
[51]	Comparator 5	Use the result of comparator 5 in the logic rule.
[60]	Logic rule 4	Use the result of logic rule 4 in the logic rule.
[61]	Logic rule 5	Use the result of logic rule 5 in the logic rule.
[70]	SL Timeout 3	Use the result of timer 3 in the logic rule.
[71]	SL Timeout 4	Use the result of timer 4 in the logic rule.
[72]	SL Timeout 5	Use the result of timer 5 in the logic rule.
[73]	SL Timeout 6	Use the result of timer 6 in the logic rule.
[74]	SL Timeout 7	Use the result of timer 7 in the logic rule.
[80]	No Flow	
[81]	Dry Pump	
[82]	End of Curve	
[83]	Broken Belt	

13-03 Reset SLC

Option:	Function:
[0] * Do not reset SLC	Retains programmed settings in all group 13 parameters (13-*).
[1] Reset SLC	Resets all group 13LC-## parameters (13-*) to default settings.

13-1* Comparators

Comparators are used for comparing continuous variables (i.e., output frequency, output current, analog input, etc.) to fixed preset values. In addition, there are digital values that will be compared to fixed time values. See explanation in par.13-10 [Comparator Operand](#). Comparators are evaluated once in each scan interval. Use the result (TRUE or FALSE) directly. All parameters in this parameter group are array parameters with an index of 0 to 5. Select index 0 to program Comparator 0, select index 1 to program Comparator 1, etc.

13-10 Comparator Operand

Array [4]

Option:

Function:

Select the variable to be monitored by the comparator.

[0] * DISABLED

[1] Reference

[2] Feedback

[3] Motor speed

[4] Motor current

[5] Motor torque

[6] Motor power

[7] Motor voltage

[8] DC-link voltage

[9] Motor thermal

[10] VLT temp.

[11] Heat sink temp.

[12] Analog input AI53

[13] Analog input AI54

[14] Analog input AIFB10

[15] Analog input AIS24V

[17] Analog input AICCT

[18] Pulse input FI29

[19] Pulse input FI33

[20] Alarm number

[30] Counter A

[31] Counter B

13-11 Comparator Operator

Array [6]

Option:

Function:

[0] * <

Select < [0] for the result of the evaluation to be TRUE, when the variable selected in par.13-10 [Comparator Operand](#) is smaller than the fixed value in par.13-12 [Comparator Value](#). The result will be FALSE, if the variable selected in par.13-10 [Comparator Operand](#) is greater than the fixed value in par.13-12 [Comparator Value](#).

[1] = (equal)

Select ≈ [1] for the result of the evaluation to be TRUE, when the variable selected in par.13-10 [Comparator Operand](#) is approximately equal to the fixed value in par.13-12 [Comparator Value](#).

[2] >

Select > [2] for the inverse logic of option < [0].

13-12 Comparator Value

Array [6]

Range:

Function:

Applica- [-100000.000 - 100000.000
tion de- N/A]
pend-
ent*

Enter the 'trigger level' for the variable that is monitored by this comparator. This is an array parameter containing comparator values 0 to 5.

13-2* Timers

This parameter group consists of timer parameters.

Use the result (TRUE or FALSE) from *timers* directly to define an *event* (see par.13-51 [SL Controller Event](#)), or as Boolean input in a *logic rule* (see par.13-40 [Logic Rule Boolean 1](#), par.13-42 [Logic Rule Boolean 2](#) or par.13-44 [Logic Rule Boolean 3](#)). A timer is only FALSE when started by an action (i.e., Start timer 1 [29]) until the timer value entered in this parameter is elapsed. Then it becomes TRUE again.

All parameters in this parameter group are array parameters with an index of 0 to 2. Select index 0 to program Timer 0, select index 1 to program Timer 1, and so on.

13-20 SL Controller Timer

Array [3]

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

13-4* Logic Rules

Combine up to three boolean inputs (TRUE / FALSE inputs) from timers, comparators, digital inputs, status bits and events using the logical operators AND, OR, and NOT. Select Boolean inputs for the calculation in par.

13-40 [Logic Rule Boolean 1](#), par.13-42 [Logic Rule Boolean 2](#) and par.13-44 [Logic Rule Boolean 3](#). Define the operators used to logically combine the selected inputs in par.13-41 [Logic Rule Operator 1](#) and par.13-43 [Logic Rule Operator 2](#).

Priority of calculation

The results of par.13-40 [Logic Rule Boolean 1](#), par.13-41 [Logic Rule Operator 1](#) and par.13-42 [Logic Rule Boolean 2](#) are calculated first. The outcome (TRUE / FALSE) of this calculation is combined with the settings of par.13-43 [Logic Rule Operator 2](#) and par.13-44 [Logic Rule Boolean 3](#), yielding the final result (TRUE / FALSE) of the logic rule.

13-40 Logic Rule Boolean 1

Array [6]

Option:

Function:

[0] * FALSE

Enters the fixed value of FALSE in the logic rule.

[1] TRUE

Enters the fixed value TRUE in the logic rule.

[2] Running

See parameter group 5-3* for further description.

[3] In range

See parameter group 5-3* for further description.

[4] On reference

See parameter group 5-3* for further description.

[5]	Torque limit	See parameter group 5-3* for further description.
[6]	Current limit	See parameter group 5-3* for further description.
[7]	Out of current range	See parameter group 5-3* for further description.
[8]	Below I low	See parameter group 5-3* for further description.
[9]	Above I high	See parameter group 5-3* for further description.
[10]	Out of speed range	
[11]	Below speed low	See parameter group 5-3* for further description.
[12]	Above speed high	See parameter group 5-3* for further description.
[13]	Out of feedb. range	See parameter group 5-3* for further description.
[14]	Below feedb. low	See parameter group 5-3* for further description.
[15]	Above feedb. high	See parameter group 5-3* for further description.
[16]	Thermal warning	See parameter group 5-3* for further description.
[17]	Mains out of range	See parameter group for further description.
[18]	Reverse	See parameter group 5-3* for further description.
[19]	Warning	See parameter group 5-3* for further description.
[20]	Alarm (trip)	See parameter group 5-3* for further description.
[21]	Alarm (trip lock)	See parameter group 5-3* for further description.
[22]	Comparator 0	Use the result of comparator 0 in the logic rule.
[23]	Comparator 1	Use the result of comparator 1 in the logic rule.
[24]	Comparator 2	Use the result of comparator 2 in the logic rule.
[25]	Comparator 3	Use the result of comparator 3 in the logic rule.
[26]	Logic rule 0	Use the result of logic rule 0 in the logic rule.
[27]	Logic rule 1	Use the result of logic rule 1 in the logic rule.
[28]	Logic rule 2	Use the result of logic rule 2 in the logic rule.
[29]	Logic rule 3	Use the result of logic rule 3 in the logic rule.
[30]	SL Timeout 0	Use the result of timer 0 in the logic rule.
[31]	SL Timeout 1	Use the result of timer 1 in the logic rule.
[32]	SL Timeout 2	Use the result of timer 2 in the logic rule.
[33]	Digital input DI18	Use the value of DI18 in the logic rule (High = TRUE).
[34]	Digital input DI19	Use the value of DI19 in the logic rule (High = TRUE).
[35]	Digital input DI27	Use the value of DI27 in the logic rule (High = TRUE).
[36]	Digital input DI29	Use the value of DI29 in the logic rule (High = TRUE).
[37]	Digital input DI32	Use the value of DI32 in the logic rule (High = TRUE).

Parameter Description

[38]	Digital input DI33	Use the value of DI33 in the logic rule (High = TRUE).
[39]	Start command	This logic rule is TRUE if the adjustable frequency drive is started by any means (either via digital input, serial communication bus or other).
[40]	Drive stopped	This logic rule is TRUE if the adjustable frequency drive is stopped or coasted by any means (either via digital input, serial communication bus or other).
[41]	Reset Trip	This logic rule is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and the reset button is pressed.
[42]	Auto Reset Trip	This logic rule is TRUE if the adjustable frequency drive is tripped (but not trip-locked) and an automatic reset is issued.
[43]	OK Key	This logic rule is TRUE if the OK key on the keypad is pressed.
[44]	Reset Key	This logic rule is TRUE if the Reset key on the keypad is pressed.
[45]	Left Key	This logic rule is TRUE if the Left key on the keypad is pressed.
[46]	Right Key	This logic rule is TRUE if the Right key on the keypad is pressed.
[47]	Up Key	This logic rule is TRUE if the Up key on the keypad is pressed.
[48]	Down Key	This logic rule is TRUE if the Down key on the keypad is pressed.
[50]	Comparator 4	Use the result of comparator 4 in the logic rule.
[51]	Comparator 5	Use the result of comparator 5 in the logic rule.
[60]	Logic rule 4	Use the result of logic rule 4 in the logic rule.
[61]	Logic rule 5	Use the result of logic rule 5 in the logic rule.
[70]	SL Timeout 3	Use the result of timer 3 in the logic rule.
[71]	SL Timeout 4	Use the result of timer 4 in the logic rule.
[72]	SL Timeout 5	Use the result of timer 5 in the logic rule.
[73]	SL Timeout 6	Use the result of timer 6 in the logic rule.
[74]	SL Timeout 7	Use the result of timer 7 in the logic rule.
[80]	No Flow	
[81]	Dry Pump	
[82]	End of Curve	
[83]	Broken Belt	

13-41 Logic Rule Operator 1

Array [6]

Option:

Function:

Select the first logical operator to use on the Boolean inputs from par. 13-40 [Logic Rule Boolean 1](#) and par.13-42 [Logic Rule Boolean 2](#).
[13 -XX] signifies the Boolean input of par. 13-*.

[0] *	DISABLED	Ignores par.13-42 Logic Rule Boolean 2 , par.13-43 Logic Rule Operator 2 , and par.13-44 Logic Rule Boolean 3 .
[1]	AND	Evaluates the expression [13-40] AND [13-42].
[2]	OR	evaluates the expression [13-40] OR[13-42].
[3]	AND NOT	evaluates the expression [13-40] AND NOT [13-42].
[4]	OR NOT	evaluates the expression [13-40] OR NOT [13-42].
[5]	NOT AND	evaluates the expression NOT [13-40] AND [13-42].
[6]	NOT OR	evaluates the expression NOT [13-40] OR [13-42].
[7]	NOT AND NOT	evaluates the expression NOT [13-40] AND NOT [13-42].
[8]	NOT OR NOT	evaluates the expression NOT [13-40] OR NOT [13-42].

13-42 Logic Rule Boolean 2

Array [6]

Option:

Function:

Select the second Boolean (TRUE or FALSE) input for the selected logic rule.

See par.13-40 [Logic Rule Boolean 1](#) for further descriptions of choices and their functions.

[0] *	FALSE
[1]	TRUE
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning



Parameter Description

[17]	Mains out of range
[18]	Reverse
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[30]	SL Timeout 0
[31]	SL Timeout 1
[32]	SL Timeout 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29
[37]	Digital input DI32
[38]	Digital input DI33
[39]	Start command
[40]	Drive stopped
[41]	Reset Trip
[42]	Auto Reset Trip
[43]	OK Key
[44]	Reset Key
[45]	Left Key
[46]	Right Key
[47]	Up Key
[48]	Down Key
[50]	Comparator 4
[51]	Comparator 5
[60]	Logic rule 4
[61]	Logic rule 5
[70]	SL Timeout 3
[71]	SL Timeout 4
[72]	SL Timeout 5
[73]	SL Timeout 6
[74]	SL Timeout 7
[80]	No Flow
[81]	Dry Pump

[82] End of Curve

[83] Broken Belt

13-43 Logic Rule Operator 2

Array [6]

Option:

Function:

Select the second logical operator to be used on the Boolean input calculated in par.13-40 [Logic Rule Boolean 1](#), par.13-41 [Logic Rule Operator 1](#), and par.13-42 [Logic Rule Boolean 2](#), and the Boolean input coming from par.13-42 [Logic Rule Boolean 2](#).

[13-44] signifies the Boolean input of par.13-44 [Logic Rule Boolean 3](#).

[13-40/13-42] signifies the Boolean input calculated in par.13-40 [Logic Rule Boolean 1](#), par.13-41 [Logic Rule Operator 1](#), and par.13-42 [Logic Rule Boolean 2](#). DISABLED [0] (factory setting). select this option to ignore par.13-44 [Logic Rule Boolean 3](#).

[0] * DISABLED

[1] AND

[2] OR

[3] AND NOT

[4] OR NOT

[5] NOT AND

[6] NOT OR

[7] NOT AND NOT

[8] NOT OR NOT

13-44 Logic Rule Boolean 3

Array [6]

Option:

Function:

Select the third Boolean (TRUE or FALSE) input for the selected logic rule.

See par.13-40 [Logic Rule Boolean 1](#) for further descriptions of choices and their functions.

[0] * FALSE

[1] TRUE

[2] Running

[3] In range

[4] On reference

[5] Torque limit

[6] Current limit

[7] Out of current range

[8] Below I low

[9] Above I high

[10] Out of speed range

[11] Below speed low

[12] Above speed high

[13] Out of feedb. range

[14] Below feedb. low

Parameter Description

[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reverse
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[30]	SL Timeout 0
[31]	SL Timeout 1
[32]	SL Timeout 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29
[37]	Digital input DI32
[38]	Digital input DI33
[39]	Start command
[40]	Drive stopped
[41]	Reset Trip
[42]	Auto Reset Trip
[43]	OK Key
[44]	Reset Key
[45]	Left Key
[46]	Right Key
[47]	Up Key
[48]	Down Key
[50]	Comparator 4
[51]	Comparator 5
[60]	Logic rule 4
[61]	Logic rule 5
[70]	SL Timeout 3
[71]	SL Timeout 4
[72]	SL Timeout 5
[73]	SL Timeout 6
[74]	SL Timeout 7

[80]	No Flow
[81]	Dry Pump
[82]	End of Curve
[83]	Broken Belt

13-5* States

Parameters for programming the Logic Controller.

13-51 SL Controller Event

Array [20]

Option:

Function:

Select the Boolean input (TRUE or FALSE) to define the Smart Logic Controller event.

See par.13-02 [Stop Event](#) for further descriptions of choices and their functions.

[0] *	FALSE
[1]	TRUE
[2]	Running
[3]	In range
[4]	On reference
[5]	Torque limit
[6]	Current limit
[7]	Out of current range
[8]	Below I low
[9]	Above I high
[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reverse
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2

Parameter Description

[29]	Logic rule 3
[30]	SL Timeout 0
[31]	SL Timeout 1
[32]	SL Timeout 2
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29
[37]	Digital input DI32
[38]	Digital input DI33
[39]	Start command
[40]	Drive stopped
[41]	Reset Trip
[42]	Auto Reset Trip
[43]	OK Key
[44]	Reset Key
[45]	Left Key
[46]	Right Key
[47]	Up Key
[48]	Down Key
[50]	Comparator 4
[51]	Comparator 5
[60]	Logic rule 4
[61]	Logic rule 5
[70]	SL Timeout 3
[71]	SL Timeout 4
[72]	SL Timeout 5
[73]	SL Timeout 6
[74]	SL Timeout 7
[80]	No Flow
[81]	Dry Pump
[82]	End of Curve
[83]	Broken Belt

13-52 SL Controller Action

Array [20]

Option:

Function:

Select the action corresponding to the SLC event. Actions are executed when the corresponding event (defined in par.13-51 [SL Controller Event](#)) is evaluated as true. The following actions are available for selection:

[0] * DISABLED

[1] No action

[2] Select set-up 1

Changes the active set-up (par.0-10 [Active Set-up](#)) to '1'.

[3]	Select set-up 2	Changes the active set-up (par.0-10 Active Set-up) to '2'.
[4]	Select set-up 3	Changes the active set-up (par.0-10 Active Set-up) to '3'.
[5]	Select set-up 4	Changes the active set-up (par.0-10 Active Set-up) to '4'. If the set-up is changed, it will merge with other set-up commands coming from either the digital inputs or via a serial communication bus.
[10]	Select preset ref 0	Selects preset reference 0.
[11]	Select preset ref 1	Selects preset reference 1.
[12]	Select preset ref 2	Selects preset reference 2.
[13]	Select preset ref 3	Selects preset reference 3.
[14]	Select preset ref 4	Selects preset reference 4.
[15]	Select preset ref 5	Selects preset reference 5.
[16]	Select preset ref 6	Selects preset reference 6.
[17]	Select preset ref 7	Selects preset reference 7. If the active preset reference is changed, it will merge with other preset reference commands coming from either the digital inputs or via a serial communication bus.
[18]	Select ramp 1	Selects ramp 1
[19]	Select ramp 2	Selects ramp 2
[22]	Run	Issues a start command to the adjustable frequency drive.
[23]	Run reverse	Issues a start reverse command to the adjustable frequency drive.
[24]	Stop	Issues a stop command to the adjustable frequency drive.
[26]	Dcstop	Issues a DC stop command to the adjustable frequency drive.
[27]	Coast	The adjustable frequency drive coasts immediately. All stop commands including the coast command stop the SLC.
[28]	Freeze output	Freezes the output frequency of the adjustable frequency drive.
[29]	Start timer 0	Starts timer 0, see par.13-20 SL Controller Timer for further description.
[30]	Start timer 1	Starts timer 1, see par.13-20 SL Controller Timer for further description.
[31]	Start timer 2	Starts timer 2, see par.13-20 SL Controller Timer for further description.
[32]	Set digital out A low	Any output with 'digital output 1' selected is low (off).
[33]	Set digital out B low	Any output with 'digital output 2' selected is low (off).
[34]	Set digital out C low	Any output with 'digital output 3' selected is low (off).
[35]	Set digital out D low	Any output with 'digital output 4' selected is low (off).
[36]	Set digital out E low	Any output with 'digital output 5' selected is low (off).
[37]	Set digital out F low	Any output with 'digital output 6' selected is low (off).
[38]	Set digital out A high	Any output with 'digital output 1' selected is high (closed).
[39]	Set digital out B high	Any output with 'digital output 2' selected is high (closed).

Parameter Description

[40]	Set digital out C high	Any output with 'digital output 3' selected is high (closed).
[41]	Set digital out D high	Any output with 'digital output 4' selected is high (closed).
[42]	Set digital out E high	Any output with 'digital output 5' selected is high (closed).
[43]	Set digital out F high	Any output with 'digital output 6' selected is high (closed).
[60]	Reset Counter A	Resets Counter A to zero.
[61]	Reset Counter B	Resets Counter A to zero.
[70]	Start Timer 3	Starts timer 3, see par.13-20 SL Controller Timer for further description.
[71]	Start Timer 4	Starts timer 4, see par.13-20 SL Controller Timer for further description.
[72]	Start Timer 5	Starts timer 5, see par.13-20 SL Controller Timer for further description.
[73]	Start Timer 6	Starts timer 6, see par.13-20 SL Controller Timer for further description.
[74]	Start Timer 7	Starts timer 7, see par.13-20 SL Controller Timer for further description.
[80]	Sleep Mode	

Main Menu - Special Functions -Group 14

14-** Special Functions

Parameter group for configuring special adjustable frequency drive functions.

Parameters for configuring the .

14-00 Switching Pattern

Option:

Function:

Select the switching pattern: 60° AVM or SFAVM.

[0] * 60 AVM

[1] SFAVM

14-01 Switching Frequency

Option:

Function:

Select the inverter switching frequency. Changing the switching frequency can help to reduce acoustic noise from the motor.

NOTE: The output frequency value of the adjustable frequency drive must never exceed 1/10 of the switching frequency. When the motor is running, adjust the switching frequency in par.14-01 [Switching Frequency](#) until the motor is as noiseless as possible. See also par.14-00 [Switching Pattern](#) and the section *Derating*.

[0] 1.0 kHz

[1] 1.5 kHz

[2] 2.0 kHz

[3] 2.5 kHz

[4] 3.0 kHz

[5] 3.5 kHz

[6]	4.0 kHz
[7] *	5.0 kHz
[8]	6.0 kHz
[9]	7.0 kHz
[10]	8.0 kHz
[11]	10.0 kHz
[12]	12.0 kHz
[13]	14.0 kHz
[14]	16.0 kHz

14-03 Overmodulation

Option:	Function:
[0] Off	Selects no overmodulation of the output voltage in order to avoid torque ripple on the motor shaft.
[1] * On	The overmodulation function generates an extra voltage of up to 8% of U_{max} output voltage without overmodulation, which results in an extra torque of 10–12% in the middle of the oversynchronous range (from 0% at nominal speed rising to approximately 12% at double nominal speed).

14-04 PWM Random

Option:	Function:
[0] * Off	No change of the acoustic motor switching noise.
[1] On	Transforms the acoustic motor switching noise from a clear ringing tone to a less noticeable 'white' noise. This is achieved by slightly and randomly altering the synchronism of the pulse width modulated output phases.

14-1* Line Power On/Off

Parameters for configuring line failure monitoring and handling.

14-10 Mains Failure

Option:	Function:
	Select the function at which the adjustable frequency drive must act, when the threshold set in par.14-11 Mains Voltage at Mains Fault has been reached or a <i>Line Failure Inverse</i> command is activated via one of the digital inputs (par. 5-1*).
[0] * No function	The energy left in the capacitor bank will be used to "drive" the motor, but will be discharged.
[1] Ctrl. ramp-down	The adjustable frequency drive will perform a controlled ramp-down. par.2-10 Brake Function must be set to <i>Off</i> [0].
[3] Coasting	The inverter will turn off and the capacitor bank will back up the control card, thus ensuring a faster restart when line power is reconnected (for short power zags).

[4]	Kinetic back-up	The adjustable frequency drive will ride through by controlling speed for generative operation of the motor utilizing the moment of inertia of the system as long as sufficient energy is present.
-----	-----------------	--

NOTE

For best performance of controlled ramp-down and kinetic backup, par.1-03 [Torque Characteristics](#) should be set to **Compressor** [0] or **Variable Torque** [1] (no automatic energy optimization should be active).




Figure 4. 2: Controlled ramp-down - short line failure. Ramping down to stop, followed by ramping up to reference.




Figure 4. 3: Controlled ramp-down, longer line failure. Controlled ramp-down, longer line failure.




Figure 4. 4: Kinetic backup, short line failure. Ride through as long as the energy in the system allows for it.




Figure 4. 5: Kinetic Backup, longer line failure. The motor is coasted as soon as the energy in the system is too low.

14-11 Mains Voltage at Mains Fault

Range:

Function:

Applica- [180 - 600 V]
tion de-
pend-
ent*

This parameter defines the threshold voltage at which the selected function in par.14-10 [Mains Failure](#) should be activated.

14-12 Function at Mains Imbalance

Option:

Function:

Operating under severe line imbalance conditions reduces the lifetime of the motor. Conditions are considered severe if the motor operates continuously near nominal load (such as when a pump or fan runs near full speed).

When a severe line imbalance is detected:

[0] *	Trip	Select <i>Trip</i> [0] to trip the adjustable frequency drive.
[1]	Warning	Select <i>Warning</i> [1] to issue a warning.
[2]	Disabled	select <i>Disabled</i> [2] for no action.
[3]	Derate	Select <i>Derate</i> [3] for derating the adjustable frequency drive.

14-2* Trip Reset

Parameters for configuring auto reset handling, special trip handling and control card self test or initialization.

14-20 Reset Mode

Option:

Function:

Select the reset function after tripping. Once reset, the adjustable frequency drive can be restarted.

[0] *	Manual reset	Select <i>Manual reset</i> [0], to perform a reset via [RESET] or via the digital inputs.
[1]	Automatic reset x 1	Select <i>Automatic reset x 1...x20</i> [1]-[12] to perform between one and twenty automatic resets after tripping.
[2]	Automatic reset x 2	
[3]	Automatic reset x 3	
[4]	Automatic reset x 4	
[5]	Automatic reset x 5	

Parameter Description

[6]	Automatic reset x 6	
[7]	Automatic reset x 7	
[8]	Automatic reset x 8	
[9]	Automatic reset x 9	
[10]	Automatic reset x 10	
[11]	Automatic reset x 15	
[12]	Automatic reset x 20	
[13]	Infinite auto reset	Select <i>Infinite Automatic Reset</i> [13] for continuous resetting after tripping.

NOTE

The motor may start without warning. If the specified number of AUTOMATIC RESETs is reached within 10 minutes, the adjustable frequency drive enters Manual reset [0] mode. After the Manual reset is performed, the setting of par. 14-20 [Reset Mode](#) reverts to the original selection. If the number of automatic resets is not reached within 10 minutes, or when a Manual reset is performed, the internal AUTOMATIC RESET counter returns to zero.

NOTE

Automatic reset will also be active for resetting safe stop function.

NOTE

The setting in par.14-20 [Reset Mode](#) is disregarded if fire mode is active (see par. 24-0*, Fire Mode).

14-21 Automatic Restart Time

Range:	Function:
10 s* [0 - 600 s]	Enter the time interval from trip to start of the automatic reset function. This parameter is active when par.14-20 Reset Mode is set to <i>Automatic reset</i> [1] - [13].

14-22 Operation Mode

Option:	Function:
	Use this parameter to specify normal operation, to perform tests or to initialize all parameters except par.15-03 Power-ups , par.15-04 Over Temps and par.15-05 Over Volts . This function is active only when the power is cycled (power off-power on) to the adjustable frequency drive.
[0] * Normal operation	Select <i>Normal operation</i> [0] for normal operation of the adjustable frequency drive with the motor in the selected application.
[1] Control card test	Select <i>Control card test</i> [1] to test the analog and digital inputs and outputs and the +10 V control voltage. The test requires a test connector with internal connections. Use the following procedure for the control card test: 1. Select <i>Control card test</i> [1]. 2. Disconnect the line power supply and wait for the light in the display to go out. 3. Set switches S201 (A53) and S202 (A54) = 'ON' / I. 4. Insert the test plug (see below).

5. Connect to the line power supply.
6. Carry out various tests.
7. The results are displayed on the keypad and the adjustable frequency drive moves into an infinite loop.
8. par.14-22 [Operation Mode](#) is automatically set to normal operation. Carry out a power cycle to start up in normal operation after a control card test.

If the test is OK:


keypad readout: Control Card OK.

Disconnect the line power supply and remove the test plug. The green LED on the control card will light up.

If the test fails:

keypad readout: Control Card I/O failure.

Replace the adjustable frequency drive or control card. The red LED on the control card is turned on. To test the plugs, connect/group the following terminals as shown below: (18 - 27 - 32), (19 - 29 - 33) and (42 - 53 - 54).



[2] Initialization

Select *Initialization* [2] to reset all parameter values to default settings, except for par.15-03 [Power-ups](#), par.15-04 [Over Temps](#) and par. 15-05 [Over Volts](#). The adjustable frequency drive will reset during the next power-up.
par.14-22 [Operation Mode](#) will also revert to the default setting *Normal operation* [0].

[3] Boot mode

14-23 Typecode Setting

Option:

Function:

Typecode re-writing. Use this parameter to set the typecode matching the specific adjustable frequency drive.

14-25 Trip Delay at Torque Limit

Range:	Function:
60 s* [0 - 60 s]	Enter the torque limit trip delay in seconds. When the output torque reaches the torque limits (par.4-16 Torque Limit Motor Mode and par. 4-17 Torque Limit Generator Mode), a warning is triggered. When the torque limit warning has been continuously present for the period specified in this parameter, the adjustable frequency drive trips. Disable the trip delay by setting the parameter to 60 s = OFF. Thermal adjustable frequency drive monitoring will still remain active.

14-26 Trip Delay at Inverter Fault

Range:	Function:
Application dependent* [0 - 35 s]	When the adjustable frequency drive detects an overvoltage in the set time, tripping will be affected after the set time.

14-28 Production Settings

Option:	Function:
[0] * No action	
[1] Service reset	
[2] Set Production Mode	

14-29 Service Code

Range:	Function:
0 N/A* [-2147483647 - 2147483647 N/A]	Service use only.

14-3* Current Limit Control

The adjustable frequency drive features an integral current limit controller which is activated when the motor current, and thus the torque, is higher than the torque limits set in par.4-16 [Torque Limit Motor Mode](#) and par. 4-17 [Torque Limit Generator Mode](#).

When the current limit is reached during motor operation or regenerative operation, the adjustable frequency drive will try to reduce torque below the preset torque limits as quickly as possible without losing control of the motor.

While the current control is active, the adjustable frequency drive can only be stopped by setting a digital input to *Coast inverse* [2] or *Coast and reset inv.* [3]. Any signal on terminals 18 to 33 will not be active until the adjustable frequency drive is no longer near the current limit.

By using a digital input set to *Coast inverse* [2] or *Coast and reset inv.* [3], the motor does not use the ramp-down time, since the adjustable frequency drive is coasted.

14-30 Current Lim Cont, Proportional Gain

Range:	Function:
100 %* [0 - 500 %]	Enter the proportional gain value for the current limit controller. Selection of a high value makes the controller react faster. Too high a setting leads to controller instability.

14-31 Current Lim Contr, Integration Time

Range:	Function:
0.020 s* [0.002 - 2.000 s]	Controls the current limit control integration time. Setting it to a lower value makes it react faster. A setting too low leads to control instability.

14-32 Current Lim Ctrl, Filter Time

Range:	Function:
26.0 [1.0 - 100.0 ms] ms*	

14-4*Energy Optimization

Parameters for adjusting the energy optimization level in both Variable Torque (VT) and Automatic Energy Optimization (AEO) mode.

Automatic Energy Optimization is only active if par.1-03 [Torque Characteristics](#), is set for either *Auto Energy Optim. Compressor* [2] or *Auto Energy Optim. VT* [3].

14-40 VT Level

Range:	Function:
66 %* [40 - 90 %]	Enter the level of motor magnetization at low speed. Selection of a low value reduces energy loss in the motor, but also reduces load capability. This parameter cannot be adjusted while the motor is running.

14-41 AEO Minimum Magnetization

Range:	Function:
Applica- [40 - 75 %] tion de- pend- ent*	Enter the minimum allowable magnetization for AEO. Selection of a low value reduces energy loss in the motor, but can also reduce resistance to sudden load changes.

14-42 Minimum AEO Frequency

Range:	Function:
10 Hz* [5 - 40 Hz]	Enter the minimum frequency at which the Automatic Energy Optimization (AEO) is to be active.

14-43 Motor Cos-Phi

Range:	Function:
Applica- [0.40 - 0.95 N/A] tion de- pend- ent*	The cos(phi) setpoint is automatically set for optimum AEO performance during AMA. This parameter should normally not be altered. However, in some situations it may be necessary to enter a new value to fine tune.

14-5* Environment

These parameters help the adjustable frequency drive to operate under special environmental conditions.

14-50 RFI 1

Option:	Function:
[0] Off	Select <i>Off</i> [0] only if the adjustable frequency drive is fed by an isolated line power source, i.e., from a special IT line power source. In this mode, the internal RFI filter capacitors between chassis and the line power RFI filter circuit are cut out to avoid damage to the intermediate circuit and to reduce the ground capacity currents according to IEC 61800-3.
[1] * On	Select <i>On</i> [1] to ensure that the adjustable frequency drive complies with EMC standards.

14-52 Fan Control

Option:	Function:
	Select the minimum speed of the main fan.
[0] * Auto	Select Auto [0] to run the fan only when the internal temperature of the adjustable frequency drive is in the range 95°F [+35°C] to approximately 131°F [+55°C]. The fan will run at low speed at 95°F [+35°C] and at full speed at approximately 131°F [+55°C].
[1] On 50%	
[2] On 75%	
[3] On 100%	

14-53 Fan Monitor

Option:	Function:
	Select which action the adjustable frequency drive should take in case a fan fault is detected.
[0] Disabled	
[1] * Warning	
[2] Trip	

14-6* Auto Derate

This group contains parameters for derating the adjustable frequency drive in case of high temperature.

14-60 Function at Overtemperature

Option:

Function:

If either heatsink or control card temperature exceeds a factory-programmed temperature limit, a warning will be activated. If the temperature increases further, select whether the adjustable frequency drive should trip (trip locked) or derate the output current.

[0] * Trip


The adjustable frequency drive will trip (trip locked) and generate an alarm. Power must be cycled to reset the alarm, but will not allow restart of the motor until the heatsink temperature has dropped below the alarm limit.

[1] Derate

If the critical temperature is exceeded, the output current will be reduced until the allowable temperature has been reached.

No Trip at Inverter Overload

In some pump systems, the adjustable frequency drive has not been sized properly to yield the current needed in all points of the operational flow-head characteristic. At these points, the pump will need a current higher than the rated current of the adjustable frequency drive. The adjustable frequency drive can yield 110% of the rated current continuously for 60 sec. If still overloaded, the adjustable frequency drive will normally trip (causing the pump to stop by coasting) and provide an alarm.



It may be preferable to run the pump at reduced speed for a while in case it is not possible to run continuously at demanded capacity.

Parameter Description

Select *Function at Inverter Overload*, par.14-61 [Function at Inverter Overload](#) to automatically reduce pump speed until the output current is below 100% of the rated current (set in par.14-62 [Inv. Overload Derate Current](#)). The *Function at Inverter Overload* is an alternative to letting the adjustable frequency drive trip.

The adjustable frequency drive estimates the load on the power section by means of an inverter load counter, which will cause a warning at 98% and a reset of the warning at 90%. At the value 100%, the adjustable frequency drive trips and provides an alarm.

Status for the counter can be read in par.16-35 [Inverter Thermal](#).

If par.14-61 [Function at Inverter Overload](#) is set to Derate, the pump speed will be reduced when the counter exceeds 98, and stay reduced until the counter has dropped below 90.7.

If par.14-62 [Inv. Overload Derate Current](#) is set, for example, to 95% a steady overload will cause the pump speed to fluctuate between values corresponding to 110% and 95% of rated output current for the adjustable frequency drive.

14-61 Function at Inverter Overload

Option:	Function:
	Is used in case of steady overload beyond the thermal limits (110% for 60 sec.).
[0] * Trip	Choose Trip [0] to make the adjustable frequency drive trip and provide an alarm.
[1] Derate	Derate [1] to reduce pump speed in order to decrease the load on the power section and allowing this to cool down.

14-62 Inv. Overload Derate Current

Range:	Function:
95 %* [50 - 100 %]	Defines the desired current level (in % of rated output current for the adjustable frequency drive) when running with reduced pump speed after load on the adjustable frequency drive has exceeded the allowable limit (110% for 60 sec.).

Main Menu - Adjustable Frequency Drive Information - Group 15

15-** Drive Information

Parameter group containing adjustable frequency drive information such as operating data, hardware configuration and software versions.

15-0* Operating Data

Parameter group containing operating data, such as operating hours, kWh counters, power-ups, etc.

15-00 Operating Hours

Range:	Function:
0 h* [0 - 2147483647 h]	View how many hours the adjustable frequency drive has run. The value is saved when the adjustable frequency drive is turned off.

15-01 Running Hours

Range:	Function:
0 h* [0 - 2147483647 h]	View how many hours the motor has run. Reset the counter in par. 15-07 Reset Running Hours Counter . The value is saved when the adjustable frequency drive is turned off.

15-02 kWh Counter

Range:	Function:
0 kWh* [0 - 2147483647 kWh]	Registering the power consumption of the motor as a mean value over one hour. Reset the counter in par.15-06 Reset kWh Counter .

15-03 Power-ups

Range:	Function:
0 N/A* [0 - 2147483647 N/A]	View the number of times the adjustable frequency drive has been powered up.

15-04 Over Temps

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the number of adjustable frequency drive temperature faults which have occurred.

15-05 Over Volts

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the number of adjustable frequency drive overvoltages which have occurred.

15-06 Reset kWh Counter

Option:	Function:
[0] * Do not reset	Select <i>Do not reset</i> [0] if no reset of the kWh counter is desired.
[1] Reset counter	Select <i>Reset</i> [1] and press [OK] to reset the kWh counter to zero (see par. 15-02 kWh Counter).

NOTE

The reset is carried out by pressing [OK].

15-07 Reset Running Hours Counter

Option:	Function:
[0] * Do not reset	Select <i>Do not reset</i> [0] if no reset of the Running Hours counter is desired.
[1] Reset counter	Select <i>Reset counter</i> [1] and press [OK] to reset the Running Hours counter (par.15-01 Running Hours) and par.15-08 Number of Starts to zero (see also par.15-01 Running Hours).

15-08 Number of Starts

Range:

0 N/A* [0 - 2147483647 N/A]

Function:

This is a readout parameter only. The counter shows the numbers of starts and stops caused by a normal Start/Stop command and/or when entering/leaving sleep mode.

NOTE

This parameter will be reset when resetting par.15-07 [Reset Running Hours Counter](#).

15-1* Data Log Settings

The Data Log enables continuous logging of up to 4 data sources (par.15-10 [Logging Source](#)) at individual rates (par.15-11 [Logging Interval](#)). A trigger event (par.15-12 [Trigger Event](#)) and window (par.15-14 [Samples Before Trigger](#)) are used to start and stop the logging conditionally.

15-10 Logging Source

Array [4]

Option:

Function:

Select which variables are to be logged.

[0] * None

[1600] Control Word

[1601] Reference [Unit]

[1602] Reference %

[1603] Status Word

[1610] Power [kW]

[1611] Power [hp]

[1612] Motor voltage

[1613] Frequency

[1614] Motor Current

[1616] Torque [Nm]

[1617] Speed [RPM]

[1618] Motor Thermal

[1622] Torque [%]

[1626] Power Filtered [kW]

[1627] Power Filtered [hp]

[1630] DC Link Voltage

[1632] Brake Energy /s

[1633] Brake Energy /2 min

[1634] Heatsink Temp.

[1635] Inverter Thermal

[1650] External Reference

[1652] Feedback [Unit]

[1654] Feedback 1 [Unit]

[1655] Feedback 2 [Unit]

[1656] Feedback 3 [Unit]

15-11 Logging Interval

Applica- [Application dependant]
tion de-
pend-
ent*

Selects the trigger event. When the trigger event occurs, a window is applied to freeze the log. The log will then retain a specified percentage of samples before the occurrence of the trigger event (par.15-14 [Samples Before Trigger](#)).

4-133

Parameter Description

[10]	Out of speed range
[11]	Below speed low
[12]	Above speed high
[13]	Out of feedb. range
[14]	Below feedb. low
[15]	Above feedb. high
[16]	Thermal warning
[17]	Mains out of range
[18]	Reverse
[19]	Warning
[20]	Alarm (trip)
[21]	Alarm (trip lock)
[22]	Comparator 0
[23]	Comparator 1
[24]	Comparator 2
[25]	Comparator 3
[26]	Logic rule 0
[27]	Logic rule 1
[28]	Logic rule 2
[29]	Logic rule 3
[33]	Digital input DI18
[34]	Digital input DI19
[35]	Digital input DI27
[36]	Digital input DI29
[37]	Digital input DI32
[38]	Digital input DI33
[50]	Comparator 4
[51]	Comparator 5
[60]	Logic rule 4
[61]	Logic rule 5

15-13 Logging Mode

Option:	Function:
[0] * Log always	Select <i>Log always</i> [0] for continuous logging.
[1] Log once on trigger	Select <i>Log once on trigger</i> [1] to conditionally start and stop logging using par.15-12 Trigger Event and par.15-14 Samples Before Trigger .

15-14 Samples Before Trigger

Range:	Function:
50 N/A* [0 - 100 N/A]	Enter the percentage of all samples prior to a trigger event which are to be retained in the log. See also par.15-12 Trigger Event and par. 15-13 Logging Mode .

15-2* Historic Log

View up to 50 logged data items via the array parameters in this parameter group. For all parameters in the group, [0] is the most recent data and [49] the oldest data. Data is logged every time an *event* occurs (not to be confused with SLC events). *Events* in this context are defined as a change in one of the following areas:

1. Digital input
2. Digital outputs (not monitored in this SW release)
3. Warning word
4. Alarm word
5. Status word
6. Control word
7. Extended status word

Events are logged with value, and time stamp in msec. The time interval between two events depends on how often *events* occur (maximum once every scan time). Data logging is continuous but if an alarm occurs, the log is saved and the values can be viewed on the display. This feature is useful, for example when carrying out service following a trip. View the historic log contained in this parameter via the serial communication port or via the display.

15-20 Historic Log: Event

Array [50]

Range:

Function:

0 N/A* [0 - 255 N/A]

View the event type of the logged events.

15-21 Historic Log: Value

Array [50]

Range:

Function:

0 N/A* [0 - 2147483647 N/A]

View the value of the logged event. Interpret the event values according to this table:

Digital input	Decimal value. See par.16-60 Digital Input for description after converting to binary value.
Digital output (not monitored in this SW release)	Decimal value. See par.16-66 Digital Output [bin] for description after converting to binary value.
Warning word	Decimal value. See par.16-92 Warning Word for description.
Alarm word	Decimal value. See par.16-90 Alarm Word for description.
Status word	Decimal value. See par.16-03 Status Word for description after converting to binary value.
Control word	Decimal value. See par.16-00 Control Word for description.
Extended status word	Decimal value. See par.16-94 Ext. Status Word for description.

15-22 Historic Log: Time

Array [50]

Range:

Function:

0 ms* [0 - 2147483647 ms]

View the time at which the logged event occurred. Time is measured in ms since adjustable frequency drive start. The max. value corresponds to approx. 24 days which means that the count will restart at zero after this time period.

15-23 Historic Log: Date and Time

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

15-3* Alarm Log

Parameters in this group are array parameters, where up to 10 fault logs can be viewed. [0] is the most recent logged data, and [9] the oldest. Error codes, values and time stamp can be viewed for all logged data.

15-30 Alarm Log: Error Code

Array [10]

Range: Function:

0 N/A* [0 - 255 N/A] View the error code and look up its meaning in the *Troubleshooting* chapter.

15-31 Alarm Log: Value

Array [10]

Range: Function:

0 N/A* [-32767 - 32767 N/A] View an extra description of the error. This parameter is mostly used in combination with alarm 38 'internal fault'.

15-32 Alarm Log: Time

Array [10]

Range: Function:

0 s* [0 - 2147483647 s] View the time when the logged event occurred. Time is measured in seconds from adjustable frequency drive start-up.

15-33 Alarm Log: Date and Time

Range: Function:

Applica- [Application dependant]
tion de-
pend-
ent*

15-4* Drive Identification

Parameters containing read only information about the hardware and software configuration of the adjustable frequency drive.

15-40 FC Type

Range: Function:

0 N/A* [0 - 0 N/A] View the FC type. The readout is identical to the adjustable frequency drive series power field of the type code definition, characters 1-6.

15-41 Power Section

Range:	Function:
0 N/A* [0 - 0 N/A]	View the FC type. The readout is identical to the adjustable frequency drive series power field of the type code definition, characters 7-10.

15-42 Voltage

Range:	Function:
0 N/A* [0 - 0 N/A]	View the FC type. The readout is identical to the adjustable frequency drive series power field of the type code definition, characters 11-12.

15-43 Software Version

Range:	Function:
0 N/A* [0 - 0 N/A]	View the combined SW version (or 'package version') consisting of power SW and control SW.

15-44 Ordered Typecode String

Range:	Function:
0 N/A* [0 - 0 N/A]	View the type code string used for re-ordering the adjustable frequency drive in its original configuration.

15-45 Actual Typecode String

Range:	Function:
0 N/A* [0 - 0 N/A]	View the actual type code string.

15-46 Adj Freq Dr Ordering No.

Range:	Function:
0 N/A* [0 - 0 N/A]	View the 8-digit ordering number used for re-ordering the adjustable frequency drive in its original configuration.

15-47 Power Card Ordering No.

Range:	Function:
0 N/A* [0 - 0 N/A]	View the power card ordering number.

15-48 LCP ID Num.

Range:	Function:
0 N/A* [0 - 0 N/A]	View the keypad ID number.

15-49 SW ID Control Card

Range:	Function:
0 N/A* [0 - 0 N/A]	View the control card software version number.

15-50 SW ID Power Card

Range:	Function:
0 N/A* [0 - 0 N/A]	View the power card software version number.



Parameter Description

15-51 Adj Freq Dr Serial No.

Range:	Function:
0 N/A* [0 - 0 N/A]	View the adjustable frequency drive serial number.

15-53 Power Card Serial Number

Range:	Function:
0 N/A* [0 - 0 N/A]	View the power card serial number.

15-6* Option Ident.

This read-only parameter group contains information about the hardware and software configuration of the options installed in slots A, B C0 and C1.

15-60 Option Mounted

Range:	Function:
0 N/A* [0 - 0 N/A]	View the installed option type.

15-61 Option SW Version

Range:	Function:
0 N/A* [0 - 0 N/A]	View the installed option software version.

15-62 Option Ordering No

Range:	Function:
0 N/A* [0 - 0 N/A]	Shows the ordering number for the installed options.

15-63 Option Serial No

Range:	Function:
0 N/A* [0 - 0 N/A]	View the installed option serial number.

15-70 Option in Slot A

Range:	Function:
0 N/A* [0 - 0 N/A]	View the type code string for the option installed in slot A, and a translation of the type code string. For example, for type code string 'AX', the translation is 'No option'.

15-71 Slot A Option SW Version

Range:	Function:
0 N/A* [0 - 0 N/A]	View the software version for the option installed in slot A.

15-72 Option in Slot B

Range:	Function:
0 N/A* [0 - 0 N/A]	View the type code string for the option installed in slot B, and a translation of the type code string. For example, for type code string 'BX', the translation is 'No option'.

15-73 Slot B Option SW Version

Range:	Function:
0 N/A* [0 - 0 N/A]	View the software version for the option installed in slot B.

15-74 Option in Slot C0

Range:	Function:
0 N/A* [0 - 0 N/A]	View the type code string for the option installed in slot C, and a translation of the type code string. For example, for type code string 'CXXXX', the translation is 'No option'.

15-75 Slot C0 Option SW Version

Range:	Function:
0 N/A* [0 - 0 N/A]	View the software version for the option installed in slot C.

15-76 Option in Slot C1

Range:	Function:
0 N/A* [0 - 0 N/A]	Shows the typecode string for the options (CXXXX if no option) and the translation, e.g., >No option<.

15-77 Slot C1 Option SW Version

Range:	Function:
0 N/A* [0 - 0 N/A]	Software version for the installed option in option slot C.

15-9* Parameter Info

Parameter lists

15-92 Defined Parameters

Array [1000]

Range:	Function:
0 N/A* [0 - 9999 N/A]	View a list of all defined parameters in the adjustable frequency drive. The list ends with 0.

15-93 Modified Parameters

Array [1000]

Range:	Function:
0 N/A* [0 - 9999 N/A]	View a list of the parameters that have been changed from their default setting. The list ends with 0. Changes may not be visible until up to 30 seconds after implementation.

15-98 Drive Identification

Range:	Function:
0 N/A* [0 - 0 N/A]	

15-99 Parameter Metadata

Array [23]

Range:	Function:
0 N/A* [0 - 9999 N/A]	This parameter contains data used by the MCT10 software tool.

Main Menu - Data Readouts - Group 16

16-** Data Readouts

Parameter group for data readouts, such as current references, voltages, control, alarm, warning and status words.

16-0* General Status

Parameters for reading the general status, such as the calculated reference, the active control word and status.

16-00 Control Word

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the control word sent from the adjustable frequency drive via the serial communication port in hex code.

16-01 Reference [Unit]

Range:	Function:
0.000 [-999999.000 - 999999.000 Referen- ReferenceFeedbackUnit] ceFeed- backU- nit*	View the present reference value applied on impulse or analog basis in the unit resulting from the configuration selected in par.1-00 Configura- tion Mode (Hz, Nm or RPM).

16-02 Reference %

Range:	Function:
0.0 %* [-200.0 - 200.0 %]	

16-03 Status Word

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the status word sent from the adjustable frequency drive via the serial communication port in hex code.

16-05 Main Actual Value [%]

Range:	Function:
0.00 %* [-100.00 - 100.00 %]	View the two-byte word sent with the status word to the bus master reporting the main actual value.

16-09 Custom Readout

Range:	Function:
0.00 [-999999.99 - 999999.99 Custom- CustomReadoutUnit] Readou- tUnit*	View the user-defined readouts as defined in par.0-30 Custom Readout Unit , par.0-31 Custom Readout Min Value and par.0-32 Custom Readout Max Value .

16-1* Motor Status

Parameters for reading the motor status values.

16-10 Power [kW]

Range:

0.00 [0.00 - 10000.00 kW]
kW*

Function:

View the motor power in kW. The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered, and therefore approx. 30 ms may pass from when an input value changes to when the data readout values change.

16-11 Power [hp]

Range:

0.00 hp* [0.00 - 10000.00 hp]

Function:

View the motor power in HP. The value shown is calculated on the basis of the actual motor voltage and motor current. The value is filtered, and therefore approximately 30 ms may pass from when an input value changes to when the data readout values change.

16-12 Motor voltage

Range:

0.0 V* [0.0 - 6000.0 V]

Function:

View the motor voltage, a calculated value used for controlling the motor.

16-13 Frequency

Range:

0.0 Hz* [0.0 - 6500.0 Hz]

Function:

View the motor frequency, without resonance dampening.

16-14 Motor Current

Range:

0.00 A* [0.00 - 10000.00 A]

Function:

View the motor current measured as a mean value, IRMS. The value is filtered, and thus approximately 30 ms may pass from when an input value changes to when the data readout values change.

16-15 Frequency [%]

Range:

0.00 %* [-100.00 - 100.00 %]

Function:

16-16 Torque [Nm]

Range:

0.0 Nm* [-30000.0 - 30000.0 Nm]

Function:

View the torque value with sign, applied to the motor shaft. Linearity is not exact between 110% motor current and torque in relation to the rated torque. Some motors supply more than 160% torque. Consequently, the minimum and maximum values will depend on the maximum motor current, as well as the motor type being used. The value is filtered, and thus approx. 1.3 seconds may pass from when an input changes value to when the data readout values change.

16-17 Speed [RPM]

Range:

0 RPM* [-30000 - 30000 RPM]

Function:

View the current motor RPM.

16-18 Motor Thermal

Range:	Function:
0 %* [0 - 100 %]	View the calculated thermal load on the motor. The cut-out limit is 100%. The basis for calculation is the ETR function selected in par.1-90 Motor Thermal Protection .

16-22 Torque [%]

Range:	Function:
0 %* [-200 - 200 %]	This is a readout parameter only. Shows the actual torque yielded in percentage of the rated torque, based on the setting of the motor size and rated speed in par.1-20 Motor Power [kW] or par.1-21 Motor Power [HP] and par.1-25 Motor Nominal Speed . This is the value monitored by the <i>Broken Belt Function</i> set in par. 22-6*.

16-3* Drive Status

Parameters for reporting the status of the adjustable frequency drive.

16-30 DC Link Voltage

Range:	Function:
0 V* [0 - 10000 V]	View a measured value. The value is filtered with an 30 ms time constant.

16-32 Brake Energy /s

Range:	Function:
0.000 [0.000 - 10000.000 kW] kW*	View the braking energy transmitted to an external brake resistor, stated as an instantaneous value.

16-33 Brake Energy /2 min

Range:	Function:
0.000 [0.000 - 10000.000 kW] kW*	View the braking energy transmitted to an external brake resistor. The mean power is calculated on an average basis for the most recent 120 seconds.

16-34 Heatsink Temp.

Range:	Function:
0 C* [0 - 255 C]	

16-35 Inverter Thermal

Range:	Function:
0 %* [0 - 100 %]	View the percentage load on the inverter.

16-36 Inv. Nom. Current

Range:	Function:
Applica- [0.01 - 10000.00 A] tion de- pend- ent*	View the inverter nominal current, which should match the nameplate data on the connected motor. The data are used for calculation of torque, motor protection, etc.

16-37 Inv. Max. Current

Range:	Function:
Applica- [0.01 - 10000.00 A] tion de- pend- ent*	View the inverter maximum current, which should match the nameplate data on the connected motor. The data are used for calculation of torque, motor protection, etc.

16-38 SL Controller State

Range:	Function:
0 N/A* [0 - 100 N/A]	View the state of the event under execution by the SL controller.

16-39 Control Card Temp.

Range:	Function:
0 C* [0 - 100 C]	

16-40 Logging Buffer Full

Option:	Function:
	View whether the logging buffer is full (see parameter group 15-1*). The logging buffer will never be full when par.15-13 Logging Mode is set to <i>Log always</i> [0].

[0] * No

[1] Yes

16-49 Current Fault Source

Range:	Function:
0 N/A* [0 - 8 N/A]	Value indicates source of current fault, including: short circuit, overcurrent and phase imbalance (from left): [1-4] Inverter, [5-8] Rectifier, [0] No fault recorded

After a short circuit alarm (imax2) or over current alarm (imax1 or phase imbalance), this will contain the power card number associated with the alarm. It only holds one number so it will indicate the highest priority power card number (master first). The value will persist on power cycle but if a new alarm occurs it will be overwritten with the new power card number (even if it a lower priority number). The value will only be cleared when the alarm log is cleared (e.g., a 3-finger reset would reset the readout to 0).

16-5* Ref. & Feedb.

Parameters for reporting the reference and feedback input.

16-50 External Reference

Range:	Function:
0.0 N/A* [-200.0 - 200.0 N/A]	View the total reference, the sum of digital, analog, preset, bus and freeze references, plus catch-up and slow-down.

16-52 Feedback [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	View value of resulting feedback value after processing of Feedback 1-3 (see par.16-54 Feedback 1 [Unit] , par.16-55 Feedback 2 [Unit] and par. 16-56) in the feedback manager. See par. 20-0* <i>Feedback</i> . The value is limited by settings in par. 20-13 and par. 20-14. Units as set in par.20-12 Reference/Feedback Unit .

16-53 Digi Pot Reference

Range:	Function:
0.00 N/ [-200.00 - 200.00 N/A] A*	View the contribution of the digital potentiometer to the actual reference.

16-54 Feedback 1 [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	View value of Feedback 1, see par. 20-0* <i>Feedback</i> . The value is limited by settings in par.20-13 Minimum Reference/Feedb. and par.20-14 Maximum Reference/Feedb. . Units as set in par. 20-12 Reference/Feedback Unit .

16-55 Feedback 2 [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	View value of Feedback 2, see par. 20-0* <i>Feedback</i> . The value is limited by settings in par. 20-13 and par. 20-14. Units as set in par.20-12 Reference/Feedback Unit .

16-56 Feedback 3 [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	View value of Feedback 3, see parameter group 20-0* <i>Feedback</i> . The value is limited by settings in par.20-13 Minimum Reference/Feedb. and par.20-14 Maximum Reference/Feedb. . Units as set in par. 20-12 Reference/Feedback Unit .

16-58 PID Output [%]

Range:	Function:
0.0 %* [0.0 - 100.0 %]	


16-6* Inputs and Outputs

Parameters for reporting the digital and analog IO ports.

16-60 Digital Input

Range:	Function:
0 N/A* [0 - 1023 N/A]	View the signal states from the active digital inputs. Example: Input 18 corresponds to bit no. 5, '0' = no signal, '1' = connected signal. Bit 6 works in the opposite way, on = '0', off = '1' (safe stop input).

Bit 0	Digital input term. 33
Bit 1	Digital input term. 32
Bit 2	Digital input term. 29
Bit 3	Digital input term. 27
Bit 4	Digital input term. 19
Bit 5	Digital input term. 18
Bit 6	Digital input term. 37
Bit 7	Digital input GP I/O term. X30/4
Bit 8	Digital input GP I/O term. X30/3
Bit 9	Digital input GP I/O term. X30/2
Bit 10-63	Reserved for future terminals



130BA894.10

16-61 Terminal 53 Switch Setting

Option:

Function:

View the setting of input terminal 53. Current = 0; Voltage = 1.

[0] * Current

[1] Voltage

[2] Pt 1000 [°C]

[3] Pt 1000 [°F]

[4] Ni 1000 [°C]

[5] Ni 1000 [°F]

16-62 Analog Input 53

Range:

Function:

0.000 N/ [-20.000 - 20.000 N/A]

View the actual value at input 53.

A*

16-63 Terminal 54 Switch Setting

Option:	Function:
	View the setting of input terminal 54. Current = 0; Voltage = 1.

[0] *	Current
[1]	Voltage
[2]	Pt 1000 [°C]
[3]	Pt 1000 [°F]
[4]	Ni 1000 [°C]
[5]	Ni 1000 [°F]

16-64 Analog Input 54

Range:	Function:
0.000 N/ [-20.000 - 20.000 N/A] A*	View the actual value at input 54.

16-65 Analog Output 42 [mA]

Range:	Function:
0.000 N/ [0.000 - 30.000 N/A] A*	View the actual value at output 42 in mA. The value shown reflects the selection in par.6-50 Terminal 42 Output .

16-66 Digital Output [bin]

Range:	Function:
0 N/A* [0 - 15 N/A]	View the binary value of all digital outputs.

16-67 Pulse Input #29 [Hz]

Range:	Function:
0 N/A* [0 - 130000 N/A]	View the actual frequency rate on terminal 29.

16-68 Pulse Input #33 [Hz]

Range:	Function:
0 N/A* [0 - 130000 N/A]	View the actual value of the frequency applied at terminal 33 as an impulse input.

16-69 Pulse Output #27 [Hz]

Range:	Function:
0 N/A* [0 - 40000 N/A]	View the actual value of impulses applied to terminal 27 in digital output mode.

16-70 Pulse Output #29 [Hz]

Range:	Function:
0 N/A* [0 - 40000 N/A]	View the actual value of pulses to terminal 29 in digital output mode.


16-71 Relay Output [bin]

Range:

0 N/A* [0 - 511 N/A]

Function:

View the settings of all relays.



16-72 Counter A

Range:

0 N/A* [-2147483648 -
2147483647 N/A]

Function:

View the present value of Counter A. Counters are useful as comparator operands, see par.13-10 [Comparator Operand](#).

The value can be reset or changed either via digital inputs (parameter group 5-1*) or by using an SLC action (par.13-52 [SL Controller Action](#)).

16-73 Counter B

Range:

0 N/A* [-2147483648 -
2147483647 N/A]

Function:

View the present value of Counter B. Counters are useful as comparator operands (par.13-10 [Comparator Operand](#)).

The value can be reset or changed either via digital inputs (parameter group 5-1*) or by using an SLC action (par.13-52 [SL Controller Action](#)).

16-75 Analog In X30/11

Range:

0.000 N/ [-20.000 - 20.000 N/A]
A*

Function:

View the actual value at input X30/11 of MCB 101.

16-76 Analog In X30/12

Range:

0.000 N/ [-20.000 - 20.000 N/A]
A*

Function:

View the actual value at input X30/12 of MCB 101.

16-77 Analog Out X30/8 [mA]

Range:

0.000 N/ [0.000 - 30.000 N/A]
A*

Function:

View the actual value at input X30/8 in mA.



Parameter Description

16-8* Ser. Com. Bus & Adjustable Frequency Drive Port

Parameters for reporting the BUS references and control words.

16-80 Fieldbus CTW 1

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the two-byte control word (CTW) received from the bus master. Interpretation of the control word depends on the serial communication bus option installed and the control word profile selected in par. 8-10 Control Profile . For more information, refer to the relevant serial communication bus manual.

16-82 Fieldbus REF 1

Range:	Function:
0 N/A* [-200 - 200 N/A]	View the two-byte word sent with the control word form the bus master to set the reference value. For more information, refer to the relevant serial communication bus manual.

16-84 Comm. Option Status

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the extended serial communication bus comm. option status word. For more information, refer to the relevant serial communication bus manual.

16-85 FC Port CTW 1

Range:	Function:
0 N/A* [0 - 65535 N/A]	View the two-byte control word (CTW) received from the bus master. Interpretation of the control word depends on the serial communication bus option installed and the control word profile selected in par. 8-10 Control Profile .

16-86 FC Port REF 1

Range:	Function:
0 N/A* [-200 - 200 N/A]	View the two-byte status word (STW) sent to the bus master. Interpretation of the status word depends on the serial communication bus option installed and the control word profile selected in par. 8-10 Control Profile .

16-9* Diagnosis Readouts

Parameters displaying alarm, warning and extended status words.

16-90 Alarm Word

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	View the alarm word sent via the serial communication port in hex code.

16-91 Alarm word 2

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	View the alarm word 2 sent via the serial communication port in hex code.

16-92 Warning Word

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	View the warning word sent via the serial communication port in hex code.

16-93 Warning word 2

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	View the warning word 2 sent via the serial communication port in hex code.

16-94 Ext. Status Word

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	Returns the extended status word sent via the serial communication port in hex code.

16-95 Ext. Status Word 2

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	Returns the extended warning word 2 sent via the serial communication port in hex code.

16-96 Maintenance Word

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	Readout of the Preventive Maintenance Word. The bits reflect the status for the programmed preventive maintenance events in parameter group 23-1*. 13 bits represent combinations of all the possible items: • Bit 0: Motor bearings • Bit 1: Pump bearings • Bit 2: Fan bearings • Bit 3: Valve • Bit 4: Pressure transmitter • Bit 5: Flow transmitter • Bit 6: Temperature transmitter • Bit 7: Pump seals • Bit 8: Fan belt • Bit 9: Filter • Bit 10: Drive cooling fan • Bit 11: Drive system health check • Bit 12: Warranty • Bit 13: Maintenance Text 0

- Bit 14: Maintenance Text 1
- Bit 15: Maintenance Text 2
- Bit 16: Maintenance Text 3
- Bit 17: Maintenance Text 4

Position 4⇒	Valve	Fan bearings	Pump bearings	Motor bearings
Position 3 ⇒	Pump seals	Temperature transmitter	Flow transmitter	Pressure transmitter
Position 2 ⇒	Drive system health check	Drive cooling fan	Filter	Fan belt
Position 1⇒				Warranty
0 _{hex}	-	-	-	-
1 _{hex}	-	-	-	+
2 _{hex}	-	-	+	-
3 _{hex}	-	-	+	+
4 _{hex}	-	+	-	-
5 _{hex}	-	+	-	+
6 _{hex}	-	+	+	-
7 _{hex}	-	+	+	+
8 _{hex}	+	-	-	-
9 _{hex}	+	-	-	+
A _{hex}	+	-	+	-
B _{hex}	+	-	+	+
C _{hex}	+	+	-	-
D _{hex}	+	+	-	+
E _{hex}	+	+	+	-
F _{hex}	+	+	+	+

Example:

The Preventive Maintenance Word shows 040A_{hex}.

Position	1	2	3	4
hex value	0	4	0	A

The first digit 0 indicates that no items from the fourth row requires maintenance

The second digit 4 refers to the third row indicating that the drive cooling fan requires maintenance

The third digit 0 indicates that no items from the second row requires maintenance

The fourth digit A refers to the top row indicating that the valve and the pump bearings require maintenance

Main Menu - Data Readouts 2 - Group 18

18-0* Maintenance LogLG-0# Maintenance Log

This group contains the last ten preventive maintenance events. Maintenance Log 0 is the latest and Maintenance Log 9 the oldest.

By selecting one of the logs and pressing [OK], the Maintenance Item, Action and time of the occurrence can be found in par.18-00 [Maintenance Log: Item](#) – par.18-03 [Maintenance Log: Date and Time](#).

The alarm log button on the keypad allows access to both alarm log and maintenance log.

18-00 Maintenance Log: Item

Array [10]. Array parameter; Error code 0–9: The meaning of the error code can be found in the Troubleshooting section of the FC Design Guide.

Range:

Function:

0 N/A* [0 - 255 N/A]

Locate the meaning of the maintenance item in the description of par. 23-10 [Maintenance Item](#).

18-01 Maintenance Log: Action

Array [10]. Array parameter; Error code 0–9: The meaning of the error code can be found in the Troubleshooting section of the Design Guide.

Range:

Function:

0 N/A* [0 - 255 N/A]

Locate the meaning of the maintenance item in the description of par. 23-11 [Maintenance Action](#)

18-02 Maintenance Log: Time

Array [10]. Array parameter; Time 0–9: This parameter shows at which time the logged event occurred. Time is measured in seconds since start of the adjustable frequency drive.

Range:

Function:

0 s* [0 - 2147483647 s]

Shows when the logged event occurred. Time is measured in seconds since last power-up.

18-03 Maintenance Log: Date and Time

Array [10]

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE

When mounting an Analog I/O MCB 109 option card, a battery back-up of date and time is included.

18-1* Fire Mode Log

The log covers the latest 10 faults which have been suppressed by the fire mode function. See *par. 24-0*, Fire Mode*. The log can be viewed either via the below parameters or by pressing the Alarm Log button on the keypad and select Fire Mode Log. It is not possible to reset the fire mode log.

18-10 Fire Mode Log: Event

Range:	Function:
0 N/A* [0 - 255 N/A]	This parameter contains an array with 10 elements. The number read represents an error code, which corresponds to a specific alarm. This can be found in the Troubleshooting section in the Design Guide.

18-11 Fire Mode Log: Time

Range:	Function:
0 s* [0 - 2147483647 s]	This parameter contains an array with 10 elements. The parameter shows at which time the logged event occurred. Time is measured in seconds since the first start of the motor.

18-12 Fire Mode Log: Date and Time

Range:	Function:
Applica- tion de- pend- ent*	

18-5* Ref. & Feedb.

Parameters for reporting the reference and feedback input.

NOTE

Sensorless Readout requires set-up by MCT10 with sensorless specific plug-in.


Main Menu - Adjustable Frequency Drive Closed-loop - Group 20

20-** Adjustable Frequency Drive Closed-loop

This parameter group is used for configuring the closed-loop PID controller, that controls the output frequency of the adjustable frequency drive.

20-0* Feedback

This parameter group is used to configure the feedback signal for the adjustable frequency drive's closed-loop PID controller. Whether the adjustable frequency drive is in closed-loop mode or open-loop mode, the feedback signals can also be shown on the adjustable frequency drive's display, be used to control an adjustable frequency drive analog output, and be transmitted over various serial communication protocols.



20-00 Feedback 1 Source

Option:

Function:

Up to three different feedback signals can be used to provide the feedback signal for the adjustable frequency drive's PID controller. This parameter defines which input will be used as the source of the first feedback signal. Analog input X30/11 and Analog input X30/12 refer to inputs on the optional general purpose I/O board.

- [0] No function
- [1] Analog input 53
- [2] * Analog input 54
- [3] Pulse input 29
- [4] Pulse input 33
- [7] Analog input X30/11
- [8] Analog input X30/12
- [9] Analog Input X42/1
- [10] Analog Input X42/3

Parameter Description

[11]	Analog Input X42/5	
[100]	Bus feedback 1	
[101]	Bus feedback 2	
[102]	Bus feedback 3	
[104]	Sensorless Flow	Requires set up by MCT10 with sensorless specific plug in.
[105]	Sensorless Pressure	Requires set up by MCT10 with sensorless specific plug in.

NOTE: If a feedback is not used, its source must be set to *No Function* [0]. par.20-20 [Feedback Function](#) determines how the three possible feedbacks will be used by the PID controller.

20-01 Feedback 1 Conversion

Option:	Function:
	This parameter allows a conversion function to be applied to Feedback 1.
[0] * Linear	<i>Linear</i> [0] has no effect on the feedback.
[1] Square root	<i>Square root</i> [1] is commonly used when a pressure sensor is used to provide flow feedback ($(\text{flow} \propto \sqrt{\text{pressure}})$).
[2] Pressure to temperature	<i>Pressure to temperature</i> [2] is used in compressor applications to provide temperature feedback using a pressure sensor. The temperature of the refrigerant is calculated using the following formula: $\text{Temperature} = \frac{A2}{(\ln(Pe + 1) - A1)} - A3$ where A1, A2 and A3 are refrigerant-specific constants. The refrigerant must be selected in par. 20-30 Refrigerant. par.20-21 Setpoint 1 through par.20-23 Setpoint 3 allow the values of A1, A2 and A3 to be entered for a refrigerant that is not listed in par.20-30 Refrigerant.
[3]	
[4]	

20-02 Feedback 1 Source Unit

Option:	Function:
	This parameter determines the unit that is used for this feedback source, prior to applying the feedback conversion of par.20-01 Feedback 1 Conversion . This unit is not used by the PID controller.
[0] *	
[1] %	
[5] PPM	
[10] min	
[11] RPM	
[12] PULSE/s	
[20] liter / sec.	
[21] liter / min	
[22] liter / hr.	
[23] m ³ / sec.	
[24] m ³ /min	
[25] m ³ / hr.	

[30] kg / sec.

[31] kg/min

[32] kg / hr.

[33] ton / min

[34] ton / hr.

[40] m / sec.

[41] m/min

[45] m

[60] °C

[70] mbar

[71] bar

[72] Pa

[73] kPa

[74] m WG

[75] mm Hg

[80] kW

[120] GPM

[121] gal / sec.

[122] gal/min

[123] gal / hr.

[124] CFM

[125] ft³/s

[126] ft³/min

[127] ft³/h

[130] lbs / sec.

[131] lbs / min.

[132] lbs / hr.

[140] ft/s

[141] ft/min

[145] ft

[160] °F

[170] psi

[171] lb/in²

[172] in. wtr. gage

[173] ft WG

[174] in Hg

[180] HP

NOTE: This parameter is only available when using pressure to temperature feedback conversion.
If the choice Linear [0] is selected in par.20-01 [Feedback 1 Conversion](#), then the setting of any choice in par. 20-02 [Feedback 1 Source Unit](#) does not matter as conversion will be one-to-one.

20-03 Feedback 2 Source

Option:

Function:

See par.20-00 [Feedback 1 Source](#) for details.

- [0] * No function
- [1] Analog input 53
- [2] Analog input 54
- [3] Pulse input 29
- [4] Pulse input 33
- [7] Analog input X30/11
- [8] Analog input X30/12
- [9] Analog Input X42/1
- [10] Analog Input X42/3
- [11] Analog Input X42/5
- [100] Bus feedback 1
- [101] Bus feedback 2
- [102] Bus feedback 3

20-04 Feedback 2 Conversion

Option:

Function:

See par.20-01 [Feedback 1 Conversion](#) for details.

- [0] * Linear
- [1] Square root
- [2] Pressure to temperature
- [3]
- [4]

20-05 Feedback 2 Source Unit

Option:

Function:

- [0] *
- [1] %
- [5] PPM
- [10] min
- [11] RPM
- [12] PULSE/s
- [20] liter / sec.
- [21] liter / min
- [22] liter / hr.
- [23] m³ / sec.
- [24] m³/min
- [25] m³ / hr.
- [30] kg / sec.
- [31] kg/min
- [32] kg / hr.
- [33] ton / min

20-06 Feedback 3 Source

Option:	Function:
---------	-----------

Parameter Description

[10]	Analog Input X42/3
[11]	Analog Input X42/5
[100]	Bus feedback 1
[101]	Bus feedback 2
[102]	Bus feedback 3

20-07 Feedback 3 Conversion

Option:

Function:

See par.20-01 [Feedback 1 Conversion](#) for details.

[0] *	Linear
[1]	Square root
[2]	Pressure to temperature
[3]	
[4]	

20-08 Feedback 3 Source Unit

Option:

Function:

[0] *	
[1]	%
[5]	PPM
[10]	min
[11]	RPM
[12]	PULSE/s
[20]	liter / sec.
[21]	liter / min
[22]	liter / hr.
[23]	m ³ / sec.
[24]	m ³ /min
[25]	m ³ / hr.
[30]	kg / sec.
[31]	kg/min
[32]	kg / hr.
[33]	ton / min
[34]	ton / hr.
[40]	m / sec.
[41]	m/min
[45]	m
[60]	°C
[70]	mbar
[71]	bar
[72]	Pa
[73]	kPa
[74]	m WG
[75]	mm Hg

[80] kW

[120] GPM

[121] gal / sec.

[122] gal/min

[123] gal / hr.

[124] CFM

[125] ft³/s

[126] ft³/min

[127] ft³/h

[130] lbs / sec.

[131] lbs / min.

[132] lbs / hr.

[140] ft/s

[141] ft/min

[145] ft

[160] °F

[170] psi

[171] lb/in²

[172] in. wtr. gage

[173] ft WG

[174] in Hg

[180] HP

20-12 Reference/Feedback Unit

Option:

Function:

See par.20-02 [Feedback 1 Source Unit](#) for details.

20-13 Minimum Reference/Feedb.

Range:

Function:

0.000 [Application dependant]
Proc-
essCtrlU-
nit*

Enter the desired minimum value for the remote reference when operating with par.1-00 [Configuration Mode](#) set for Closed-loop [3] operation. Units are set in par.20-12 [Reference/Feedback Unit](#).

Minimum feedback will be -200% of either the value set in par. 20-13 [Minimum Reference/Feedb.](#) or in par.20-14 [Maximum Reference/Feedb.](#), which ever numeric value is the highest.

NOTE: If operating with par.1-00 [Configuration Mode](#) set for Open-loop [0], par.3-02 [Minimum Reference](#) must be used.

20-14 Maximum Reference/Feedb.

Range:

Function:

100.000 [Application dependant]
Proc-
essCtrlU-
nit*

Enter the maximum reference/feedback for closed-loop operation. The setting determines the highest value obtainable by summing all reference sources for closed-loop operation. The setting determines 100% feedback in open-loop and closed-loop (total feedback range: -200% to +200%).

NOTE: If operating with par.1-00 [Configuration Mode](#) set for Open-loop [0], par.3-03 [Maximum Reference](#) must be used.

20-2* Feedback & Setpoint

This parameter group is used to determine how the adjustable frequency drive's PID controller will use the three possible feedback signals to control the output frequency of the adjustable frequency drive. This group is also used to store the three internal setpoint references.

20-20 Feedback Function

Option:	Function:
	This parameter determines how the three possible feedbacks will be used to control the output frequency of the adjustable frequency drive.
[0] Sum	<i>Sum</i>[0] sets up the PID Controller to use the sum of Feedback 1, Feedback 2 and Feedback 3 as the feedback. NOTE: Any unused feedbacks must be set to <i>No Function</i> in par. 20-00 Feedback 1 Source, par.20-03 Feedback 2 Source, or par. 20-06 Feedback 3 Source. The sum of Setpoint 1 and any other references that are enabled (see par. group 3-1*) will be used as the PID Controller's setpoint reference.
[1] Difference	<i>Difference</i> [1] sets up the PID controller to use the difference between Feedback 1 and Feedback 2 as the feedback. Feedback 3 will not be used with this selection. Only Setpoint 1 will be used. The sum of Setpoint 1 and any other references that are enabled (see par. group 3-1*) will be used as the PID controller's setpoint reference.
[2] Average	<i>Average</i> [2] sets up the PID Controller to use the average of Feedback 1, Feedback 2 and Feedback 3 as the feedback. NOTE: Any unused feedbacks must be set to <i>No Function</i> in par. 20-00 Feedback 1 Source, par.20-03 Feedback 2 Source, or par. 20-06 Feedback 3 Source. The sum of Setpoint 1 and any other references that are enabled (see par. group 3-1*) will be used as the PID Controller's setpoint reference.
[3] * Minimum	<i>Minimum</i> [3] sets up the PID controller to compare Feedback 1, Feedback 2 and Feedback 3 and use the lowest value as the feedback. NOTE: Any unused feedbacks must be set to <i>No Function</i> in par. 20-00 Feedback 1 Source, par.20-03 Feedback 2 Source, or par. 20-06 Feedback 3 Source. Only setpoint 1 will be used. The sum of Setpoint 1 and any other references that are enabled (see par. group 3-1*) will be used as the PID controller's setpoint reference.
[4] Maximum	<i>Maximum</i> [4] sets up the PID controller to compare Feedback 1, Feedback 2 and Feedback 3 and use the highest value as the feedback. NOTE: Any unused feedbacks must be set to <i>No Function</i> in par. 20-00 Feedback 1 Source, par.20-03 Feedback 2 Source, or par. 20-06 Feedback 3 Source. Only Setpoint 1 will be used. The sum of Setpoint 1 and any other references that are enabled (see par. group 3-1*) will be used as the PID controller's setpoint reference.

[5]	Multi Setpoint Min	<i>Multi-setpoint minimum</i> [5] sets up the PID Controller to calculate the difference between Feedback 1 and Setpoint 1, Feedback 2 and Setpoint 2, and Feedback 3 and Setpoint 3. It will use the feedback/setpoint pair in which the feedback is the farthest below its corresponding setpoint reference. If all feedback signals are above their corresponding setpoints, the PID Controller will use the feedback/setpoint pair in which the difference between the feedback and setpoint is the least. NOTE: If only two feedback signals are used, the feedback that is not to be used must be set to <i>No Function</i> in par.20-00 Feedback 1 Source, par. 20-03 Feedback 2 Source or par.20-06 Feedback 3 Source. Note that each setpoint reference will be the sum of its respective parameter value (par. 20-21 Setpoint 1, par.20-22 Setpoint 2 and par.20-23 Setpoint 3) and any other references that are enabled (see par. group 3-1*).
[6]	Multi Setpoint Max	<i>Multi-setpoint maximum</i> [6] sets up the PID Controller to calculate the difference between Feedback 1 and Setpoint 1, Feedback 2 and Setpoint 2, and Feedback 3 and Setpoint 3. It will use the feedback/setpoint pair in which the feedback is farthest above its corresponding setpoint reference. If all feedback signals are below their corresponding setpoints, the PID Controller will use the feedback/setpoint pair in which the difference between the feedback and the setpoint reference is the least. NOTE: If only two feedback signals are used, the feedback that is not to be used must be set to <i>No Function</i> in par.20-00 Feedback 1 Source, par. 20-03 Feedback 2 Source or par.20-06 Feedback 3 Source. Note that each setpoint reference will be the sum of its respective parameter value (par. 20-21 Setpoint 1, par.20-22 Setpoint 2 and par.20-23 Setpoint 3) and any other references that are enabled (see par. group 3-1*).

NOTE: Any unused feedback must be set to “No function” in its Feedback Source parameter: par.20-00 [Feedback 1 Source](#), par.20-03 [Feedback 2 Source](#) or par.20-06 [Feedback 3 Source](#).

The feedback resulting from the function selected in par.20-20 [Feedback Function](#) will be used by the PID controller to control the output frequency of the adjustable frequency drive. This feedback can also be shown on the adjustable frequency drive’s display, be used to control an adjustable frequency drive's analog output, and be transmitted over various serial communication protocols.


The adjustable frequency drive can be configured to handle multi-zone applications. Two different multi-zone applications are supported:

- Multi-zone, single setpoint
- Multi-zone, multi setpoint

The difference between the two is illustrated by the following examples:

Example 1: Multi-zone, single setpoint

In an office building, a VAV (variable air volume) TR200 system must ensure a minimum pressure at selected VAV boxes. Due to the varying pressure losses in each duct, the pressure at each VAV box cannot be assumed to be the same. The minimum pressure required is the same for all VAV boxes. This control method can be set up by setting par.20-20 [Feedback Function](#) to option [3], Minimum, and entering the desired pressure in par. 20-21 [Setpoint 1](#). The PID controller will increase the speed of the fan if any one feedback is below the setpoint, and decrease the speed of the fan if all feedbacks are above the setpoint.



Example 2: Multi-zone, multi setpoint

The previous example can be used to illustrate the use of multi-zone, multi-setpoint control. If the zones require different pressures for each VAV box, each setpoint may be specified in par.20-21 [Setpoint 1](#), par.20-22 [Setpoint 2](#) and par.20-23 [Setpoint 3](#). By selecting *Multi-setpoint minimum*, [5], in par.20-20 [Feedback Function](#), the PID controller will increase the speed of the fan if any one of the feedbacks is below its setpoint and decrease the speed of the fan if all feedbacks are above their individual setpoints.

20-21 Setpoint 1

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	Setpoint 1 is used in closed-loop mode to enter a setpoint reference that is used by the adjustable frequency drive's PID controller. See the description of par.20-20 Feedback Function . NOTE: Setpoint reference entered here is added to any other references that are enabled (see par. group 3-1*).

20-22 Setpoint 2

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	Setpoint 2 is used in closed-loop mode to enter a setpoint reference that may be used by the adjustable frequency drive's PID controller. See the description of <i>Feedback Function</i> , par.20-20 Feedback Function .

NOTE: The setpoint reference entered here is added to any other references that are enabled (see par. group 3-1*).

20-23 Setpoint 3

Range:	Function:
0.000 [-999999.999 - 999999.999] Proc- ProcessCtrlUnit] essCtrlU- nit*	Setpoint 3 is used in closed-loop mode to enter a setpoint reference that may be used by the adjustable frequency drive's PID controller. See the description of par.20-20 Feedback Function . NOTE The setpoint reference entered here is added to any other references that are enabled (see par. group 3-1*).

20-3* Feedback Adv. Conversion

In air conditioning compressor applications it is often useful to control the system based on the temperature of the refrigerant. However, it is generally more convenient to directly measure its pressure. This parameter group allows the adjustable frequency drive's PID controller to convert refrigerant pressure measurements into temperature values.

20-30 Refrigerant

Option:

Function:

Select the refrigerant used in the compressor application. This parameter must be specified correctly for the pressure to temperature conversion to be accurate. If the refrigerant used is not listed in choices [0] through [6], select *User defined* [7], use par.20-31 [User-defined Refrigerant A1](#), par.20-32 [User-defined Refrigerant A2](#) and par.20-33 [User-defined Refrigerant A3](#) to provide A1, A2 and A3 for the equation below:

$$Temperature = \frac{A2}{(\ln(Pe + 1) - A1)} - A3$$

[0] * R22

[1] R134a

[2] R404a

[3] R407c

[4] R410a

[5] R502

[6] R744

[7] User-defined

20-31 User-defined Refrigerant A1

Range:

Function:

10.0000 [8.0000 - 12.0000 N/A]
N/A*

Use this parameter to enter the value of coefficient A1 when par. 20-30 [Refrigerant](#) is set to *User-defined* [7].

20-32 User-defined Refrigerant A2

Range:

Function:

-2250.00 [-3000.00 - -1500.00 N/A]
N/A*

Use this parameter to enter the value of coefficient A2 when par. 20-30 [Refrigerant](#) is set to *User-defined* [7].

20-33 User-defined Refrigerant A3

Range:

Function:

250.000 [200.000 - 300.000 N/A]
N/A*

Use this parameter to enter the value of coefficient A3 when par. 20-30 [Refrigerant](#) is set to *User-defined* [7].



Parameter Description

Sets the area of the air duct at measuring point.

20-34 Fan 1 Area [m2]

Range: Function:

0.500 [0.000 - 10.000 m2]
m2*

NOTE

Units of measurement depend on the setting of **par. 0-03 Regional Settings**.

Sets the area of the air duct at measuring point.

20-35 Fan 1 Area [in2]

Range: Function:

750 in2* [0 - 15000 in2]

NOTE

Units of measurement depend on the setting of **par. 0-03 Regional Settings**.

Sets the area of the air duct at measuring point.

20-36 Fan 2 Area [m2]

Range: Function:

0.500 [0.000 - 10.000 m2]
m2*

NOTE

Units of measurement depend on the setting of **par. 0-03 Regional Settings**.

Sets the area of the air duct at measuring point.

20-37 Fan 2 Area [in2]

Range: Function:

750 in2* [0 - 15000 in2]

NOTE

Units of measurement depend on the setting of **par. 0-03 Regional Settings**.

Adjusts the density of the air in % of the normalized air density (1.2 kg/m³).

20-38 Air Density Factor [%]

Range: Function:

100 %* [50 - 150 %]

20-6* Sensorless

Parameters for Sensorless. See also par.20-00 [Feedback 1 Source](#), par.18-50 [Sensorless Readout \[unit\]](#), par.16-26 [Power Filtered \[kW\]](#) and par.16-27 [Power Filtered \[hp\]](#).

NOTE

Sensorless unit and Sensorless Information requires set-up by MCT10 with sensorless specific plug-in.

20-7* PID autotuning

The adjustable frequency drive PID closed-loop controller (parameters 20-**, Adjustable Frequency Drive Closed-loop) can be autotuned, simplifying and saving time during commissioning, while ensuring accurate PID control adjustment. To use autotuning, it is necessary for the adjustable frequency drive to be configured for closed-loop in par.1-00 [Configuration Mode](#).

A Graphical Local Control Panel (keypad) must be used in order to react on messages during the autotuning sequence.

Enabling par.20-79 [PID Autotuning](#), puts the adjustable frequency drive into autotuning mode. The keypad then directs the user with on-screen instructions.

The fan/pump is started by pressing [Auto On] button on the keypad and applying a start signal. The speed is adjusted manually by pressing the [▲] or [▼] navigation keys on the keypad to a level where the feedback is around the system setpoint.

NOTE

It is not possible to run the motor at maximum or minimum speed, when manually adjusting the motor speed due to the need of giving the motor a step in the speed during autotuning.

PID autotuning functions by introducing step changes while operating at a steady state and then monitoring the feedback. From the feedback response, the required values for par.20-93 [PID Proportional Gain](#) and par.20-94 [PID Integral Time](#) are calculated. par.20-95 [PID Differentiation Time](#) is set to value 0 (zero). par.20-81 [PID Normal/ Inverse Control](#) is determined during the tuning process.

These calculated values are presented on the keypad and the user can decide whether to accept or reject them. Once accepted, the values are written to the relevant parameters and autotuning mode is disabled in par.20-79 [PID Autotuning](#). Depending on the system being controlled, the time required to carry out autotuning could be several minutes.

It is advised to set the ramp times in par.3-41 [Ramp 1 Ramp-up Time](#), par.3-42 [Ramp 1 Ramp-down Time](#) or par.3-51 [Ramp 2 Ramp-up Time](#) and par.3-52 [Ramp 2 Ramp-down Time](#) according to the load inertia before carrying out PID autotuning. If PID autotuning is carried out with slow ramp times, the autotuned parameters will typically result in very slow control. Excessive feedback sensor noise should be removed using the input filter (parameter groups 6-** and 5-5*, Terminal 53/54 Filter Time Constant/Pulse Filter Time Constant #29/33) before activating PID autotuning. In order to obtain the most accurate controller parameters, it is advised to carry out PID autotuning when the application is running in typical operation, i.e., with a typical load.

20-70 Closed-loop Type

Option:

Function:

This parameter defines the application response. The default mode should be sufficient for most applications. If the application response speed is known, it can be selected here. This will decrease the time needed for carrying out PID autotuning. The setting has no impact on the value of the tuned parameters and is used only for the autotuning sequence.

- [0] * Auto
- [1] Fast Pressure
- [2] Slow Pressure
- [3] Fast Temperature
- [4] Slow Temperature

20-71 PID Performance

Option:

Function:

- [0] * Normal Normal setting of this parameter will be suitable for pressure control in fan systems.
- [1] Fast Fast setting would generally be used in pumping systems, where a faster control response is desirable.

20-72 PID Output Change

Range:

Function:

0.10 N/ [0.01 - 0.50 N/A]
A*

This parameter sets the magnitude of step change during autotuning. The value is a percentage of full speed. This means that if the maximum output frequency in par.4-13 [Motor Speed High Limit \[RPM\]](#)/par.4-14 [Motor Speed High Limit \[Hz\]](#) is set to 50 Hz, 0.10 is 10% of 50 Hz, which is 5 Hz. This parameter should be set to a value resulting in feedback changes of between 10% and 20% for best tuning accuracy.

20-73 Minimum Feedback Level

Range:

Function:

-999999. [Application dependant]
000
Proc-
essCtrlU-
nit*

The minimum allowable feedback level should be entered here in user units as defined in par.20-12 [Reference/Feedback Unit](#). If the level falls below par.20-73 [Minimum Feedback Level](#), autotuning is aborted and an error message will appear on the keypad.

20-74 Maximum Feedback Level

Range:

Function:

999999. [Application dependant]
000
Proc-
essCtrlU-
nit*

The maximum allowable feedback level should be entered here in user units as defined in par.20-12 [Reference/Feedback Unit](#). If the level rises above par.20-74 [Maximum Feedback Level](#), autotuning is aborted and an error message will appear on the keypad.

20-79 PID Autotuning

Option:

Function:

This parameter starts the PID autotuning sequence. Once the autotuning has successfully completed and the settings have been accepted or rejected by the user, by pressing [OK] or [Cancel] buttons on the keypad at the end of tuning, this parameter is reset to [0] Disabled.

[0] * Disabled

[1] Enabled

20-8* PID Basic Settings

This parameter group is used to configure the basic operation of the adjustable frequency drive's PID controller, including how it responds to a feedback that is above or below the setpoint, the speed at which it first starts functioning, and when it will indicate that the system has reached the setpoint.

20-81 PID Normal/ Inverse Control

Option:

Function:

[0] * Normal

Normal [0] causes the adjustable frequency drive's output frequency to decrease when the feedback is greater than the setpoint reference. This is common for pressure-controlled supply fan and pump applications.

[1] Inverse

Inverse [1] causes the adjustable frequency drive's output frequency to increase when the feedback is greater than the setpoint reference. This is common for temperature-controlled cooling applications, such as cooling towers.

20-82 PID Start Speed [RPM]

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

20-83 PID Start Speed [Hz]

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

20-84 On Reference Bandwidth

Range:

Function:

5 %* [0 - 200 %]

When the difference between the feedback and the setpoint reference is less than the value of this parameter, the adjustable frequency drive's display will show "Run on Reference". This status can be communicated externally by programming the function of a digital output for *Run on Reference/No Warning* [8]. In addition, for serial communications, the On Reference status bit of the adjustable frequency drive's status word will be high (1).

The *On Reference Bandwidth* is calculated as a percentage of the setpoint reference.

20-9* PID Controller

This group provides the ability to manually adjust this PID controller. By adjusting the PID controller parameters the control performance may be improved. See section **PID** in the TR200 Design Guide, *MG.11.Bx.yy* for guidelines on adjusting the PID controller parameters.

20-91 PID Anti Windup

Option:	Function:
[0] Off	<i>Off</i> [0] The integrator will continue to change value also after output has reached one of the extremes. This can afterwards cause a delay of change of the output of the controller.
[1] * On	<i>On</i> [1] The integrator will be locked if the output of the built-in PID controller has reached one of the extremes (min or max value) and therefore not able to add further change to the value of the process parameter controlled. This allows the controller to respond more quickly when it again can control the system.

20-93 PID Proportional Gain

Range:	Function:
0.50 N/ A* [0.00 - 10.00 N/A]	

If (Error x Gain) jumps with a value equal to what is set in par.20-14 [Maximum Reference/Feedb.](#), the PID controller will try to change the output speed equal to what is set in par.4-13 [Motor Speed High Limit \[RPM\]](#)/par. 4-14 [Motor Speed High Limit \[Hz\]](#) but in practice of course limited by this setting.

The proportional band (error causing output to change from 0–100%) can be calculated by means of the formula:

$$\left(\frac{1}{\text{Proportional Gain}} \right) \times (\text{Max Reference})$$

NOTE: Always set the desired for par.20-14 [Maximum Reference/Feedb.](#) before setting the values for the PID controller in par. group 20-9*.

20-94 PID Integral Time

Range:	Function:
20.00 s* [0.01 - 10000.00 s]	Over time, the integrator accumulates a contribution to the output from the PID controller as long as there is a deviation between the reference/setpoint and feedback signals. The contribution is proportional to the size of the deviation. This ensures that the deviation (error) approaches zero. Quick response on any deviation is obtained when the integral time is set to a low value. Setting it too low, however, may cause the control to become unstable. The value set is the time needed for the integrator to add the same contribution as the proportional part for a certain deviation. If the value is set to 10,000, the controller will act as a pure proportional controller with a P-band based on the value set in par.20-93 PID Proportional Gain. When no deviation is present, the output from the proportional controller will be 0.

20-95 PID Differentiation Time

Range:

0.00 s* [0.00 - 10.00 s]

Function:

The differentiator monitors the rate of change of the feedback. If the feedback is changing quickly, it will adjust the output of the PID controller to reduce the rate of change of the feedback. Quick PID controller response is obtained when this value is large. However, if too large of a value is used, the adjustable frequency drive's output frequency may become unstable.

Differentiation time is useful in situations where extremely fast adjustable frequency drive response and precise speed control are required. It can be difficult to adjust this for proper system control. Differentiation time is not commonly used in TR200 applications. Therefore, it is generally best to leave this parameter at 0 or OFF.

20-96 PID Diff. Gain Limit

Range:

5.0 N/A* [1.0 - 50.0 N/A]

Function:

The differential function of a PID controller responds to the rate of change of the feedback. As a result, an abrupt change in the feedback can cause the differential function to make a very large change in the PID controller's output. This parameter limits the maximum effect that the PID controller's differential function can produce. A smaller value reduces the maximum effect of the PID controller's differential function.

This parameter is only active when par.20-95 [PID Differentiation Time](#) is not set to OFF (0 s).

Main Menu - Extended Closed-loop - TR200 - Group 21

21-** Ext. Closed-loop

The TR200 offers 3 extended closed-loop PID controllers in addition to the PID controller. These can be configured independently to control either external servos (valves, dampers, etc.) or be used together with the internal PID controller to improve the dynamic responses to setpoint changes or load disturbances.

The extended closed-loop PID controllers may be interconnected or connected to the PID closed-loop controller to form a dual loop configuration.

In order to control a modulating device (e.g., a valve motor), this device must be a positioning servo motor with built-in electronics accepting either a 0–10 V (signal from Analog I/O card MCB 115) or a 0/4–20 mA (signal from control card and/or General Purpose I/O card MCB 101) control signal.

The output function can be programmed in the following parameters:

- Control Card, terminal 42: par.6-50 [Terminal 42 Output](#) (setting [113]...[115] or [149]...[151], Ext. Closed-loop 1/2/3
- General Purpose I/O card MCB 101, terminal X30/8: par.6-60 [Terminal X30/8 Output](#), (setting [113]...[115] or [149]...[151], Ext. Closed-loop 1/2/3

General Purpose I/O card and Analog I/O card are optional cards.

21-0* Extended CL autotuning

The extended PID closed-loop PID controllers (*parameter group 21-**, Ext. Closed-loop*) can each be auto-tuned, simplifying and saving time during commissioning, while ensuring accurate PID control adjustment.

To use PID autotuning, it is necessary for the relevant extended PID controller to have been configured for the application.

A graphical Local Control Panel (keypad) must be used in order to react on messages during the autotuning sequence.

Enabling autotuning par.21-09 [PID Autotuning](#) puts the relevant PID controller into PID autotuning mode. The keypad then directs the user with on-screen instructions.

PID autotuning functions by introducing step changes and then monitoring the feedback. From the feedback response, the required values for PID Proportional Gain, par.21-21 [Ext. 1 Proportional Gain](#) for EXT CL 1, par. 21-41 [Ext. 2 Proportional Gain](#) for EXT CL 2 and par.21-61 [Ext. 3 Proportional Gain](#) for EXT CL 3 and Integral Time, par.21-22 [Ext. 1 Integral Time](#) for EXT CL 1, par.21-42 [Ext. 2 Integral Time](#) for EXT CL 2 and par.21-62 [Ext. 3 Integral Time](#) for EXT CL 3 are calculated. PID Differentiation Time, par.21-23 [Ext. 1 Differentiation Time](#) for EXT CL 1, par.21-43 [Ext. 2 Differentiation Time](#) for EXT CL 2 and par.21-63 [Ext. 3 Differentiation Time](#) for EXT CL 3 are set to value 0 (zero). Normal / Inverse, par.21-20 [Ext. 1 Normal/Inverse Control](#) for EXT CL 1, par.21-40 [Ext. 2 Normal/Inverse Control](#) for EXT CL 2 and par.21-60 [Ext. 3 Normal/Inverse Control](#) for EXT CL 3 are determined during the tuning process.

These calculated values are presented on the keypad and the user can decide whether to accept or reject them. Once accepted, the values are written to the relevant parameters and PID autotuning mode is disabled in par. 21-09 [PID Autotuning](#). Depending on the system being controlled the time required to carry out PID autotuning could be several minutes.

Excessive feedback sensor noise should be removed using the input filter (parameter groups 6-** and 5-5*, Terminal 53/54 Filter Time Constant/Pulse Filter Time Constant #29/33) before activating PID autotuning.

21-00 Closed-loop Type

Option:

Function:

This parameter defines the application response. The default mode should be sufficient for most applications. If the relative application speed is known, it can be selected here. This will decrease the time needed for carrying out PID autotuning. The setting has no impact on the value of the tuned parameters and is used only for the PID autotuning sequence.

- | | |
|-------|------------------|
| [0] * | Auto |
| [1] | Fast Pressure |
| [2] | Slow Pressure |
| [3] | Fast Temperature |
| [4] | Slow Temperature |

21-01 PID Performance

Option:	Function:
[0] * Normal	Normal setting of this parameter will be suitable for pressure control in fan systems.
[1] Fast	Fast setting would generally be used in pumping systems, where a faster control response is desirable.

21-02 PID Output Change

Range:	Function:
0.10 N/ [0.01 - 0.50 N/A] A*	This parameter sets the magnitude of step change during autotuning. The value is a percentage of full operating range. This means that if maximum analog output voltage is set to 10 V, 0.10 is 10% of 10 V, which is 1 V. This parameter should be set to a value resulting in feedback changes of between 10% and 20% for best tuning accuracy.

21-03 Minimum Feedback Level

Range:	Function:
-999999. [Application dependant] 000 N/ A*	The minimum allowable feedback level should be entered here in user units as defined in par.21-10 Ext. 1 Ref./Feedback Unit for EXT CL 1, par. 21-30 Ext. 2 Ref./Feedback Unit for EXT CL 2 or par.21-50 Ext. 3 Ref./Feedback Unit for EXT CL 3. If the level falls below par.21-03 Minimum Feedback Level , PID autotuning is aborted and an error message will appear on the keypad.

21-04 Maximum Feedback Level


Range:	Function:
999999. [Application dependant] 000 N/ A*	The maximum allowable feedback level should be entered here in user units as defined in par.21-10 Ext. 1 Ref./Feedback Unit for EXT CL 1, par. 21-30 Ext. 2 Ref./Feedback Unit for EXT CL 2 or par.21-50 Ext. 3 Ref./Feedback Unit for EXT CL 3. If the level rises above par.21-04 Maximum Feedback Level , PID autotuning is aborted and an error message will appear on the keypad.

21-09 PID Autotuning

Option:	Function:
[0] * Disabled	This parameter enables selection of the extended PID controller to be autotuned and starts the PID autotuning for that controller. Once the autotuning has successfully completed and the settings have been accepted or rejected by the user, by pressing [OK] or [Cancel] buttons on the keypad at the end of tuning, this parameter is reset to [0] Disabled.
[1] Enabled Ext CL 1 PID	
[2] Enabled Ext CL 2 PID	
[3] Enabled Ext CL 3 PID	

21-1* Closed-loop 1 Ref/Feedback

Configure Extended Closed-loop 1 Controller reference and feedback.



21-10 Ext. 1 Ref./Feedback Unit

Option:

Function:

Select the unit for the reference and feedback.

[0]

[1] * %

[5] PPM

[10] min

[11] RPM

[12] PULSE/s

[20] liter / sec.

[21] liter / min

[22] liter / hr.

[23] m³ / sec.

[24] m³/min

[25] m³ / hr.

[30] kg / sec.

[31] kg/min

[32] kg / hr.

[33] ton / min

[34] ton / hr.

[40] m / sec.

[41] m/min

[45] m

[60] °C

[70] mbar

[71] bar

[72] Pa

[73] kPa

[74] m WG

[75] mm Hg

21-11 Ext. 1 Minimum Reference

21-12 Ext. 1 Maximum Reference

4-173

21-13 Ext. 1 Reference Source

Option:

Function:

This parameter defines which input on the adjustable frequency drive should be treated as the source of the reference signal for the closed-loop 1 controller. Analog input X30/11 and Analog input X30/12 refer to inputs on the General Purpose I/O.

- [0] * No function
- [1] Analog input 53
- [2] Analog input 54
- [7] Pulse input 29
- [8] Pulse input 33
- [20] Digital pot.meter
- [21] Analog input X30/11
- [22] Analog input X30/12
- [23] Analog Input X42/1
- [24] Analog Input X42/3
- [25] Analog Input X42/5
- [30] Ext. Closed-loop 1
- [31] Ext. Closed-loop 2
- [32] Ext. Closed-loop 3

21-14 Ext. 1 Feedback Source

Option:

Function:

This parameter defines which input on the adjustable frequency drive should be treated as the source of the feedback signal for the closed-loop 1 controller. Analog input X30/11 and Analog input X30/12 refer to inputs on the General Purpose I/O .

- [0] * No function
- [1] Analog input 53
- [2] Analog input 54
- [3] Pulse input 29
- [4] Pulse input 33
- [7] Analog input X30/11
- [8] Analog input X30/12
- [9] Analog Input X42/1
- [10] Analog Input X42/3
- [11] Analog Input X42/5
- [100] Bus feedback 1
- [101] Bus feedback 2
- [102] Bus feedback 3

21-15 Ext. 1 Setpoint

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID1Unit] tPID1Un it*	The setpoint reference is used in extended 1 closed-loop. Ext.1 Setpoint is added to the value from the Ext.1 Reference source selected in par. 21-13 Ext. 1 Reference Source .

21-17 Ext. 1 Reference [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID1Unit] tPID1Un it*	Readout of the reference value for the closed-loop 1 controller.

21-18 Ext. 1 Feedback [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID1Unit] tPID1Un it*	Readout of the feedback value for the closed-loop 1 controller.

21-19 Ext. 1 Output [%]

Range:	Function:
0 %* [0 - 100 %]	Readout of the output value for the closed-loop 1 controller.

21-2* Closed-loop 1 PID

Configure the closed-loop 1 PID controller.

21-20 Ext. 1 Normal/Inverse Control

Option:	Function:
[0] * Normal	Select <i>Normal</i> [0] if the output should be reduced when feedback is higher than the reference.
[1] Inverse	Select <i>Inverse</i> [1] if the output should be increased when feedback is higher than the reference.

21-21 Ext. 1 Proportional Gain

Range:	Function:
0.01 N/ [0.00 - 10.00 N/A] A*	

If (Error x Gain) jumps with a value equal to what is set in par.20-14 [Maximum Reference/Feedb.](#), the PID controller will try to change the output speed equal to what is set in par. 4-13/4-14, Motor Speed High Limit, but in practice of course limited by this setting.

The proportional band (error causing output to change from 0%–100%) can be calculated by means of the formula:

$$\left(\frac{1}{\text{Proportional Gain}} \right) \times (\text{Max Reference})$$

NOTE

Always set the desired for par.20-14 [Maximum Reference/Feedb.](#) before setting the values for the PID controller in par. group 20-9*.

21-22 Ext. 1 Integral Time

Range:	Function:
10000.0 [0.01 - 10000.00 s] 0 s*	Over time, the integrator accumulates a contribution to the output from the PID controller as long as there is a deviation between the reference/setpoint and feedback signals. The contribution is proportional to the size of the deviation. This ensures that the deviation (error) approaches zero. Quick response on any deviation is obtained when the integral time is set to a low value. Setting it too low, however, may cause the control to become unstable. The value set is the time needed for the integrator to add the same contribution as the proportional part for a certain deviation. If the value is set to 10,000, the controller will act as a pure proportional controller with a P-band based on the value set in par.20-93 PID Proportional Gain. When no deviation is present, the output from the proportional controller will be 0.

21-23 Ext. 1 Differentiation Time

Range:	Function:
0.00 s* [0.00 - 10.00 s]	The differentiator does not react to a constant error. It only provides a gain when the feedback changes. The quicker the feedback changes, the stronger the gain from the differentiator.

21-24 Ext. 1 Dif. Gain Limit

Range:	Function:
5.0 N/A* [1.0 - 50.0 N/A]	Set a limit for the differentiator gain (DG). The DG will increase if there are fast changes. Limit the DG to obtain a pure differentiator gain at slow changes and a constant differentiator gain where quick changes occur.

21-3* Closed-loop 2 Ref/Fb

Configure Extended Closed-loop 2 Controller reference and feedback.

21-30 Ext. 2 Ref./Feedback Unit

Option:	Function:
	See par.21-10 Ext. 1 Ref./Feedback Unit for details
[0]	
[1] *	%
[5]	PPM
[10]	min
[11]	RPM
[12]	PULSE/s
[20]	liter / sec.
[21]	liter / min

[22] liter / hr.

[23] m³ / sec.

[24] m³/min

[25] m³ / hr.

[30] kg / sec.

[31] kg/min

[32] kg / hr.

[33] ton / min

[34] ton / hr.

[40] m / sec.

[41] m/min

[45] m

[60] °C

[70] mbar

[71] bar

[72] Pa

[73] kPa

[74] m WG

[75] mm Hg

[80] kW

[120] GPM

[121] gal / sec.

[122] gal/min

[123] gal / hr.

[124] CFM

[125] ft³/s

[126] ft³/min

[127] ft³/h

[130] lbs / sec.

[131] lbs / min.

[132] lbs / hr.

[140] ft/s

[141] ft/min

[145] ft

[160] °F

[170] psi

[171] lb/in²

[172] in. wtr. gage

[173] ft WG

[174] in Hg

[180] HP

21-31 Ext. 2 Minimum Reference

Range:

0.000 [Application dependant]

Ex-
tPID2Un
it*

Function:

See par.21-11 [Ext. 1 Minimum Reference](#) for details.

21-32 Ext. 2 Maximum Reference

Range:

100.000 [Application dependant]

Ex-
tPID2Un
it*

Function:

See par.21-12 [Ext. 1 Maximum Reference](#) for details.

21-33 Ext. 2 Reference Source

Option:

Function:

See par.21-13 [Ext. 1 Reference Source](#) for details.

[0] * No function

[1] Analog input 53

[2] Analog input 54

[7] Pulse input 29

[8] Pulse input 33

[20] Digital pot.meter

[21] Analog input X30/11

[22] Analog input X30/12

[23] Analog Input X42/1

[24] Analog Input X42/3

[25] Analog Input X42/5

[30] Ext. Closed-loop 1

[31] Ext. Closed-loop 2

[32] Ext. Closed-loop 3

21-34 Ext. 2 Feedback Source

Option:

Function:

See par.21-14 [Ext. 1 Feedback Source](#) for details.

[0] * No function

[1] Analog input 53

[2] Analog input 54

[3] Pulse input 29

[4] Pulse input 33

[7] Analog input X30/11

[8] Analog input X30/12

[9] Analog Input X42/1

[10] Analog Input X42/3

[11] Analog Input X42/5

[100] Bus feedback 1

[101] Bus feedback 2

[102] Bus feedback 3

21-35 Ext. 2 Setpoint

Range:

Function:

0.000 [-999999.999 - 999999.999 See par.21-15 [Ext. 1 Setpoint](#) for details.

Ex- ExtPID2Unit]

tPID2Un

it*

21-37 Ext. 2 Reference [Unit]

Range:

Function:

0.000 [-999999.999 - 999999.999 See par.21-17 [Ext. 1 Reference \[Unit\]](#), *Ext. 1 Reference [Unit]*, for details.

Ex- ExtPID2Unit]

tPID2Un

it*

21-38 Ext. 2 Feedback [Unit]

Range:

Function:

0.000 [-999999.999 - 999999.999 See par.21-18 [Ext. 1 Feedback \[Unit\]](#) for details.

Ex- ExtPID2Unit]

tPID2Un

it*

21-39 Ext. 2 Output [%]

Range:

Function:

0 %* [0 - 100 %] See par.21-19 [Ext. 1 Output \[%\]](#) for details.

21-4* Closed-loop 2 PID

Configure the Closed-loop 2 PID controller.

21-40 Ext. 2 Normal/Inverse Control

Option:

Function:

See par.21-20 [Ext. 1 Normal/Inverse Control](#) for details.

[0] * Normal

[1] Inverse

21-41 Ext. 2 Proportional Gain

Range:

Function:

0.01 N/A* [0.00 - 10.00 N/A]

See par.21-21 [Ext. 1 Proportional Gain](#) for details.

21-42 Ext. 2 Integral Time

Range:

Function:

10000.0 [0.01 - 10000.00 s]
0 s*

See par.21-22 [Ext. 1 Integral Time](#) for details.

21-43 Ext. 2 Differentiation Time

Range:

Function:

0.00 s* [0.00 - 10.00 s]

See par.21-23 [Ext. 1 Differentiation Time](#) for details.

21-44 Ext. 2 Dif. Gain Limit

Range:

Function:

5.0 N/A* [1.0 - 50.0 N/A]

See par.21-24 [Ext. 1 Dif. Gain Limit](#) for details.

21-5* Closed-loop 3 Ref/Fb

Configure Extended Closed-loop 3 Controller reference and feedback.

21-50 Ext. 3 Ref./Feedback Unit

Option:

Function:

See par.21-10 [Ext. 1 Ref./Feedback Unit](#) for details.

[0]

[1] * %

[5] PPM

[10] min

[11] RPM

[12] PULSE/s

[20] liter / sec.

[21] liter / min

[22] liter / hr.

[23] m³ / sec.

[24] m³/min

[25] m³ / hr.

[30] kg / sec.

[31]	kg/min
[32]	kg / hr.
[33]	ton / min
[34]	ton / hr.
[40]	m / sec.
[41]	m/min
[45]	m
[60]	°C
[70]	mbar
[71]	bar
[72]	Pa
[73]	kPa
[74]	m WG
[75]	mm Hg
[80]	kW
[120]	GPM
[121]	gal / sec.
[122]	gal/min
[123]	gal / hr.
[124]	CFM
[125]	ft ³ /s
[126]	ft ³ /min
[127]	ft ³ /h
[130]	lbs / sec.
[131]	lbs / min.
[132]	lbs / hr.
[140]	ft/s
[141]	ft/min
[145]	ft
[160]	°F
[170]	psi
[171]	lb/in ²
[172]	in. wtr. gage
[173]	ft WG
[174]	in Hg
[180]	HP

21-51 Ext. 3 Minimum Reference

Range:

Function:

0.000 [Application dependant]

See par.21-11 [Ext. 1 Minimum Reference](#) for details.

Ex-
tPID3Un
it*

21-52 Ext. 3 Maximum Reference

Range:

100.000 [Application dependant]

Ex-
tPID3Un
it*

Function:

See par.21-12 [Ext. 1 Maximum Reference](#) for details.

21-53 Ext. 3 Reference Source

Option:

Function:

See par.21-13 [Ext. 1 Reference Source](#) for details.

[0] * No function

[1] Analog input 53

[2] Analog input 54

[7] Pulse input 29

[8] Pulse input 33

[20] Digital pot.meter

[21] Analog input X30/11

[22] Analog input X30/12

[23] Analog Input X42/1

[24] Analog Input X42/3

[25] Analog Input X42/5

[30] Ext. Closed-loop 1

[31] Ext. Closed-loop 2

[32] Ext. Closed-loop 3

21-54 Ext. 3 Feedback Source

Option:

Function:

See par.21-14 [Ext. 1 Feedback Source](#) for details.

[0] * No function

[1] Analog input 53

[2] Analog input 54

[3] Pulse input 29

[4] Pulse input 33

[7] Analog input X30/11

[8] Analog input X30/12

[9] Analog Input X42/1

[10] Analog Input X42/3

[11] Analog Input X42/5

[100] Bus feedback 1

[101] Bus feedback 2

[102] Bus feedback 3

21-55 Ext. 3 Setpoint

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID3Unit] tPID3Un it*	See par.21-15 Ext. 1 Setpoint for details.

21-57 Ext. 3 Reference [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID3Unit] tPID3Un it*	See par.21-17 Ext. 1 Reference [Unit] for details.

21-58 Ext. 3 Feedback [Unit]

Range:	Function:
0.000 [-999999.999 - 999999.999 Ex- ExtPID3Unit] tPID3Un it*	See par.21-18 Ext. 1 Feedback [Unit] for details.

21-59 Ext. 3 Output [%]

Range:	Function:
0 %* [0 - 100 %]	See par.21-19 Ext. 1 Output [%] for details.

21-6* Closed-loop 3 PID

Configure the closed-loop 3 PID controller.

21-60 Ext. 3 Normal/Inverse Control

Option:	Function:
	See par.21-20 Ext. 1 Normal/Inverse Control for details.
[0] * Normal	
[1] Inverse	

21-61 Ext. 3 Proportional Gain

Range:	Function:
0.01 N/ [0.00 - 10.00 N/A] A*	See par.21-21 Ext. 1 Proportional Gain for details.

21-62 Ext. 3 Integral Time

Range:	Function:
10000.0 [0.01 - 10000.00 s] 0 s*	See par.21-22 Ext. 1 Integral Time for details.

21-63 Ext. 3 Differentiation Time

Range:	Function:
0.00 s* [0.00 - 10.00 s]	See par.21-23 Ext. 1 Differentiation Time for details.

21-64 Ext. 3 Dif. Gain Limit

Range:

5.0 N/A* [1.0 - 50.0 N/A]

Function:

See par.21-24 [Ext. 1 Dif. Gain Limit](#) for details.

Main Menu - Application Functions - TR200 - Group 22

This group contains parameters used for monitoring TR200 applications.

22-00 External Interlock Delay

Range:


0 s* [0 - 600 s]

Function:

Only relevant if one of the digital inputs in parameter group 5-1* has been programmed for *External Interlock* [7]. The external interlock timer will introduce a delay after the signal has been removed from the digital input programmed for External Interlock, before a reaction takes place.

22-2* No-Flow Detection

130BA252.14



The adjustable frequency drive includes functions for detecting if the load conditions in the system allow the motor to be stopped:

*Low Power Detection

*Low Speed Detection

One of these two signals must be active for a set time (par.22-24 [No-Flow Delay](#)) before selected action takes place. Possible actions to select (par.22-23 [No-Flow Function](#)): No action, Warning, Alarm, Sleep Mode.

No Flow Detection:


This function is used for detecting a no flow situation in pump systems where all valves can be closed. Can be used both when controlled by the integrated PI controller in the adjustable frequency drive or an external PI controller. The actual configuration must be programmed in par.1-00 [Configuration Mode](#).

Configuration mode for

- Integrated PI Controller: Closed-loop
- External PI Controller: Open-loop

⚠ CAUTION

Carry out No Flow tuning before setting the PI controller parameters!



No Flow Detection is based on the measurement of speed and power. For a certain speed, the adjustable frequency drive calculates the power at no-flow.

This coherence is based on the adjustment of two sets of speed and associated power at no-flow. By monitoring the power, it is possible to detect no-flow conditions in systems with fluctuating suction pressure, or if the pump has a flat characteristic towards low speed.

⚠ CAUTION

If to use the integrated PI controller, carry out No Flow tuning before setting the PI controller parameters!

Low speed detection:

Low Speed Detection gives a signal if the motor is operating with minimum speed as set in par.4-11 [Motor Speed Low Limit \[RPM\]](#) or par.4-12 [Motor Speed Low Limit \[Hz\]](#). Actions are common with No Flow Detection (individual selection not possible).

The use of Low Speed Detection is not limited to systems with a no flow situation, but can be used in any system where operation at minimum speed allows for a stop of the motor until the load calls for a speed higher than minimum speed, e.g., systems with fans and compressors.

⚠ CAUTION

In pump systems, ensure that the minimum speed in par.4-11 [Motor Speed Low Limit \[RPM\]](#) or par.4-12 [Motor Speed Low Limit \[Hz\]](#) has been set high enough for detection as the pump can run with a rather high speed even with valves closed.

Dry pump detection:

No Flow Detection can also be used for detecting if the pump has run dry (low power consumption-high speed). Can be used with both the integrated PI controller and an external PI controller.

The condition for Dry Pump signal:

- Power consumption below no flow level
- and
- Pump running at maximum speed or maximum reference open-loop, whichever is lowest.

22-22 Low Speed Detection

Option: Function:

[0] * Disabled

[1] Enabled

Select Enabled for detecting when the motor operates with a speed as set in par.4-11 [Motor Speed Low Limit \[RPM\]](#) or par.4-12 [Motor Speed Low Limit \[Hz\]](#).

22-23 No-Flow Function

Common actions for Low Power Detection and Low Speed Detection (Individual selections not possible).

Option: Function:

[0] * OFF

[1] Sleep Mode

The drive will enter sleep mode and stop when a No Flow condition is detected. See parameter group 22-4* for programming options for sleep mode.

[2] Warning

The drive will continue to run, but activate a No-Flow Warning [W92]. A drive digital output or a serial communication bus can communicate a warning to other equipment.

[3] Alarm

The drive will stop running and activate a No-Flow Alarm [A 92]. A drive digital output or a serial communication bus can communicate an alarm to other equipment.

NOTE

Do not set par.14-20 [Reset Mode](#) to [13] Infinite auto reset when par.22-23 [No-Flow Function](#) is set to [3] Alarm. Doing so will cause the drive to continuously cycle between running and stopping when a No Flow condition is detected.

NOTE

If the drive is equipped with a constant speed bypass with an automatic bypass function that starts the bypass if the drive experiences a persistent alarm condition, be sure to disable the bypass' automatic bypass function, if [3] Alarm is selected as the No-Flow Function.

22-24 No-Flow Delay

Range: Function:

10 s* [1 - 600 s]

Set the time. Low Power/Low Speed must remain detected to activate signal for actions. If detection disappears before the timer runs out, the timer will be reset.

22-4* Sleep Mode

If the load on the system allows for stop of the motor and the load is monitored, the motor can be stopped by activating the sleep mode function. This is not a normal stop command, but ramps the motor down to 0 RPM and stops energizing the motor. When in sleep mode, certain conditions are monitored to find out when load has been applied to the system again.

Sleep mode can be activated either from the No Flow Detection/Minimum Speed Detection (must be programmed via parameters for No-Flow Detection, see the signal flow diagram in parameter group 22-2*, No-Flow Detection) or via an external signal applied to one of the digital inputs (must be programmed via the parameters for configuration of the digital inputs, par. 5-1* selecting [66] Sleep Mode). Sleep mode is activated only when no wake-up conditions are present.

To make it possible to use, for example, an electro-mechanical flow switch to detect a no flow condition and activate sleep mode, the action takes place at raising edge of the external signal applied (otherwise, the adjustable frequency drive would never come out of sleep mode as the signal would be steady connected).


NOTE

If sleep mode is to be based on No Flow Detection/Minimum Speed, remember to choose Sleep Mode [1] in par. 22-23 [No-Flow Function](#).

When entering sleep mode, the lower status line in the Local Control Panel shows sleep mode.


See also signal flow chart in section 22-2* *No Flow Detection*.

There are three different ways of using the sleep mode function:




1) Systems where the integrated PI controller is used for controlling pressure or temperature, for example, to boost systems with a pressure feedback signal applied to the adjustable frequency drive from a pressure transducer. par.1-00 [Configuration Mode](#) must be set for closed-loop and the PI controller configured for desired reference and feedback signals.

Example: Boost system.




If no flow is detected, the adjustable frequency drive will increase the setpoint for pressure to ensure a slight overpressure in the system (boost to be set in par.22-45 [Setpoint Boost](#)).

The feedback from the pressure transducer is monitored and when this pressure has dropped with a set percentage below the normal setpoint for pressure (P_{set}), the motor will ramp up again and pressure will be controlled for reaching the set value (P_{set}).



2) In systems where the pressure or temperature is controlled by an external PI controller, the wake-up conditions cannot be based on feedback from the pressure/temperature transducer as the setpoint is not known. In the example with a boost system, desired pressure P_{set} is not known. par.1-00 [Configuration Mode](#) must be set for Open-loop.

Example: Boost system.



When low power or low speed is detected the motor is stopped, but the reference signal (f_{Ref}) from the external controller is still monitored and because of the low pressure created, the controller will increase the reference signal to gain pressure. When the reference signal has reached a set value f_{Wake} , the motor restarts.

Configuration possibilities, overview:

	Internal PI Controller (par.1-00 Configuration Mode : Closed-loop)		External PI controller or manual control (par.1-00 Configuration Mode : Open-loop)	
	Sleep mode	Wake up	Sleep mode	Wake up
No Flow detection (pumps only)	Yes		Yes (except manual setting of speed)	
Low speed detection	Yes		Yes	
External signal	Yes		Yes	
Pressure/Temperature (transmitter connected)		Yes		No
Output frequency		No		Yes

NOTE

Sleep mode will not be active when Local Reference is active (set speed manually by means of arrow buttons on the keypad). See par.3-13 [Reference Site](#).

Does not work in hand mode. Auto set-up in open-loop must be carried out before setting input/output in closed-loop.

22-40 Minimum Run Time

Range:

10 s* [0 - 600 s]

Function:

Set the desired minimum running time for the motor after a start command (digital input or bus) before entering sleep mode.

22-41 Minimum Sleep Time

Range:

10 s* [0 - 600 s]

Function:

Set the desired minimum time for staying in sleep mode. This will override any wake-up conditions.

22-42 Wake-up Speed [RPM]

Range:

Application dependent*
Application dependent*
Application dependent*

Function:

22-43 Wake-up Speed [Hz]

Range:

Function:

Applica-
tion de-
pend-
ent*

22-44 Wake-up Ref./FB Difference

Range:

Function:

10 %* [0 - 100 %]

Only to be used if par.1-00 [Configuration Mode](#) is set for closed-loop and the integrated PI controller is used for controlling the pressure.
Set the pressure drop allowed in percentage of setpoint for the pressure (Pset) before canceling the sleep mode.

NOTE: If used in application where the integrated PI controller is set for inverse control (e.g., cooling tower applications) in par.20-71 [PID Performance](#), the value set in par.22-44 [Wake-up Ref./FB Difference](#) will automatically be added.

22-45 Setpoint Boost

Range:

Function:

0 %* [-100 - 100 %]

Only to be used if par.1-00 [Configuration Mode](#), is set for closed-loop and the integrated PI controller is used. For example, in systems with constant pressure control, it is advantageous to increase the system pressure before the motor is stopped. This will extend the time during which the motor is stopped and help to avoid frequent start/stop.
Set the desired overpressure/temperature as a percentage of the setpoint for the pressure (Pset)/temperature before entering sleep mode.
If set at 5%, the boost pressure will be $Pset \times 1.05$. The negative values can be used, for example, for cooling tower control, where a negative change is needed.

22-46 Maximum Boost Time

Range:

Function:

60 s* [0 - 600 s]

Only to be used if par.1-00 [Configuration Mode](#) is set for closed-loop and the integrated PI controller is used for controlling the pressure.
Set the maximum time for which boost mode will be allowed. If the set time is exceeded, sleep mode will be entered and will not wait for the set boost pressure to be reached.

22-6* Broken Belt Detection

Broken belt detection can be used in both closed-loop and open-loop systems for pumps, fans and compressors. If the estimated motor torque is below the broken belt torque value (par.22-61 [Broken Belt Torque](#)) and the adjustable frequency drive output frequency is above or equal to 15 Hz, the broken belt function (par. 22-60 [Broken Belt Function](#)) is performed.

22-60 Broken Belt Function

Selects the action to be performed if the broken belt condition is detected.

Option:	Function:
[0] * OFF	
[1] Warning	The drive will continue to run, but activate a Broken Belt Warning [W95]. A drive digital output or a serial communication bus can communicate a warning to other equipment.
[2] Trip	The drive will stop running and activate a Broken Belt alarm [A 95]. A drive digital output or a serial communication bus can communicate an alarm to other equipment.

NOTE

Do not set par.14-20 [Reset Mode](#) to [13] Infinite auto reset when par.22-60 [Broken Belt Function](#) is set to [2] Trip. Doing so will cause the drive to continuously cycle between running and stopping when a broken belt condition is detected.

NOTE

If the drive is equipped with a constant speed bypass with an automatic bypass function that starts the bypass if the drive experiences a persistent alarm condition, be sure to disable the bypass' automatic bypass function, if [2] Trip is selected as the broken belt function.

22-61 Broken Belt Torque

Range:	Function:
10 %* [0 - 100 %]	Sets the broken belt torque as a percentage of the rated motor torque.

22-62 Broken Belt Delay

Range:	Function:
10 s [0 - 600 s]	Sets the time for which the broken belt conditions must be active before carrying out the action selected in par.22-60 Broken Belt Function .

22-7* Short Cycle Protection

When controlling refrigeration compressors, often there will be a need for limiting the numbers of starts. One way to do this is to ensure a minimum run time (time between a start and a stop) and a minimum interval between starts.

This means that any normal stop command can be overridden by the *Minimum Run Time* function (par. 22-77 [Minimum Run Time](#)) and any normal start command (Start/Jog/Freeze) can be overridden by the *Interval Between Starts* function (par.22-76 [Interval between Starts](#)).

None of the two functions are active if *Hand On* or *Off* modes have been activated via the keypad. If selecting *Hand On* or *Off*, the two timers will be reset to 0, and not start counting until *Auto* is pressed and an active start command applied.

22-75 Short Cycle Protection

Option:	Function:
[0] * Disabled	Timer set in par.22-76 Interval between Starts is disabled.
[1] Enabled	Timer set in par.22-76 Interval between Starts is enabled.



Sets the time desired as minimum run time after a normal start command (Start/Jog/Freeze). Any normal stop command will be disregarded until the set time has expired. The timer will start counting following a normal start command (Start/Jog/Freeze).

The timer will be overridden by a Coast (Inverse) or an External Interlock command.

Applica- [Application dependant]
tion de-
pend-
ent*

23-01 ON Action

Arra [10]

Option:

Function:

Select the action during ON Time. See par.13-52 [SL Controller Action](#) for descriptions of the options.

[0] *	DISABLED
[1]	No action
[2]	Select set-up 1
[3]	Select set-up 2
[4]	Select set-up 3
[5]	Select set-up 4
[10]	Select preset ref 0
[11]	Select preset ref 1
[12]	Select preset ref 2
[13]	Select preset ref 3
[14]	Select preset ref 4
[15]	Select preset ref 5
[16]	Select preset ref 6
[17]	Select preset ref 7
[18]	Select ramp 1
[19]	Select ramp 2
[22]	Run
[23]	Run reverse
[24]	Stop
[26]	Dcstop
[27]	Coast
[28]	Freeze output
[29]	Start timer 0
[30]	Start timer 1
[31]	Start timer 2
[32]	Set digital out A low
[33]	Set digital out B low
[34]	Set digital out C low
[35]	Set digital out D low
[36]	Set digital out E low
[37]	Set digital out F low
[38]	Set digital out A high
[39]	Set digital out B high
[40]	Set digital out C high
[41]	Set digital out D high
[42]	Set digital out E high
[43]	Set digital out F high
[60]	Reset Counter A

Parameter Description

[61] Reset Counter B

[70] Start Timer 3

[71] Start Timer 4

[72] Start Timer 5

[73] Start Timer 6

[74] Start Timer 7

23-02 OFF Time

Array [10]

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

23-03 OFF Action

Array [10]

Option:

Function:

Select the action during OFF Time. See par.13-52 [SL Controller Action](#) for descriptions of the options.

[0] * DISABLED

[1] No action

[2] Select set-up 1

[3] Select set-up 2

[4] Select set-up 3

[5] Select set-up 4

[10] Select preset ref 0

[11] Select preset ref 1

[12] Select preset ref 2

[13] Select preset ref 3

[14] Select preset ref 4

[15] Select preset ref 5

[16] Select preset ref 6

[17] Select preset ref 7

[18] Select ramp 1

[19] Select ramp 2

[22] Run

[23] Run reverse

[24] Stop

[26] Dcstop

[27] Coast

[28] Freeze output

[29] Start timer 0

[30] Start timer 1

[31] Start timer 2

[32]	Set digital out A low
[33]	Set digital out B low
[34]	Set digital out C low
[35]	Set digital out D low
[36]	Set digital out E low
[37]	Set digital out F low
[38]	Set digital out A high
[39]	Set digital out B high
[40]	Set digital out C high
[41]	Set digital out D high
[42]	Set digital out E high
[43]	Set digital out F high
[60]	Reset Counter A
[61]	Reset Counter B
[70]	Start Timer 3
[71]	Start Timer 4
[72]	Start Timer 5
[73]	Start Timer 6
[74]	Start Timer 7

23-04 Occurrence

Array [10]

Option:

Function:

Select the day(s) to which the timed action applies. Specify working/non-working days in par.0-81 [Working Days](#), par.0-82 [Additional Working Days](#) and par.0-83 [Additional Non-Working Days](#).

[0] *	All days
[1]	Working days
[2]	Non-working days
[3]	Monday
[4]	Tuesday
[5]	Wednesday
[6]	Thursday
[7]	Friday
[8]	Saturday
[9]	Sunday

23-1 * Maintenance

Wear and tear calls for periodic inspection and service of elements in the application, e.g., motor bearings, feedback sensors and seals or filters. Using preventive maintenance, service intervals may be programmed into the adjustable frequency drive. The adjustable frequency drive will give a message when maintenance is required. Twenty preventive maintenance events can be programmed into the adjustable frequency drive. The following must be specified for each event:


Parameter Description

- Maintenance item (e.g., “Motor Bearings”)
- Maintenance action (e.g., “Replace”)
- Maintenance Time Base (e.g., “Running Hours” or a specific date and time)
- Maintenance Time Interval or the date and time of next maintenance

NOTE

To disable a preventive maintenance event, the associated par.23-12 [Maintenance Time Base](#) must be set to **Disabled** [0].

Preventive Maintenance can be programmed from the keypad, but use of the PC-based Motion Control Tool Trane Drive Utility is recommended.



ID	Name	Setup 1	Setup 2	Setup 3	Setup 4
2310.0	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.1	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.2	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.3	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.4	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.5	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.6	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.7	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.8	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.9	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.10	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.11	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.12	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.13	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.14	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.15	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.16	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.17	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.18	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2310.19	Maintenance Item	Motor bearings	Motor bearings	Motor bearings	Motor bearings
2311.0	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.1	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.2	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.3	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.4	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.5	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate
2311.6	Maintenance Action	Lubricate	Lubricate	Lubricate	Lubricate

130BA492.10

The keypad indicates (with a wrench-icon and an “M”) when it is time for a preventive maintenance action, and can be programmed to be indicated on a digital output in parameter group 5-3*. The Preventive Maintenance Status may be read in par.16-96 [Maintenance Word](#). A preventive maintenance indication can be reset from a digital input, the adjustable frequency drive bus or manually from the keypad through par.23-15 [Reset Maintenance Word](#).

A maintenance log with the latest 10 logs can be read from parameter group 18-0* and via the Alarm log button on the keypad after selecting Maintenance Log.

NOTE

The preventive maintenance events are defined in a 20-element array. Hence, each preventive maintenance event must use the same array element index in par.23-10 [Maintenance Item](#) to par.23-14 [Maintenance Date and Time](#).

23-10 Maintenance Item

Option:

Function:

Array with 20 elements displayed below parameter number in the display. Press [OK] and step between elements by means of and buttons on the LCP.

Select the item to be associated with the preventive maintenance event.

[1] * Motor bearings

[2] Fan bearings

[3] Pump bearings

[4] Valve

[5] Pressure transmitter

[6] Flow transmitter

[7] Temperature transm.

[8] Pump seals

[9] Fan belt

[10] Filter

[11] Drive cooling fan

[12] System health check

[13] Warranty

[20] Maintenance Text 0

[21] Maintenance Text 1

[22] Maintenance Text 2

[23] Maintenance Text 3

[24] Maintenance Text 4

[25] Maintenance Text 5

23-11 Maintenance Action

Option:

Function:

Select the action to be associated with the preventive maintenance event.

- [1] * Lubricate
- [2] Clean
- [3] Replace
- [4] Inspect/Check
- [5] Overhaul
- [6] Renew
- [7] Check
- [20] Maintenance Text 0
- [21] Maintenance Text 1
- [22] Maintenance Text 2
- [23] Maintenance Text 3
- [24] Maintenance Text 4
- [25] Maintenance Text 5

23-12 Maintenance Time Base

Option:

Function:

Select the time base to be associated with the preventive maintenance event.

- [0] * Disabled
Disabled [0] must be used when disabling the preventive maintenance event.
- [1] Running Hours
Running Hours [1] is the number of hours the motor has been running. Running hours are not reset at power-on. The *Maintenance Time Interval* must be specified in par.23-13 [Maintenance Time Interval](#).
- [2] Operating Hours
Operating Hours [2] is the number of hours the adjustable frequency drive has been running. Operating hours are not reset at power-on. The *Maintenance Time Interval* must be specified in par.23-13 [Maintenance Time Interval](#).
- [3] Date & Time
Date & Time [3] uses the internal clock. The date and time of the next maintenance occurrence must be specified in par.23-14 [Maintenance Date and Time](#).

23-13 Maintenance Time Interval

Range:

1 h* [1 - 2147483647 h]

Function:

Set the interval associated with the current preventive maintenance event. This parameter is only used if *Running Hours* [1] or *Operating Hours* [2] is selected in par.23-12 [Maintenance Time Base](#). The timer is reset from par.23-15 [Reset Maintenance Word](#).

Example:

A preventive maintenance event is set up for Monday at 8:00. par. 23-12 [Maintenance Time Base](#) is *Operating hours* [2] and par.23-13 [Maintenance Time Interval](#) is 7 x 24 hours=168 hours. The next maintenance event will be indicated the following Monday at 8:00. If this maintenance event is not reset until Tuesday at 9:00, the next occurrence will be the following Tuesday at 9:00.

23-14 Maintenance Date and Time

Range:

Applica- [Application dependant]
tion de-
pend-
ent*

Function:

23-15 Reset Maintenance Word

Option:

Function:

Set this parameter to *Do reset* [1] to reset the Maintenance Word in par. 16-96 [Maintenance Word](#) and reset the message displayed in the keypad. This parameter will change back to *Do not reset* [0] when pressing OK.

[0] * Do not reset

[1] Do reset

NOTE

When messages are reset - Maintenance Item, Action and Maintenance Date/Time are not cancelled. par.23-12 [Maintenance Time Base](#) is set to Disabled [0].

23-16 Maintenance Text

Range:

0 N/A* [0 - 0 N/A]

Function:

23-5* Energy Log

The adjustable frequency drive is continuously accumulating the consumption of the motor controlled, based on the actual power yielded by the adjustable frequency drive.

These data can be used for an Energy Log function allowing the user to compare and structure the information about the energy consumption related to time.

There are basically two functions:

Parameter Description


- Data related to a pre-programmed period, defined by a set date and time for start
- Data related to a predefined period back in time, e.g., the last seven days within the pre-programmed period

For each of the above two functions, the data are stored in a number of counters allowing for selecting the time frame and a split on hours, days or weeks.

The period/split (resolution) can be set in par.23-50 [Energy Log Resolution](#).

The data are based on the value registered by the kWh counter in the adjustable frequency drive. This counter value can be read in par.15-02 [kWh Counter](#) containing the accumulated value since the first power-up or latest reset of the counter (par.15-06 [Reset kWh Counter](#)).

All data for the energy log are stored in counters which can be read from par.23-53 [Energy Log](#).



Counter 00 will always contain the oldest data. A counter will cover a period from XX:00 to XX:59 if hours or 00:00 to 23:59 if days.

If logging either the last hours or last days, the counters will shift contents at XX:00 every hour or at 00:00 every day.

The counter with the highest index will always be subject to updates (containing data for the current hour since XX:00 or the current day since 00:00).

The contents of counters can be displayed as bars on keypad. Select *Quick Menu, Loggings, Energy Log: Trending Continued Bin / Trending Timed Bin / Trending Comparison*.

23-50 Energy Log Resolution

Option:

Function:

Select the desired type of period for logging of consumption. Hour of Day [0] , Day of Week [1] or Day of Month [2]. The counters contain the logging data from the programmed date/time for start (par.23-51 [Period Start](#)) and the numbers of hours/days as programmed for (par.23-50 [Energy Log Resolution](#)).

The logging will start on the date programmed in par.23-51 [Period Start](#), and continue until one day/week/month has gone. Last 24 Hours [5], Last 7 Days [6] or Last 5 Weeks [7]. The counters contain data for one day, one week or five weeks back in time and up to the current time.

The logging will start at the date programmed in par.23-51 [Period Start](#). In all cases, the period split will refer to operating hours (time where adjustable frequency drive is powered up).

[0] Hour of Day

[1] Day of Week

[2] Day of Month

[5] * Last 24 Hours

[6] Last 7 Days

[7] Last 5 Weeks

NOTE

The adjustable frequency drive has no back-up of the clock function and the set date/time will reset to default (2000-01-01 00:00) after a power-down unless a Real Time Clock module with back-up is installed. Consequently, the logging will be stopped until date/time is readjusted in par.0-70 [Date and Time](#). In par.0-79 [Clock Fault](#), it is possible to program for a warning in case the clock has not been set properly, e.g., after a power-down.

23-51 Period Start

Range:

Function:

Applica- [Application dependant]
tion de-
pend-
ent*

NOTE

When mounting an Analog I/O MCB109 option card, a battery back-up of the date and time is included.

23-53 Energy Log


Range:

0 N/A* [0 - 4294967295 N/A]

Function:

Array with a number of elements equal to the number of counters ([00]-[xx] below parameter number in display). Press OK and Step between elements by means of ▲ and ▼ buttons on the Local Control Panel.

Array elements:



Data from latest period is stored in the counter with the highest index. At power-down, all counter values are stored and resumed at next power-up.

NOTE

All counters are automatically reset when changing the setting in par.23-50 [Energy Log Resolution](#). At overflow the update of the counters will stop at maximum value.

NOTE

When mounting an Analog I/O MCB109 option card, a battery backup of the date and time is included.

23-54 Reset Energy Log

Option:

Function:

Select *Do reset* [1] to reset all values in the Energy Log counters shown in par.23-53 [Energy Log](#). After pressing OK, the setting of the parameter value will automatically change to *Do not reset* [0].

[0] * Do not reset

[1] Do reset

23-6* Trending

Trending is used to monitor a process variable over a period of time and record how often the data falls into each of ten user-defined data ranges. This is a convenient tool to get a quick overview indicating where to put focus for improvement of operation.

Two sets of data for trending can be created in order to make it possible to compare current values for a selected operating variable with data for a certain reference period, for the same variable. This reference period can be pre-programmed (par.23-63 [Timed Period Start](#) and par.23-64 [Timed Period Stop](#)). The two sets of data can be read from par.23-61 [Continuous Bin Data](#) (current) and par.23-62 [Timed Bin Data](#) (reference).

It is possible to create trending for following operation variables:

- Power
- Current
- Output frequency
- Motor Speed

The trending function includes ten counters (forming a bin) for each set of data containing the numbers of registrations reflecting how often the operating variable is within each of ten pre-defined intervals. The sorting is based on a relative value of the variable.

The relative value for the operating variable is


Actual/Rated * 100%.

for Power and Current and

Actual/Max * 100%

for Output Frequency and Motor Speed.

The size of each interval can be adjusted individually, but will default be 10% for each. Power and current can exceed rated value, but those registrations will be included in the 90%–100% (MAX) counter.



Parameter Description

Once a second, the value of the operating variable selected is registered. If a value has been registered to equal 13%, the counter "10%–<20%" will be updated with the value "1". If the value stays at 13% for 10s, then "10" will be added to the counter value.

The contents of counters can be displayed as bars on keypad. Select *Quick Menu > Loggings: Trending Continued Bin / Trending Timed Bin / Trending Comparison*.

NOTE

The counters starts counting whenever the adjustable frequency drive is powered up. The power cycle will shortly after a reset zero the counters. EEPROM data are updated once per hour.

23-60 Trend Variable

Option:		Function:
		Select the desired operating variable to be monitored for trending.
[0] *	Power [kW]	Power yielded to the motor. Reference for the relative value is the rated motor power programmed in par.1-20 Motor Power [kW] or par. 1-21 Motor Power [HP] . Actual value can be read in par.16-10 Power [kW] or par.16-11 Power [hp] .
[1]	Current [A]	Output current to the motor. Reference for the relative value is the rated motor current programmed in par.1-24 Motor Current . Actual value can be read in par.16-14 Motor Current .
[2]	Frequency [Hz]	Output frequency to the motor. Reference for the relative value is the maximum output frequency programmed in par.4-14 Motor Speed High Limit [Hz] . Actual value can be read in par.16-13 Frequency .
[3]	Motor Speed [RPM]	Speed of the motor. Reference for relative value is the maximum motor speed programmed in par.4-13 Motor Speed High Limit [RPM] .

23-61 Continuous Bin Data

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	Array with 10 elements ([0]-[9] below parameter number in display). Press OK and step between elements by means of ▲ and ▼ buttons on the keypad. 10 counters with the frequency of occurrence for the operating variable monitored, sorted according to the following intervals: - Counter [0]: 0%—<10% - Counter [1]: 10%—<20% - Counter [2]: 20%—<30% - Counter [3]: 30%—<40% - Counter [4]: 40%—<50% - Counter [5]: 50%—<60% - Counter [6]: 60%—<70% - Counter [7]: 70%—<80% - Counter [8]: 80%—<90% - Counter [9]: 90%—<100% or Max The above minimum limits for the intervals are the default limits. These can be changed in par.23-65 Minimum Bin Value. Starts to count when the adjustable frequency drive is powered up for the first time. All counters can be reset to 0 in par.23-66 Reset Continuous Bin Data.

23-62 Timed Bin Data

Range:	Function:
0 N/A* [0 - 4294967295 N/A]	Array with 10 elements ([0]-[9] below parameter number in display). Press OK and step between elements by means of ▲ and ▼ buttons on the keypad. 10 counters with the frequency of occurrence for the operating data monitored sorted according to the intervals as for par.23-61 Continuous Bin Data. Starts to count at the date/time programmed in par.23-63 Timed Period Start, and stops at the time/date programmed in par.23-64 Timed Period Stop. All counters can be reset to 0 in par.23-67 Reset Timed Bin Data.

23-63 Timed Period Start

Range:	Function:
Applica- [Application dependant] tion de- pend- ent*	



The adjustable frequency drive has no back-up of the clock function and the set date/time will reset to default (2000-01-01 00:00) after a power-down unless a Real Time Clock module with back-up is installed. Consequently, logging will be stopped until the date/time is readjusted in par.0-70 [Date and Time](#). In par.0-79 [Clock Fault](#), it is possible to program for a warning in case the clock has not been set properly, e.g., after a power-down.

When mounting an Analog I/O MCB109 option card, a battery back-up of the date and time is included.

23-64 Timed Period Stop

Range: _____ Function: _____

Applica- [Application dependant]
tion de-
pend-
ent*

When mounting an Analog I/O MCB109 option card, a battery back-up of the date and time is included.

23-65 Minimum Bin Value

Range: _____ Function: _____

Applica- [Application dependant]
tion de-
pend-
ent*

23-66 Reset Continuous Bin Data

Option:	Function:
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

Select *Do reset* [1] to reset all values in par.23-61 [Continuous Bin Data](#). After pressing OK, the setting of the parameter value will automatically change to *Do not reset* [0].

[0] * Do not reset

[1] Do reset

23-67 Reset Timed Bin Data

Option:	Function:
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100


Select *Do reset* [1] to reset all counters in par.23-62 [Timed Bin Data](#). After pressing OK, the setting of the parameter value will automatically change to *Do not reset* [0].

[0] * Do not reset

[1] Do reset

23-8* Payback Counter

The adjustable frequency drive includes a feature which can give a rough calculation on payback in cases where the adjustable frequency drive has been installed in an existing plant to ensure energy savings by changing from fixed to variable speed control. Reference for the savings is a set value to represent the average power yielded before the upgrade with variable speed control.



The difference between the Reference Power at fixed speed and the Actual Power yielded with speed control represent the actual savings.

As value for the fixed speed case, the rated motor size (kW) is multiplied with a factor (set in %) representing the power produced at fixed speed. The difference between this reference power and the actual power is accumulated and stored. The difference in energy can be read in par.23-83 [Energy Savings](#).

The accumulated value for the difference in power consumption is multiplied with the energy cost in local currency and the investment is subtracted. This calculation for cost savings can also be read in par.23-84 [Cost Savings](#).

$$Cost\ Savings = \left\{ \sum_{t=0}^t [(Rated\ Motor\ Power * Power\ Reference\ Factor) - Actual\ Power\ Consumption] \times Energy\ Cost \right\} - Investment\ Cost$$

– Actual Power Consumption] × Energy Cost} – Investment Cost

Break even (payback) occurs when the value read in the parameter turns from negative to positive.

It is not possible to reset the Energy Savings counter, but the counter can be stopped any time by setting par. 23-80 [Power Reference Factor](#) to 0.

Parameter overview:

Parameter for settings		Parameters for readout	
Rated Motor Power	par.1-20 Motor Power [kW]	Energy Savings	par.23-83 Energy Savings
Power Reference Factor in %	par.23-80 Power Reference Factor	Actual Power	par.16-10 Power [kW] , par.16-11 Power [hp]
Energy Cost per kWh	par.23-81 Energy Cost	Cost Savings	par.23-84 Cost Savings
Investment	par.23-82 Investment		

23-80 Power Reference Factor

Range:

100 %* [0 - 100 %]

Function:

Set the percentage of the rated motor size (set in par.1-20 [Motor Power \[kW\]](#) or par.1-21 [Motor Power \[HP\]](#)) which is supposed to represent the average power yielded at the time running with fixed speed (before upgrade with variable speed control).
Must be set to a value different from zero to start counting.

23-81 Energy Cost

Range:

1.00 N/ [0.00 - 999999.99 N/A]
A*

Function:

Set the current cost for a kWh in local currency. If the energy cost is changed later on, it will impact the calculation for the entire period!

23-82 Investment

Range:

0 N/A* [0 - 999999999 N/A]

Function:

Set the value of the investment spent on upgrading the plant with speed control, in same currency as used in par.23-81 [Energy Cost](#).

23-83 Energy Savings

Range:

0 kWh* [0 - 0 kWh]

Function:

This parameter allows for a readout of the accumulated difference between the reference power and the actual output power.
If the motor size is set in HP (par.1-21 [Motor Power \[HP\]](#)), the equivalent kW value will be used for the Energy Savings.

23-84 Cost Savings

Range:

0 N/A* [0 - 2147483647 N/A]

Function:

This parameter allows a readout of the calculation based on the above equation (in local currency).

Main Menu - Application Functions 2 - Group 24

24-0*

NOTE

Please note the adjustable frequency drive is only one component of the TR200 system. Correct function of fire mode depends on the correct design and selection of system components. Ventilation systems working in life safety applications have to be approved by the local fire authorities. ***Non-interruption of the adjustable frequency drive due to fire mode operation may cause overpressure and result in damage to TR200 system and components, including dampers and air ducts. The adjustable frequency drive itself may be damaged and it may cause damage or fire. Trane accepts no responsibility for errors, malfunctions, personal injury or any damage to the adjustable frequency drive itself or components herein, TR200 systems and components herein or other property when the adjustable frequency drive has been programmed for fire mode. In no event shall Trane be liable to the end user or any other party for any direct or indirect, special or consequential damage or loss suffered by such party, which has occurred due to the adjustable frequency drive being programmed and operated in fire mode.***

Background

Fire mode is for use in critical situations, where it is imperative for the motor to keep running, regardless of the adjustable frequency drive's normal protective functions. These could be ventilation fans in tunnels or stairwells for instance, where continued operation of the fan facilitates safe evacuation of personnel in the event of a fire. Some selections of the fire mode function cause alarms and trip conditions to be disregarded, enabling the motor to run without interruption.

Activation

Fire mode is activated only via digital input terminals. See parameter group 5-1* Digital Inputs.

Messages in display

When fire mode is activated, the display will show a status message "Fire Mode" and a warning "Fire Mode". Once fire mode is again deactivated, the status messages will disappear and the warning will be replaced by the warning "Fire M Was Active". This message can only be reset by power-cycling the adjustable frequency drive supply. If, while the adjustable frequency drive is active in fire mode, a warranty-affecting alarm (see par. 24-09 [Fire Mode Alarm Handling](#)) should occur, the display will show the warning "Fire M Limits Exceeded". Digital and relay outputs can be configured for the status messages "Fire Mode Active" and the warning "Fire M Was Active". See parameter group 5-3* and parameter group 5-4*.

"Fire M was Active" messages can also be accessed in the warning word via serial communication. (See relevant documentation).

The status messages "Fire Mode" can be accessed via the extended status word.

Message	Type	keypad	Digital Out/Re- lay	Warning Word 2	Ext. Status Word 2
Fire Mode	Status	+	+		+
Fire Mode	Warning	+			
Fire M was Active	Warning	+	+	+	
Fire M Limits Exceeded	Warning	+	+		

Log

An overview of events related to fire mode can be viewed in the fire mode log, parameter group 18-1*, or via the alarm log button on the keypad.

The log will include up to 10 of the latest events. Warranty-affecting alarms will have a higher priority as the two other types of events.

The log cannot be reset!

Following events are logged:

*Warranty affecting alarms (see par.24-09 [Fire Mode Alarm Handling](#), Fire Mode Alarm Handling)

*Fire Mode activated

*Fire Mode deactivated

All other alarms occurring while fire mode activated will be logged as usual.

NOTE

During fire mode operation all stop commands to the adjustable frequency drive will be ignored, including Coast/Coast inverse and External Interlock. However, if your adjustable frequency drive incorporates "Safe-Stop", this function is still active. See Section "How to Order / Ordering Form Type Code"

NOTE

If in fire mode, it is desired to use the live zero function, then it will also be active for analog inputs other than that used for fire mode setpoint/feedback. Should the feedback to any of those other analog inputs be lost, for example a cable is burned, live zero function will operate. If this is undesirable, the live zero function must be disabled for those other inputs.

Desired live zero function, if a signal is missing when fire mode is active, must be set in par.6-02 [Fire Mode Live Zero Timeout Function](#).

Warning for live zero will have a higher priority than the warning "Fire Mode".

NOTE

When setting the command Start Reversing [11] on a digital input terminal in par.5-10 [Terminal 18 Digital Input](#), the adjustable frequency converter will understand this as a reversing command.

24-00 Fire Mode Function

Option:		Function:
[0] *	Disabled	Fire Mode Function is not active.
[1]	Enabled - Run Fwd	In this mode, the motor will continue to operate in a clockwise direction. Works only in open-loop. Set par. par.24-01 Fire Mode Configuration to Open-loop [0].
[2]	Enabled - Run Rev	In this mode, the motor will continue to operate in a counter-clockwise direction. Works only in open-loop. Set par.24-01 Fire Mode Configuration to Open-loop [0].
[3]	Enabled - Coast	When this mode is enabled, the output is disabled and the motor is allowed to coast to stop.
[4]	Enabled - Run Fwd/Re	

In the above, alarms are produced or ignored in accordance with the selection in par.24-09 [Fire Mode Alarm Handling](#).

Range: _____ Function: _____

Applica- [Application dependant]
tion de-
pend-
ent*

Range:	Function:
1-10	1-10
11-20	11-20
21-30	21-30
31-40	31-40
41-50	41-50
51-60	51-60
61-70	61-70
71-80	71-80
81-90	81-90
91-100	91-100

0,00 %* [-100,00 - 100,00 %]

Option:	Function:
1. Option 1: <i>Standard</i> (100%) 2. Option 2: <i>Standard</i> (100%) 3. Option 3: <i>Standard</i> (100%) 4. Option 4: <i>Standard</i> (100%) 5. Option 5: <i>Standard</i> (100%) 6. Option 6: <i>Standard</i> (100%) 7. Option 7: <i>Standard</i> (100%) 8. Option 8: <i>Standard</i> (100%) 9. Option 9: <i>Standard</i> (100%) 10. Option 10: <i>Standard</i> (100%) 11. Option 11: <i>Standard</i> (100%) 12. Option 12: <i>Standard</i> (100%) 13. Option 13: <i>Standard</i> (100%) 14. Option 14: <i>Standard</i> (100%) 15. Option 15: <i>Standard</i> (100%) 16. Option 16: <i>Standard</i> (100%) 17. Option 17: <i>Standard</i> (100%) 18. Option 18: <i>Standard</i> (100%) 19. Option 19: <i>Standard</i> (100%) 20. Option 20: <i>Standard</i> (100%) 21. Option 21: <i>Standard</i> (100%) 22. Option 22: <i>Standard</i> (100%) 23. Option 23: <i>Standard</i> (100%) 24. Option 24: <i>Standard</i> (100%) 25. Option 25: <i>Standard</i> (100%) 26. Option 26: <i>Standard</i> (100%) 27. Option 27: <i>Standard</i> (100%) 28. Option 28: <i>Standard</i> (100%) 29. Option 29: <i>Standard</i> (100%) 30. Option 30: <i>Standard</i> (100%) 31. Option 31: <i>Standard</i> (100%) 32. Option 32: <i>Standard</i> (100%) 33. Option 33: <i>Standard</i> (100%) 34. Option 34: <i>Standard</i> (100%) 35. Option 35: <i>Standard</i> (100%) 36. Option 36: <i>Standard</i> (100%) 37. Option 37: <i>Standard</i> (100%) 38. Option 38: <i>Standard</i> (100%) 39. Option 39: <i>Standard</i> (100%) 40. Option 40: <i>Standard</i> (100%) 41. Option 41: <i>Standard</i> (100%) 42. Option 42: <i>Standard</i> (100%) 43. Option 43: <i>Standard</i> (100%) 44. Option 44: <i>Standard</i> (100%) 45. Option 45: <i>Standard</i> (100%) 46. Option 46: <i>Standard</i> (100%) 47. Option 47: <i>Standard</i> (100%) 48. Option 48: <i>Standard</i> (100%) 49. Option 49: <i>Standard</i> (100%) 50. Option 50: <i>Standard</i> (100%) 51. Option 51: <i>Standard</i> (100%) 52. Option 52: <i>Standard</i> (100%) 53. Option 53: <i>Standard</i> (100%) 54. Option 54: <i>Standard</i> (100%) 55. Option 55: <i>Standard</i> (100%) 56. Option 56: <i>Standard</i> (100%) 57. Option 57: <i>Standard</i> (100%) 58. Option 58: <i>Standard</i> (100%) 59. Option 59: <i>Standard</i> (100%) 60. Option 60: <i>Standard</i> (100%) 61. Option 61: <i>Standard</i> (100%) 62. Option 62: <i>Standard</i> (100%) 63. Option 63: <i>Standard</i> (100%) 64. Option 64: <i>Standard</i> (100%) 65. Option 65: <i>Standard</i> (100%) 66. Option 66: <i>Standard</i> (100%) 67. Option 67: <i>Standard</i> (100%) 68. Option 68: <i>Standard</i> (100%) 69. Option 69: <i>Standard</i> (100%) 70. Option 70: <i>Standard</i> (100%) 71. Option 71: <i>Standard</i> (100%) 72. Option 72: <i>Standard</i> (100%) 73. Option 73: <i>Standard</i> (100%) 74. Option 74: <i>Standard</i> (100%) 75. Option 75: <i>Standard</i> (100%) 76. Option 76: <i>Standard</i> (100%) 77. Option 77: <i>Standard</i> (100%) 78. Option 78: <i>Standard</i> (100%) 79. Option 79: <i>Standard</i> (100%) 80. Option 80: <i>Standard</i> (100%) 81. Option 81: <i>Standard</i> (100%) 82. Option 82: <i>Standard</i> (100%) 83. Option 83: <i>Standard</i> (100%) 84. Option 84: <i>Standard</i> (100%) 85. Option 85: <i>Standard</i> (100%) 86. Option 86: <i>Standard</i> (100%) 87. Option 87: <i>Standard</i> (100%) 88. Option 88: <i>Standard</i> (100%) 89. Option 89: <i>Standard</i> (100%) 90. Option 90: <i>Standard</i> (100%) 91. Option 91: <i>Standard</i> (100%) 92. Option 92: <i>Standard</i> (100%) 93. Option 93: <i>Standard</i> (100%) 94. Option 94: <i>Standard</i> (100%) 95. Option 95: <i>Standard</i> (100%) 96. Option 96: <i>Standard</i> (100%) 97. Option 97: <i>Standard</i> (100%) 98. Option 98: <i>Standard</i> (100%) 99. Option 99: <i>Standard</i> (100%) 100. Option 100: <i>Standard</i> (100%)	1. Function 1: <i>Standard</i> (100%) 2. Function 2: <i>Standard</i> (100%) 3. Function 3: <i>Standard</i> (100%) 4. Function 4: <i>Standard</i> (100%) 5. Function 5: <i>Standard</i> (100%) 6. Function 6: <i>Standard</i> (100%) 7. Function 7: <i>Standard</i> (100%) 8. Function 8: <i>Standard</i> (100%) 9. Function 9: <i>Standard</i> (100%) 10. Function 10: <i>Standard</i> (100%) 11. Function 11: <i>Standard</i> (100%) 12. Function 12: <i>Standard</i> (100%) 13. Function 13: <i>Standard</i> (100%) 14. Function 14: <i>Standard</i> (100%) 15. Function 15: <i>Standard</i> (100%) 16. Function 16: <i>Standard</i> (100%) 17. Function 17: <i>Standard</i> (100%) 18. Function 18: <i>Standard</i> (100%) 19. Function 19: <i>Standard</i> (100%) 20. Function 20: <i>Standard</i> (100%) 21. Function 21: <i>Standard</i> (100%) 22. Function 22: <i>Standard</i> (100%) 23. Function 23: <i>Standard</i> (100%) 24. Function 24: <i>Standard</i> (100%) 25. Function 25: <i>Standard</i> (100%) 26. Function 26: <i>Standard</i> (100%) 27. Function 27: <i>Standard</i> (100%) 28. Function 28: <i>Standard</i> (100%) 29. Function 29: <i>Standard</i> (100%) 30. Function 30: <i>Standard</i> (100%) 31. Function 31: <i>Standard</i> (100%) 32. Function 32: <i>Standard</i>

Select the external reference input to be used for fire mode. This signal will be added to the value set in par.24-06 [Fire Mode Reference Source](#).

- | | |
|-------|---------------------|
| [0] * | No function |
| [1] | Analog input 53 |
| [2] | Analog input 54 |
| [7] | Pulse input 29 |
| [8] | Pulse input 33 |
| [20] | Digital pot.meter |
| [21] | Analog input X30/11 |
| [22] | Analog input X30/12 |
| [23] | Analog Input X42/1 |
| [24] | Analog Input X42/3 |
| [25] | Analog Input X42/5 |

Option:	Function:
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

- | | | |
|-------|-----------------------|--|
| [0] | Trip+Reset, Crit Alar | If this mode is selected, the adjustable frequency drive will continue to run, ignoring most alarms, EVEN IF DOING SO MAY RESULT IN DAMAGE OF THE ADJUSTABLE FREQUENCY DRIVE . Critical alarms are alarms, which cannot be suppressed but a restart attempt is possible (Infinity Automatic Reset). |
| [1] * | Trip, Critical Alarms | In case of a critical alarm, the adjustable frequency drive will trip and not auto-restart (Manual Reset). |
| [2] | Trip, All Alarms/Test | It is possible to test the operation of fire mode, but all alarm states are activated normally (Manual Reset). |

NOTE

Warranty-affecting alarms. Certain alarms can affect the lifetime of the adjustable frequency drive. If one of these ignored alarms occur while in fire mode, a log of the event is stored in the fire mode log.

Here the 10 latest events of warranty-affecting alarms, fire mode activation and fire mode deactivation are stored.

NOTE

The setting in par.14-20 [Reset Mode](#) is disregarded if fire mode is active (see par. 24-0*, Fire Mode).

No:	Description	Critical Alarms	Warranty Affecting Alarms
4	Line ph. Loss		x
7	DC overvoltage	x	
8	DC undervoltage	x	
9	Inverter overloaded		x
13	Overcurrent	x	
14	Ground fault	x	
16	Short circuit	x	
29	Power card temp		x
33	Soft-charge fault		x
38	Internal fault		x
65	Ctrl. card temp		x
68	SafeStop	x	

24-1*

The adjustable frequency drive includes a feature, which can be used to automatically activate an external electro-mechanical bypass in case of a trip/trip lock of the adjustable frequency drive or the event of a fire mode coast (see par.24-00 [Fire Mode Function](#)).

The bypass will switch the motor to operation direct on line. The external bypass is activated by means of one of the digital outputs or relays in the adjustable frequency drive, when programmed in parameter group 5-3* or parameter group 5-4*.

NOTE

Important! After enabling the Drive Bypass function, the adjustable frequency drive is no longer Safety Certified (for using the Safe Stop in versions, where included).


To deactivate the drive bypass at normal operation (fire mode not activated), one of following actions must be carried out:

- Press the Off button on the keypad, (or program two of the digital inputs for Hand On-Off-Auto).
- Activate External Interlock via digital input
- Carry out Power Cycling.

NOTE

The drive bypass cannot be deactivated if in fire mode. It can be deactivated only by either removing the fire mode command signal or the power supply to the adjustable frequency drive!

When the Drive Bypass function is activated, the display on the keypad will show the status message Drive Bypass. This message has a higher priority than the fire mode status messages. When the automatic drive bypass function is enabled, it will cut in the external bypass according to the below sequence:



24-10 Drive Bypass Function

Option:

Function:

This parameter determines, what circumstances will activate the drive bypass function:

[0] * Disabled

[1] Enabled

If in normal operation, the automatic drive bypass function will be activated at following conditions:

At a Trip Lock or a Trip. After the programmed number of reset attempts, programmed in par.14-20 [Reset Mode](#) or if the bypass delay timer (par. 24-11 [Drive Bypass Delay Time](#)) expires before reset attempts have been completed

When in fire mode, the bypass function will operate under following conditions:

When experiencing a trip at critical alarms, a coast or if the bypass delay timer expires before reset attempts have completed when [2] Enabled in fire mode. The bypass function will operate at trip at critical alarms, coast or if the bypass delay timer expires before reset attempts have been completed.

[2] Enabled (Fire M Only)

The bypass function will operate at trip at critical alarms, coast or bypass delay timer if the timer expires before reset attempts have completed.

CAUTION

Important! After enabling the drive bypass function, the safe stop function (in versions, where included) no longer complies with standard EN 954-1, Cat. 3 installations.

24-11 Drive Bypass Delay Time

Range:

0 s* [0 - 600 s]

Function:

Programmable in 1 s increments. Once the bypass function is activated in accordance with the setting in par.24-10 [Drive Bypass Function](#), the bypass delay timer begins to operate. If the adjustable frequency drive has been set for a number of restart attempts, the timer will continue to run while the adjustable frequency drive tries to restart. If the motor restarts within the time period of the bypass delay timer, then the timer is reset.

If the motor fails to restart at the end of the bypass delay time, the drive bypass relay will be activated, which will have been programmed for Bypass in par.5-40 [Function Relay](#). If a [Relay Delay] has also been programmed in par.5-41 [On Delay, Relay](#), [Relay] or par.5-42 [Off Delay, Relay](#), [Relay], then this time must also elapse before the relay action is performed.

Where no restart attempts are programmed, the timer will run for the delay period set in this parameter and will then activate the drive bypass relay, which will have been programmed for Bypass in par.5-40 [Function Relay](#), Function Relay. If a relay delay has also been programmed in par. 5-41 [On Delay, Relay](#), On Delay, Relay or par.5-42 [Off Delay, Relay](#), [Relay], then this time must also elapse before the relay action is performed.

Troubleshooting

Troubleshooting

Alarms and Warnings

A warning or an alarm is signaled by the relevant LED on the front of the adjustable frequency drive and indicated by a code on the display.

A warning remains active until its cause is no longer present. Under certain circumstances operation of the motor may still be continued. Warning messages may be critical, but are not necessarily so.

In the event of an alarm, the adjustable frequency drive will have tripped. Alarms must be reset to restart operation once their cause has been rectified.

This may be done in four ways:

1. By using the [RESET] control button on the keypad.
2. Via a digital input with the "Reset" function.
3. Via serial communication/optional serial communication bus.
4. By resetting automatically using the [Auto Reset] function, which is a default setting for TR200 Drive, see par.14-20 [Reset Mode](#).

NOTE: After a manual reset using the [RESET] button on the keypad, the [AUTO ON] or [HAND ON] button must be pressed to restart the motor.

If an alarm cannot be reset, the reason may be that its cause has not been rectified, or the alarm is trip-locked (see also table on following page).

WARNING

Alarms that are trip-locked offer additional protection, means that the line power supply must be switched off before the alarm can be reset. After being switched back on, the adjustable frequency drive is no longer blocked and may be reset as described above, once the cause has been rectified.

Alarms that are not trip-locked can also be reset using the automatic reset function in par.14-20 [Reset Mode](#) (Warning: automatic wake-up is possible!)

If a warning and alarm is marked against a code in the table on the following page, this means that either a warning occurs before an alarm, or it can be specified whether it is a warning or an alarm that is to be displayed for a given fault. This is possible, for instance, in par.1-90 [Motor Thermal Protection](#). After an alarm or trip, the motor carries on coasting, and the alarm and warning flash on the adjustable frequency drive. Once the problem has been rectified, only the alarm continues flashing.

No.	Description	Warn- ing	Alarm/Trip	Alarm/Trip Lock	Parameter Refer- ence
1	10 Volts low	X			
2	Live zero error	(X)	(X)		6-01
3	No motor	(X)			1-80
4	Line phase loss	(X)	(X)	(X)	14-12
5	DC link voltage high	X			
6	DC link voltage low	X			
7	DC overvoltage	X	X		
8	DC undervoltage	X	X		
9	Inverter overloaded	X	X		
10	Motor ETR overtemperature	(X)	(X)		1-90
11	Motor thermistor overtemperature	(X)	(X)		1-90
12	Torque limit	X	X		
13	Overcurrent	X	X	X	
14	Ground fault	X	X	X	
15	Hardware mismatch		X	X	
16	Short Circuit		X	X	
17	Control word timeout	(X)	(X)		8-04
23	Internal Fan Fault	X			
24	External Fan Fault	X			14-53
25	Brake resistor short-circuited	X			
26	Brake resistor power limit	(X)	(X)		2-13
27	Brake chopper short-circuited	X	X		
28	Brake check	(X)	(X)		2-15
29	Drive overtemperature	X	X	X	
30	Motor phase U missing	(X)	(X)	(X)	4-58
31	Motor phase V missing	(X)	(X)	(X)	4-58
32	Motor phase W missing	(X)	(X)	(X)	4-58
33	Soft-charge fault		X	X	
34	Serial Communication Bus communi- cation fault	X	X		
35	Out of frequency ranges	X	X		
36	Line failure	X	X		
37	Phase Imbalance	X	X		
38	Internal fault		X	X	
39	Heatsink sensor		X	X	
40	Overload of Digital Output Terminal 27	(X)			5-01
41	Overload of Digital Output Terminal 29	(X)			5-02
42	Overload of Digital Output On X30/6	(X)			5-32
42	Overload of Digital Output On X30/7	(X)			5-33
46	Pwr. card supply		X	X	
47	24 V supply low	X	X	X	
48	1.8 V supply low		X	X	
49	Speed limit	X	(X)		1-86
50	AMA calibration failed		X		
51	AMA check U_{nom} and I_{nom}		X		
52	AMA low I_{nom}		X		
53	AMA motor too big		X		
54	AMA motor too small		X		
55	AMA Parameter out of range		X		
56	AMA interrupted by user		X		
57	AMA timeout		X		
58	AMA internal fault	X	X		
59	Current limit	X			

Table 5. 1: Alarm/Warning code list

No.	Description	Warn- ing	Alarm/Trip	Alarm/Trip Lock	Parameter Refer- ence
60	External Interlock	X			
62	Output Frequency at Maximum Limit	X			
64	Voltage Limit	X			
65	Control Board Overtemperature	X	X	X	
66	Heatsink Temperature Low	X			
67	Option Configuration has Changed		X		
68	Safe Stop Activated		X ¹⁾		
69	Pwr. Card Temp		X	X	
70	Illegal adjustable frequency drive con- figuration			X	
71	PTC 1 Safe Stop	X	X ¹⁾		
72	Dangerous Failure			X ¹⁾	
73	Safe Stop Auto Restart				
76	Power Unit Set-up	X			
79	Illegal PS config		X	X	
80	Drive Initialized to Default Value		X		
91	Analog input 54 wrong settings			X	
92	NoFlow	X	X		22-2*
93	Dry Pump	X	X		22-2*
94	End of Curve	X	X		22-5*
95	Broken Belt	X	X		22-6*
96	Start Delayed	X			22-7*
97	Stop Delayed	X			22-7*
98	Clock Fault	X			0-7*
201	Fire M was Active				
202	Fire M Limits Exceeded				
203	Missing Motor				
204	Locked Rotor				
243	Brake IGBT	X	X		
244	Heatsink temp	X	X	X	
245	Heatsink sensor		X	X	
246	Pwr.card supply		X	X	
247	Pwr.card temp		X	X	
248	Illegal PS config		X	X	
250	New spare parts			X	
251	Type Code		X	X	

Table 5. 2: Alarm/Warning code list

(X) Dependent on parameter

1) Cannot be auto reset via par.14-20 [Reset Mode](#)

A trip is the action when an alarm has appeared. The trip will coast the motor and can be reset by pressing the reset button or make a reset by a digital input (parameter group 5-1* [1]). The original event that caused an alarm cannot damage the adjustable frequency drive or cause dangerous conditions. A trip lock is an action that

occurs in conjunction with an alarm, which may cause damage to the adjustable frequency drive or connected parts. A trip lock situation can only be reset by power cycling.

LED indication

Warning	yellow
Alarm	flashing red
Trip locked	yellow and red

Alarm Word and Extended Status Word

Bit	Hex	Dec	Alarm Word	Warning Word	Extended Status Word
0	00000001	1	Brake Check	Brake Check	Ramping
1	00000002	2	Pwr. Card Temp	Pwr. Card Temp	AMA Running
2	00000004	4	Ground Fault	Ground Fault	Start CW/CCW
3	00000008	8	Ctrl.Card Temp	Ctrl.Card Temp	Slow Down
4	00000010	16	Ctrl. Word TO	Ctrl. Word TO	Catch Up
5	00000020	32	Overcurrent	Overcurrent	Feedback High
6	00000040	64	Torque Limit	Torque Limit	Feedback Low
7	00000080	128	Motor Th Over	Motor Th Over	Output Current High
8	00000100	256	Motor ETR Over	Motor ETR Over	Output Current Low
9	00000200	512	Inverter Overld.	Inverter Overld.	Output Freq High
10	00000400	1024	DC undervolt	DC undervolt	Output Freq Low
11	00000800	2048	DC overvolt	DC overvolt	Brake Check OK
12	00001000	4096	Short Circuit	DC Voltage Low	Braking Max
13	00002000	8192	Soft-charge fault	DC Voltage High	Braking
14	00004000	16384	Line ph. Loss	Line ph. Loss	Out of Speed Range
15	00008000	32768	AMA Not OK	No Motor	OVC Active
16	00010000	65536	Live Zero Error	Live Zero Error	
17	00020000	131072	Internal Fault	10V low	
18	00040000	262144	Brake Overload	Brake Overload	
19	00080000	524288	U phase Loss	Brake Resistor	
20	00100000	1048576	V phase Loss	Brake IGBT	
21	00200000	2097152	W phase Loss	Speed Limit	
22	00400000	4194304	Serial Communi- cation Bus Fault	Serial Communication Bus Fault	
23	00800000	8388608	24 V Supply Low	24V Supply Low	
24	01000000	16777216	Line failure	Line failure	
25	02000000	33554432	1.8 V Supply Low	Current Limit	
26	04000000	67108864	Brake Resistor	Low Temp	
27	08000000	134217728	Brake IGBT	Voltage Limit	
28	10000000	268435456	Option Change	Unused	
29	20000000	536870912	Drive Initialized	Unused	
30	40000000	1073741824	Safe Stop	Unused	

Table 5. 3: Description of Alarm Word, Warning Word and Extended Status Word

The alarm words, warning words and extended status words can be read out via serial bus or optional serial communication bus for diagnosis. See also par.16-90 [Alarm Word](#), par.16-92 [Warning Word](#) and par.16-94 [Ext. Status Word](#).

Alarm Words

Alarm word, par.16-90 [Alarm Word](#)

Bit (Hex)	Alarm Word (par.16-90 Alarm Word)
00000001	Brake check
00000002	Power card overtemperature
00000004	Ground fault
00000008	Ctrl. card overtemperature
00000010	Control word timeout
00000020	Overcurrent
00000040	Torque limit
00000080	Motor thermistor overtemp.
00000100	Motor ETR overtemperature
00000200	Inverter overloaded
00000400	DC link undervoltage
00000800	DC link overvoltage
00001000	Short circuit
00002000	Soft-charge fault
00004000	Line phase loss
00008000	AMA not OK
00010000	Live zero error
00020000	Internal fault
00040000	Brake overload
00080000	Motor phase U is missing
00100000	Motor phase V is missing
00200000	Motor phase W is missing
00400000	Serial communication bus fault
00800000	24 V supply fault
01000000	Line failure
02000000	1.8 V supply fault
04000000	Brake resistor short circuit
08000000	Brake chopper fault
10000000	Option change
20000000	Drive initialized
40000000	Safe Stop
80000000	Not used

Alarm word 2, par.16-91 [Alarm word 2](#)

Bit (Hex)	Alarm Word 2 (par.16-91 Alarm word 2)
00000001	Service Trip, read / Write
00000002	Reserved
00000004	Service Trip, Typecode / Spare part
00000008	Reserved
00000010	Reserved
00000020	No Flow
00000040	Dry Pump
00000080	End of Curve
00000100	Broken Belt
00000200	Not used
00000400	Not used
00000800	Reserved
00001000	Reserved
00002000	Reserved
00004000	Reserved
00008000	Reserved
00010000	Reserved
00020000	Not used
00040000	Fans error
00080000	ECB error
00100000	Reserved
00200000	Reserved
00400000	Reserved
00800000	Reserved
01000000	Reserved
02000000	Reserved
04000000	Reserved
08000000	Reserved
10000000	Reserved
20000000	Reserved
40000000	Reserved
80000000	Reserved

Warning Words

Warning word , par.16-92 [Warning Word](#)

Bit (Hex)	Warning Word (par.16-92 Warning Word)
00000001	Brake check
00000002	Power card overtemperature
00000004	Ground fault
00000008	Ctrl. card overtemperature
00000010	Control word timeout
00000020	Overcurrent
00000040	Torque limit
00000080	Motor thermistor overtemp.
00000100	Motor ETR overtemperature
00000200	Inverter overloaded
00000400	DC link undervoltage
00000800	DC link overvoltage
00001000	DC link voltage low
00002000	DC link voltage high
00004000	Line phase loss
00008000	No motor
00010000	Live zero error
00020000	10 V low
00040000	Brake resistor power limit
00080000	Brake resistor short circuit
00100000	Brake chopper fault
00200000	Speed limit
00400000	Serial Communication Bus comm. fault
00800000	24 V supply fault
01000000	Line failure
02000000	Current limit
04000000	Low temperature
08000000	Voltage limit
10000000	Encoder loss
20000000	Output frequency limit
40000000	Not used
80000000	Not used

Warning word 2, par.16-93 [Warning word 2](#)

Bit (Hex)	Warning Word 2 (par.16-93 Warning word 2)
00000001	Start Delayed
00000002	Stop Delayed
00000004	Clock Failure
00000008	Reserved
00000010	Reserved
00000020	No Flow
00000040	Dry Pump
00000080	End of Curve
00000100	Broken Belt
00000200	Not used
00000400	Reserved
00000800	Reserved
00001000	Reserved
00002000	Reserved
00004000	Reserved
00008000	Reserved
00010000	Reserved
00020000	Not used
00040000	Fans warning
00080000	ECB warning
00100000	Reserved
00200000	Reserved
00400000	Reserved
00800000	Reserved
01000000	Reserved
02000000	Reserved
04000000	Reserved
08000000	Reserved
10000000	Reserved
20000000	Reserved
40000000	Reserved
80000000	Reserved

Extended Status Words

Extended status word, par.16-94 [Ext. Status Word](#)

Bit (Hex)	Extended Status Word (par.16-94 Ext. Status Word)
00000001	Ramping
00000002	AMA tuning
00000004	Start CW/CCW
00000008	Not used
00000010	Not used
00000020	Feedback high
00000040	Feedback low
00000080	Output current high
00000100	Output current low
00000200	Output frequency high
00000400	Output frequency low
00000800	Brake check OK
00001000	Braking max
00002000	Braking
00004000	Out of speed range
00008000	OVC active
00010000	AC brake
00020000	Password Timelock
00040000	Password Protection
00080000	Reference high
00100000	Reference low
00200000	Local Ref./Remote Ref.
00400000	Reserved
00800000	Reserved
01000000	Reserved
02000000	Reserved
04000000	Reserved
08000000	Reserved
10000000	Reserved
20000000	Reserved
40000000	Reserved
80000000	Reserved

Extended status word 2, par.16-95 [Ext. Status Word 2](#)

Bit (Hex)	Extended Status Word 2 (par. 16-95 Ext. Status Word 2)
00000001	Off
00000002	Hand / Auto
00000004	Not used
00000008	Not used
00000010	Not used
00000020	Relay 123 active
00000040	Start Prevented
00000080	Control ready
00000100	Drive ready
00000200	Quick Stop
00000400	DC Brake
00000800	Stop
00001000	Standby
00002000	Freeze Output Request
00004000	Freeze Output
00008000	Jog Request
00010000	Jog
00020000	Start Request
00040000	Start
00080000	Start Applied
00100000	Start Delay
00200000	Sleep
00400000	Sleep Boost
00800000	Running
01000000	Bypass
02000000	Fire Mode
04000000	Reserved
08000000	Reserved
10000000	Reserved
20000000	Reserved
40000000	Reserved
80000000	Reserved

Fault messages

Hazardous Service Procedures!

The maintenance and troubleshooting procedures recommended in this section of the manual could result in exposure to electrical, mechanical or other potential safety hazards. Always refer to the safety warnings provided throughout this manual concerning these procedures. Unless specified otherwise, disconnect all electrical power including remote disconnect and discharge all energy storing devices such as capacitors before servicing. Follow proper lockout/tagout procedures to ensure the power cannot be inadvertently energized. When necessary to work with live electrical components, have a qualified licensed electrician or other individual who has been trained in handling live electrical components perform these tasks. Failure to follow all of the recommended safety warnings provided, could result in death or serious injury.

WARNING 1, 10 volts low

The control card voltage is below 10 V from terminal 50.

Remove some of the load from terminal 50, as the 10 V supply is overloaded. Max. 15 mA or minimum 590 Ω .

This condition can be caused by a short in a connected potentiometer or improper wiring of the potentiometer.

Troubleshooting: Remove the wiring from terminal 50. If the warning clears, the problem is with the customer wiring. If the warning does not clear, replace the control card.

WARNING/ALARM 2, Live zero error

This warning or alarm will only appear if programmed by the user in par.6-01 [Live Zero Timeout Function](#). The signal on one of the analog inputs is less than 50% of the minimum value programmed for that input. This condition can be caused by broken wiring or faulty device sending the signal.

WARNING/ALARM 3, No motor

No motor has been connected to the output of the adjustable frequency drive. This warning or alarm will only appear if programmed by the user in par. 1-80 [Function at Stop](#).

Troubleshooting: Check the connection between the drive and the motor.

WARNING/ALARM 4, Mains phase loss

A phase is missing on the supply side, or the line voltage imbalance is too high. This message also appears for a fault in the input rectifier on the adjustable frequency drive. Options are programmed at par. 14-12 [Function at Mains Imbalance](#).

Troubleshooting: Check the supply voltage and supply currents to the adjustable frequency drive.

WARNING 5, DC link voltage high

The intermediate circuit voltage (DC) is higher than the high voltage warning limit. The limit is dependent on the drive voltage rating. The adjustable frequency drive is still active.

WARNING 6, DC link voltage low

The intermediate circuit voltage (DC) is lower than the low voltage warning limit. The limit is dependent on the drive voltage rating. The adjustable frequency drive is still active.

WARNING/ALARM 7, DC overvoltage

If the intermediate circuit voltage exceeds the limit, the adjustable frequency drive trips after a time.

Troubleshooting:

Extend the ramp time

Change the ramp type

Activate functions in par.2-10 [Brake Function](#)

Increase par.14-26 [Trip Delay at Inverter Fault](#)

WARNING/ALARM 8, DC undervoltage

If the intermediate circuit voltage (DC) drops below the undervoltage limit, the adjustable frequency drive checks if a 24 V backup supply is connected. If no 24 V backup supply is connected, the adjustable frequency drive trips after a fixed time delay. The time delay varies with unit size.

WARNING/ALARM 9, Inverter overloaded

The adjustable frequency drive is about to cut out because of an overload (too high current for too long). The counter for electronic, thermal inverter protection gives a warning at 98% and trips at 100%, while giving an alarm. The adjustable frequency drive *cannot* be reset until the counter is below 90%.

The fault is that the adjustable frequency drive is overloaded by more than 100% for too long. NOTE: See the derating section in the Design Guide for more details if a high switching frequency is required.

WARNING/ALARM 10, Motor overload temperature

According to the electronic thermal protection (ETR), the motor is too hot. Select whether the adjustable frequency drive gives a warning or an alarm when the counter reaches 100% in par.1-90 [Motor Thermal Protection](#). The fault is that the motor is overloaded by more than 100% for too long.

Troubleshooting:

Check if the motor is overheating.

If the motor is mechanically overloaded

That the motor par.1-24 [Motor Current](#) is set correctly.

Motor data in parameters 1-20 through 1-25 are set correctly.

The setting in par.1-91 [Motor External Fan](#).

Run AMA in par.1-29 [Automatic Motor Adaptation \(AMA\)](#).

WARNING

Live Electrical Components!

WARNING/ALARM 11, Motor thermistor overtemp

The thermistor or the thermistor connection is disconnected. Select whether the adjustable frequency drive gives a warning or an alarm when the counter reaches 100% in par.1-90 [Motor Thermal Protection](#).

Troubleshooting:

Check if the motor is overheating.

Check if the motor is mechanically overloaded.

Check that the thermistor is connected correctly between terminal 53 or 54 (analog voltage input) and terminal 50 (+10 V supply), or between terminal 18 or 19 (digital input PNP only) and terminal 50.

If a KTY sensor is used, check for correct connection between terminal 54 and 55.

If using a thermal switch or thermistor, check the programming of par.1-93 [Thermistor Source](#) matches sensor wiring.

If using a KTY sensor, check the programming of parameters 1-95, 1-96, and 1-97 match sensor wiring.

WARNING/ALARM 12, Torque limit

The torque is higher than the value in par.4-16 [Torque Limit Motor Mode](#) (in motor operation) or the torque is higher than the value in par.4-17 [Torque Limit Generator Mode](#) (in regenerative operation). par.

14-25 [Trip Delay at Torque Limit](#) can be used to change this from a warning only condition to a warning followed by an alarm.

WARNING/ALARM 13, Overcurrent

The inverter peak current limit (approx. 200% of the rated current) is exceeded. The warning lasts about 1.5 sec. Then the adjustable frequency drive trips and issues an alarm. If extended mechanical brake control is selected, trip can be reset externally.

Troubleshooting:

This fault may be caused by shock loading or fast acceleration with high inertia loads.

Turn off the adjustable frequency drive. Check if the motor shaft can be turned.

Make sure that the motor size matches the adjustable frequency drive.

Incorrect motor data in parameters 1-20 through 1-25.

WARNING

Disconnect power before proceeding.

ALARM 14, Earth (ground) fault

There is a discharge from the output phases to ground, either in the cable between the adjustable frequency drive and the motor or in the motor itself.

Troubleshooting:

Turn off the adjustable frequency drive and remove the ground fault.

Measure the resistance to ground of the motor leads and the motor with a megohmmeter to check for ground faults in the motor.

Perform current sensor test.

ALARM 15, Hardware mismatch

A fitted option is not operational with the present control board hardware or software.

Record the value of the following parameters and contact your Trane supplier:

par.15-40 [FC Type](#)

par.15-41 [Power Section](#)

par.15-42 [Voltage](#)

par.15-43 [Software Version](#)

par.15-45 [Actual Typecode String](#)

par.15-49 [SW ID Control Card](#)

par.15-50 [SW ID Power Card](#)

par.15-60 [Option Mounted](#)

par.15-61 [Option SW Version](#)

ALARM 16, Short circuit

There is short-circuiting in the motor or on the motor terminals.

Turn off the adjustable frequency drive and remove the short-circuit.

WARNING

Disconnect power before proceeding.

WARNING/ALARM 17, Control word timeout

There is no communication to the adjustable frequency drive.

The warning will only be active when par.8-04 [Control Word Timeout Function](#) is NOT set to OFF.

If par.8-04 [Control Word Timeout Function](#) is set to *Stop* and *Trip*, a warning appears and the adjustable frequency drive ramps down until it trips, while giving an alarm.

Troubleshooting:

Check connections on the serial communication cable.

Increase par.8-03 [Control Word Timeout Time](#)

Check the operation of the communication equipment.

Verify proper installation based on EMC requirements.

WARNING

Live Electrical Components!

WARNING 23, Internal fan fault

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in par.14-53 [Fan Monitor](#) ([0] Disabled).

For the D, E, and F Frame drives, the regulated voltage to the fans is monitored.

Troubleshooting:

Check fan resistance.

Check soft charge fuses.

WARNING

Disconnect power before proceeding.

WARNING 24, External fan fault

The fan warning function is an extra protection function that checks if the fan is running / mounted. The fan warning can be disabled in par.14-53 [Fan Monitor](#) ([0] Disabled).

For the D, E, and F Frame drives, the regulated voltage to the fans is monitored.

Troubleshooting:

Check fan resistance.

Check soft charge fuses.

WARNING/ALARM 28, Brake check failed

Brake resistor fault: the brake resistor is not connected or not working.

Check par.2-15 [Brake Check](#).

ALARM 29, Heatsink temp

The maximum temperature of the heatsink has been exceeded. The temperature fault will not be reset until the temperature falls below a defined heatsink temperature. The trip and reset point are different based on the drive power size.

Troubleshooting:

Ambient temperature too high.

Too long motor cable.

Incorrect clearance above and below the drive.

Dirty heatsink.

Blocked air flow around the drive.

Damaged heatsink fan.

For the D, E, and F Frame drives, this alarm is based on the temperature measured by the heatsink sensor mounted inside the IGBT modules. For the F Frame drives, this alarm can also be caused by the thermal sensor in the rectifier module.

Troubleshooting:

Check fan resistance.

Check soft charge fuses.

IGBT thermal sensor.

WARNING

Disconnect power before proceeding.

ALARM 30, Motor phase U missing

Motor phase U between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase U.

WARNING

Disconnect power before proceeding.

ALARM 31, Motor phase V missing

Motor phase V between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase V.

WARNING

Disconnect power before proceeding.

ALARM 32, Motor phase W missing

Motor phase W between the adjustable frequency drive and the motor is missing.

Turn off the adjustable frequency drive and check motor phase W.

WARNING

Disconnect power before proceeding.

ALARM 33, Inrush fault

Too many power-ups have occurred within a short time period. Let unit cool to operating temperature.

WARNING/ALARM 34, Fieldbus communication fault

The serial communication bus on the communication option card is not working.

WARNING/ALARM 35, Out of frequency ranges:

This warning is active if the output frequency has reached the high limit (set in par. 4-53) or low limit (set in par. 4-52). In *Process Control, Closed-loop* (. 1-00) this warning is displayed.

WARNING/ALARM 36, Mains failure

This warning/alarm is only active if the supply voltage to the adjustable frequency drive is lost and par. 14-10 [Line Failure](#) is NOT set to OFF. Check the fuses to the adjustable frequency drive

ALARM 38, Internal fault

It may be necessary to contact your Trane supplier. Some typical alarm messages:

0	Serial port cannot be initialized. Serious hardware failure
256-258	Power EEPROM data is defect or too old
512	Control board EEPROM data is defect or too old
513	Communication time out reading EEPROM data
514	Communication time out reading EEPROM data
515	Application Orientated Control cannot recognize the EEPROM data
516	Cannot write to the EEPROM because a write command is on progress
517	Write command is under timeout
518	Failure in the EEPROM
519	Missing or invalid Barcode data in EEPROM
783	Parameter value outside of min/max limits
1024-1279	A CAN message that has to be sent, couldn't be sent
1281	Digital Signal Processor flash timeout
1282	Power micro software version mismatch
1283	Power EEPROM data version mismatch
1284	Cannot read Digital Signal Processor software version
1299	Option SW in slot A is too old
1300	Option SW in slot B is too old
1302	Option SW in slot C1 is too old
1315	Option SW in slot A is not supported (not allowed)
1316	Option SW in slot B is not supported (not allowed)
1318	Option SW in slot C1 is not supported (not allowed)
1379	Option A did not respond when calculating Platform Version.
1380	Option B did not respond when calculating Platform Version.
1536	An exception in the Application Orientated Control is registered. Debug information written in keypad
1792	DSP watchdog is active. Debugging of power part data Motor Orientated Control data not transferred correctly
2049	Power data restarted
2064-2072	H081x: option in slot x has restarted
2080-2088	H082x: option in slot x has issued a power-up wait
2096-2104	H083x: option in slot x has issued a legal power-up wait
2304	Could not read any data from power EEPROM
2305	Missing SW version from power unit
2314	Missing power unit data from power unit
2315	Missing SW version from power unit

ALARM 39, Heatsink sensor

No feedback from the heatsink temperature sensor.

The signal from the IGBT thermal sensor is not available on the power card. The problem could be on the power card, on the gate drive card, or the ribbon cable between the power card and gate drive card.

WARNING 40, Overload of Digital Output Terminal 27

Check the load connected to terminal 27 or remove short-circuit connection. Check par.5-01 [Terminal 27 Mode](#).

WARNING 41, Overload of Digital Output Terminal 29

Check the load connected to terminal 29 or remove short-circuit connection. Check par.5-02 [Terminal 29 Mode](#).

WARNING 42, Overload of Digital Output on X30/6 or Overload of Digital Output on X30/7

For X30/6, check the load connected to X30/6 or remove short-circuit connection. Check par.5-32 [Term X30/6 Digi Out \(MCB 101\)](#).

For X30/7, check the load connected to X30/7 or remove short-circuit connection. Check par.5-33 [Term X30/7 Digi Out \(MCB 101\)](#).

ALARM 46, Power card supply

The supply on the power card is out of range.

There are three power supplies generated by the switch mode power supply (SMPS) on the power card: 24 V, 5 V, +/-18 V. When powered with three-phase AC line voltage, all three supplied are monitored.

WARNING 47, 24 V supply low

The 24 Vdc is measured on the control card.

WARNING 48, 1.8 V supply low

The 1.8 Vdc supply used on the control card is outside of allowable limits. The power supply is measured on the control card.

WARNING 49, Speed limit

When the speed is not within the specified range in par. 4-11 and par. 4-13, the drive will show a warning. When the speed is below the specified limit in par. 1-86 [Trip Speed Low \[RPM\]](#) (except when starting or stopping), the drive will trip.

ALARM 50, AMA calibration failed

Contact your Trane supplier.

ALARM 51, AMA check Unom and Inom

The setting of motor voltage, motor current, and motor power is presumably wrong. Check the settings.

ALARM 52, AMA low Inom

The motor current is too low. Check the settings.

ALARM 53, AMA big motor

The motor is too big for the AMA to be carried out.

ALARM 54, AMA small motor

The motor is too big for the AMA to be carried out.

ALARM 55, AMA Parameter out of range

The parameter values found from the motor are outside acceptable range.

ALARM 56, AMA interrupted by user

The AMA has been interrupted by the user.

ALARM 57, AMA timeout

Try to start the AMA again a number of times, until the AMA is carried out. Please note that repeated runs may heat the motor to a level where the resistances Rs and Rr are increased. In most cases, however, this is not critical.

ALARM 58, AMA internal fault

Contact your Trane supplier.

WARNING 59, Current limit

The current is higher than the value in par.4-18 [Current Limit](#).

WARNING 60, External interlock

External interlock has been activated. To resume normal operation, apply 24 Vdc to the terminal programmed for external interlock and reset the adjustable frequency drive (via serial communication, digital I/O, or by pressing the reset button on the keypad).

WARNING 61, Tracking error

An error has been detected between the calculated motor speed and the speed measurement from the feedback device. The function for warning/alarm/disable is set in 4-30, *Motor Feedback Loss Function*, error setting in 4-31, *Motor Feedback Speed Error*, and the allowed error time in 4-32, *Motor Feedback Loss Timeout*. During a commissioning procedure the function may be effective.

WARNING 62, Output frequency at maximum limit

The output frequency is higher than the value set in par.4-19 [Max Output Frequency](#)

WARNING 64, Voltage limit

The load and speed combination demands a motor voltage higher than the actual DC link voltage.

WARNING/ALARM/TRIP 65, Control card overtemperature

Control card overtemperature: The cutout temperature of the control card is 176°F [80°C].

WARNING 66, Heatsink temperature low

This warning is based on the temperature sensor in the IGBT module.

ALARM 67, Option module configuration has changed

One or more options have either been added or removed since the last power-down.

ALARM 68, Safe stop activated

Safe stop has been activated. To resume normal operation, apply 24 Vdc to terminal 37, then send a reset signal (via Bus, Digital I/O, or by pressing the reset key. See par. .

ALARM 69, Power card temperature

The temperature sensor on the power card is either too hot or too cold.

Troubleshooting:

Check the operation of the door fans.

Make sure that the filters for the door fans are not blocked.

Make sure that the connector plate is properly installed on IP 21 and IP 54 (NEMA 1 and NEMA 12) drives.

ALARM 70, Illegal FC Configuration

Actual combination of control board and power board is illegal.

ALARM 72, Dangerous failure

Safe stop with trip lock. Unexpected signal levels on safe stop.

Warning 76, Power Unit Set-up

The required number of power units does not match the detected number of active power units.

Troubleshooting:**WARNING 73, Safe stop auto restart**

Safe stopped. Note that with automatic restart enabled, the motor may start when the fault is cleared.

WARNING 77, Reduced power mode:

This warning indicates that the drive is operating in reduced power mode (i.e., less than the allowed number of inverter sections). This warning will be generated on power cycle when the drive is set to run with fewer inverters and will remain on.

ALARM 79, Illegal power section configuration

The scaling card is the incorrect t number or not installed. Also MK102 connector on the power card could not be installed.

ALARM 80, Drive initialized to default value

Parameter settings are initialized to default settings after a manual reset.

ALARM 91, Analog input 54 wrong settings

Switch S202 has to be set in position OFF (voltage input) when a KTY sensor is connected to analog input terminal 54.

ALARM 92, No flow

A no-load situation has been detected in the system. See parameter group 22-2.

ALARM 93, Dry pump

A no-flow situation and high speed indicates that the pump has run dry. See parameter group 22-2.

ALARM 94, End of curve

Feedback stays lower than the setpoint which may indicate leakage in the pipe system.

ALARM 95, Broken belt

Torque is below the torque level set for no load, indicating a broken belt. See parameter group 22-6.

ALARM 96, Start delayed

Motor start has been delayed due to short-cycle protection active. See parameter group 22-7.

WARNING 97, Stop delayed

Stopping the motor has been delayed due to short cycle protection is active. See parameter group 22-7.

WARNING 98, Clock fault

Clock Fault. Time is not set or RTC clock (if mounted) has failed. See parameter group 0-7.

WARNING 201, Fire Mode was Active

Fire mode has been active.

WARNING 202, Fire Mode Limits Exceeded

Fire mode has suppressed one or more warranty voiding alarms.

WARNING 203, Missing Motor

A multi-motor underload situation was detected, this could be due to, for example, a missing motor.

WARNING 204, Locked Rotor

A multi-motor overload situation was detected, which could be due to, e.g., a locked rotor.

ALARM 244, Heatsink temperature

This alarm is only for F Frame drives. It is equivalent to Alarm 29. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 drive.
- 2 = right inverter module in F1 or F3 drive.
- 3 = right inverter module in F2 or F4 drive.
- 5 = rectifier module.

ALARM 245, Heatsink sensor

This alarm is only for F Frame drives. It is equivalent to Alarm 39. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 drive.
- 2 = right inverter module in F1 or F3 drive.
- 3 = right inverter module in F2 or F4 drive.
- 5 = rectifier module.

ALARM 246, Power card supply

This alarm is only for F Frame drives. It is equivalent to Alarm 46. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 drive.
- 2 = right inverter module in F1 or F3 drive.
- 3 = right inverter module in F2 or F4 drive.
- 5 = rectifier module.

ALARM 247, Power card temperature

This alarm is only for F Frame drives. It is equivalent to Alarm 69. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 drive.
- 2 = right inverter module in F1 or F3 drive.
- 3 = right inverter module in F2 or F4 drive.
- 5 = rectifier module.

ALARM 248, Illegal power section configuration

This alarm is only for F Frame drives. It is equivalent to Alarm 79. The report value in the alarm log indicates which power module generated the alarm:

- 1 = left most inverter module.
- 2 = middle inverter module in F2 or F4 drive.
- 2 = right inverter module in F1 or F3 drive.
- 3 = right inverter module in F2 or F4 drive.
- 5 = rectifier module.

ALARM 250, New spare part

The power or switch mode power supply has been exchanged. The adjustable frequency drive type code must be restored in the EEPROM. Select the correct type code in par.14-23 [Typecode Setting](#) according to

the label on the unit. Remember to select 'Save to EEPROM' to complete.

ALARM 251, New type code

The adjustable frequency drive has a new type code.

Parameter Lists

Parameter Lists TR200

Default settings

Changes during operation:

“TRUE” means that the parameter can be changed while the adjustable frequency drive is in operation, and
 “FALSE” means that the adjustable frequency drive must be stopped before a change can be made.

4 set-up:

'All set-up': the parameter can be set individually in each of the four set-ups, i. e., one single parameter can have four different data values.

'1 set-up': data value will be the same in all set-ups.

SR:

Size related

N/A:

No default value available.

Conversion index:

This number refers to a conversion figure used when writing or reading by means of an adjustable frequency drive.

Conv. index	100	67	6	5	4	3	2	1	0	-1	-2	-3	-4	-5	-6
Conv. factor	1	1/60	1000000	100000	10000	1000	100	10	1	0.1	0.01	0.001	0.0001	0.00001	0.000001

Data type	Description	Type
2	Integer 8	Int8
3	Integer 16	Int16
4	Integer 32	Int32
5	Unsigned 8	UInt8
6	Unsigned 16	UInt16
7	Unsigned 32	UInt32
9	Visible String	VisStr
33	Normalized value 2 bytes	N2
35	Bit sequence of 16 Boolean variables	V2
54	Time difference w/o date	TimD

0-** Operation and Display

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
0-0* Basic Settings						
0-01	Language	[0] English	1 set-up	TRUE	-	UInt8
0-02	Motor Speed Unit	[1] Hz	2 set-ups	FALSE	-	UInt8
0-03	Regional Settings	[0] International	2 set-ups	FALSE	-	UInt8
0-04	Operating State at Power-up	[0] Resume	All set-ups	TRUE	-	UInt8
0-05	Local Mode Unit	[0] As Motor Speed Unit	2 set-ups	FALSE	-	UInt8
0-1* Set-up Operations						
0-10	Active Set-up	[1] Set-up 1	1 set-up	TRUE	-	UInt8
0-11	Programming Set-up	[9] Active Set-up	All set-ups	TRUE	-	UInt8
0-12	This Set-up Linked to	[0] Not linked	All set-ups	FALSE	-	UInt8
0-13	Readout: Linked Set-ups	0 N/A	All set-ups	FALSE	0	UInt16
0-14	Readout: Prog. Set-ups / Channel	0 N/A	All set-ups	TRUE	0	Int32
0-2* LCP Display						
0-20	Display Line 1.1 Small	1602	All set-ups	TRUE	-	UInt16
0-21	Display Line 1.2 Small	1614	All set-ups	TRUE	-	UInt16
0-22	Display Line 1.3 Small	1610	All set-ups	TRUE	-	UInt16
0-23	Display Line 2 Large	1613	All set-ups	TRUE	-	UInt16
0-24	Display Line 3 Large	1502	All set-ups	TRUE	-	UInt16
0-25	My Personal Menu	ExpressionLimit	1 set-up	TRUE	0	UInt16
0-3* LCP Cust. Readout						
0-30	Custom Readout Unit	[1] %	All set-ups	TRUE	-	UInt8
0-31	Custom Readout Min Value	ExpressionLimit	All set-ups	TRUE	-2	Int32
0-32	Custom Readout Max Value	100.00 CustomReadoutUnit	All set-ups	TRUE	-2	Int32
0-37	Display Text 1	0 N/A	1 set-up	TRUE	0	VisStr[25]
0-38	Display Text 2	0 N/A	1 set-up	TRUE	0	VisStr[25]
0-39	Display Text 3	0 N/A	1 set-up	TRUE	0	VisStr[25]
0-4* LCP Keypad						
0-40	[Hand on] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-41	[Off] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-42	[Auto on] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-43	[Reset] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-44	[Off/Reset] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-45	[Drive Bypass] Key on LCP	[1] Enabled	All set-ups	TRUE	-	UInt8
0-5* Copy/Save						
0-50	LCP Copy	[0] No copy	All set-ups	FALSE	-	UInt8
0-51	Set-up Copy	[0] No copy	All set-ups	FALSE	-	UInt8
0-6* Password						
0-60	Main Menu Password	100 N/A	1 set-up	TRUE	0	Int16
0-61	Access to Main Menu w/o Password	[0] Full access	1 set-up	TRUE	-	UInt8
0-65	Personal Menu Password	200 N/A	1 set-up	TRUE	0	Int16
0-66	Access to Personal Menu w/o Password	[0] Full access	1 set-up	TRUE	-	UInt8
0-7* Clock Settings						
0-70	Date and Time	ExpressionLimit	All set-ups	TRUE	0	TimeOf-Day
0-71	Date Format	null	1 set-up	TRUE	-	UInt8
0-72	Time Format	null	1 set-up	TRUE	-	UInt8
0-74	DST/Summertime	[0] OFF	1 set-up	TRUE	-	UInt8
0-76	DST/Summertime Start	ExpressionLimit	1 set-up	TRUE	0	TimeOf-Day
0-77	DST/Summertime End	ExpressionLimit	1 set-up	TRUE	0	TimeOf-Day
0-79	Clock Fault	null	1 set-up	TRUE	-	UInt8
0-81	Working Days	null	1 set-up	TRUE	-	UInt8
0-82	Additional Working Days	ExpressionLimit	1 set-up	TRUE	0	TimeOf-Day
0-83	Additional Non-Working Days	ExpressionLimit	1 set-up	TRUE	0	TimeOf-Day
0-89	Date and Time Readout	0 N/A	All set-ups	TRUE	0	VisStr[25]

1-** Load / Motor

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
1-0* General Settings						
1-00	Configuration Mode	null	All set-ups	TRUE	-	UInt8
1-03	Torque Characteristics	[3] Auto Energy Optim. VT	All set-ups	TRUE	-	UInt8
1-2* Motor Data						
1-20	Motor Power [kW]	ExpressionLimit	All set-ups	FALSE	1	UInt32
1-21	Motor Power [HP]	ExpressionLimit	All set-ups	FALSE	-2	UInt32
1-22	Motor Voltage	ExpressionLimit	All set-ups	FALSE	0	UInt16
1-23	Motor Frequency	ExpressionLimit	All set-ups	FALSE	0	UInt16
1-24	Motor Current	ExpressionLimit	All set-ups	FALSE	-2	UInt32
1-25	Motor Nominal Speed	ExpressionLimit	All set-ups	FALSE	67	UInt16
1-28	Motor Rotation Check	[0] OFF	All set-ups	FALSE	-	UInt8
1-29	Automatic Motor Adaptation (AMA)	[0] Off	All set-ups	FALSE	-	UInt8
1-3* Addl. Motor Data						
1-30	Stator Resistance (Rs)	ExpressionLimit	All set-ups	FALSE	-4	UInt32
1-31	Rotor Resistance (Rr)	ExpressionLimit	All set-ups	FALSE	-4	UInt32
1-35	Main Reactance (Xh)	ExpressionLimit	All set-ups	FALSE	-4	UInt32
1-36	Iron Loss Resistance (Rfe)	ExpressionLimit	All set-ups	FALSE	-3	UInt32
1-39	Motor Poles	ExpressionLimit	All set-ups	FALSE	0	UInt8
1-5* Load-Indep. Setting						
1-50	Motor Magnetization at Zero Speed	100 %	All set-ups	TRUE	0	UInt16
1-51	Min Speed Normal Magnetizing [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
1-52	Min Speed Normal Magnetizing [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
1-6* Load-Depend. Settg.						
1-60	Low Speed Load Compensation	100 %	All set-ups	TRUE	0	Int16
1-61	High Speed Load Compensation	100 %	All set-ups	TRUE	0	Int16
1-62	Slip Compensation	0 %	All set-ups	TRUE	0	Int16
1-63	Slip Compensation Time Constant	ExpressionLimit	All set-ups	TRUE	-2	UInt16
1-64	Resonance Dampening	100 %	All set-ups	TRUE	0	UInt16
1-65	Resonance Dampening Time Constant	5 ms	All set-ups	TRUE	-3	UInt8
1-7* Start Adjustments						
1-71	Start Delay	0.0 s	All set-ups	TRUE	-1	UInt16
1-73	Flying Start	[0] Disabled	All set-ups	TRUE	-	UInt8
1-8* Stop Adjustments						
1-80	Function at Stop	[0] Coast	All set-ups	TRUE	-	UInt8
1-81	Min Speed for Function at Stop [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
1-82	Min Speed for Function at Stop [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
1-86	Trip Speed Low [RPM]	0 RPM	All set-ups	TRUE	67	UInt16
1-87	Trip Speed Low [Hz]	0.0 Hz	All set-ups	TRUE	-1	UInt16
1-9* Motor Temperature						
1-90	Motor Thermal Protection	[4] ETR trip 1	All set-ups	TRUE	-	UInt8
1-91	Motor External Fan	[0] No	All set-ups	TRUE	-	UInt16
1-93	Thermistor Source	[0] None	All set-ups	TRUE	-	UInt8

2-** Brakes

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
2-0* DC Brake						
2-00	DC Hold/Preheat Current	50 %	All set-ups	TRUE	0	Uint8
2-01	DC Brake Current	50 %	All set-ups	TRUE	0	Uint16
2-02	DC Braking Time	10.0 s	All set-ups	TRUE	-1	Uint16
2-03	DC Brake Cut-in Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
2-04	DC Brake Cut-in Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
2-1* Brake Energy Funct.						
2-10	Brake Function	[0] Off	All set-ups	TRUE	-	Uint8
2-11	Brake Resistor (ohm)	ExpressionLimit	All set-ups	TRUE	-2	Uint32
2-12	Brake Power Limit (kW)	ExpressionLimit	All set-ups	TRUE	0	Uint32
2-13	Brake Power Monitoring	[0] Off	All set-ups	TRUE	-	Uint8
2-15	Brake Check	[0] Off	All set-ups	TRUE	-	Uint8
2-16	AC Brake Max. Current	100.0 %	All set-ups	TRUE	-1	Uint32
2-17	Over-voltage Control	[2] Enabled	All set-ups	TRUE	-	Uint8

3-** Reference / Ramps

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
3-0* Reference Limits						
3-02	Minimum Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
3-03	Maximum Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
3-04	Reference Function	null	All set-ups	TRUE	-	Uint8
3-1* References						
3-10	Preset Reference	0.00 %	All set-ups	TRUE	-2	Int16
3-11	Jog Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
3-13	Reference Site	[0] Linked to Hand / Auto	All set-ups	TRUE	-	Uint8
3-14	Preset Relative Reference	0.00 %	All set-ups	TRUE	-2	Int32
3-15	Reference 1 Source	[1] Analog input 53	All set-ups	TRUE	-	Uint8
3-16	Reference 2 Source	[20] Digital pot.meter	All set-ups	TRUE	-	Uint8
3-17	Reference 3 Source	[0] No function	All set-ups	TRUE	-	Uint8
3-19	Jog Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
3-4* Ramp 1						
3-41	Ramp 1 Ramp-up Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
3-42	Ramp 1 Ramp-down Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
3-5* Ramp 2						
3-51	Ramp 2 Ramp-up Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
3-52	Ramp 2 Ramp-down Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
3-8* Other Ramps						
3-80	Jog Ramp Time	ExpressionLimit	All set-ups	TRUE	-2	Uint32
3-81	Quick Stop Ramp Time	ExpressionLimit	2 set-ups	TRUE	-2	Uint32
3-9* Digital Pot. meter						
3-90	Step Size	0.10 %	All set-ups	TRUE	-2	Uint16
3-91	Ramp Time	1.00 s	All set-ups	TRUE	-2	Uint32
3-92	Power Restore	[0] Off	All set-ups	TRUE	-	Uint8
3-93	Maximum Limit	100 %	All set-ups	TRUE	0	Int16
3-94	Minimum Limit	0 %	All set-ups	TRUE	0	Int16
3-95	Ramp Delay	ExpressionLimit	All set-ups	TRUE	-3	TimD

4-** Limits / Warnings

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
4-1* Motor Limits						
4-10	Motor Speed Direction	[2] Both directions	All set-ups	FALSE	-	UInt8
4-11	Motor Speed Low Limit [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
4-12	Motor Speed Low Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
4-13	Motor Speed High Limit [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
4-14	Motor Speed High Limit [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
4-16	Torque Limit Motor Mode	ExpressionLimit	All set-ups	TRUE	-1	UInt16
4-17	Torque Limit Generator Mode	100.0 %	All set-ups	TRUE	-1	UInt16
4-18	Current Limit	ExpressionLimit	All set-ups	TRUE	-1	UInt32
4-19	Max Output Frequency	ExpressionLimit	All set-ups	FALSE	-1	UInt16
4-5* Adj. Warnings						
4-50	Warning Current Low	0.00 A	All set-ups	TRUE	-2	UInt32
4-51	Warning Current High	I _{max} VLT (P1637)	All set-ups	TRUE	-2	UInt32
4-52	Warning Speed Low	0 RPM	All set-ups	TRUE	67	UInt16
4-53	Warning Speed High	outputSpeedHighLimit (P413)	All set-ups	TRUE	67	UInt16
4-54	Warning Reference Low	-999999.999 N/A	All set-ups	TRUE	-3	Int32
4-55	Warning Reference High	999999.999 N/A	All set-ups	TRUE	-3	Int32
4-56	Warning Feedback Low	-999999.999 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
4-57	Warning Feedback High	999999.999 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
4-58	Missing Motor Phase Function	[2] Trip 1000 ms	All set-ups	TRUE	-	UInt8
4-6* Speed Bypass						
4-60	Bypass Speed From [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
4-61	Bypass Speed From [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
4-62	Bypass Speed to [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
4-63	Bypass Speed To [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
4-64	Semi-Auto Bypass Set-up	[0] OFF	All set-ups	FALSE	-	UInt8

5-** Digital In / Out

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
5-0* Digital I/O mode						
5-00	Digital I/O Mode	[0] PNP - Active at 24 V	All set-ups	FALSE	-	Uint8
5-01	Terminal 27 Mode	[0] Input	All set-ups	TRUE	-	Uint8
5-02	Terminal 29 Mode	[0] Input	All set-ups	TRUE	-	Uint8
5-1* Digital Inputs						
5-10	Terminal 18 Digital Input	[8] Start	All set-ups	TRUE	-	Uint8
5-11	Terminal 19 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-12	Terminal 27 Digital Input	null	All set-ups	TRUE	-	Uint8
5-13	Terminal 29 Digital Input	[14] Jog	All set-ups	TRUE	-	Uint8
5-14	Terminal 32 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-15	Terminal 33 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-16	Terminal X30/2 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-17	Terminal X30/3 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-18	Terminal X30/4 Digital Input	[0] No operation	All set-ups	TRUE	-	Uint8
5-3* Digital Outputs						
5-30	Terminal 27 Digital Output	[0] No operation	All set-ups	TRUE	-	Uint8
5-31	Terminal 29 digital Output	[0] No operation	All set-ups	TRUE	-	Uint8
5-32	Term X30/6 Digi Out (MCB 101)	[0] No operation	All set-ups	TRUE	-	Uint8
5-33	Term X30/7 Digi Out (MCB 101)	[0] No operation	All set-ups	TRUE	-	Uint8
5-4* Relays						
5-40	Function Relay	null	All set-ups	TRUE	-	Uint8
5-41	On Delay, Relay	0.01 s	All set-ups	TRUE	-2	Uint16
5-42	Off Delay, Relay	0.01 s	All set-ups	TRUE	-2	Uint16
5-5* Pulse Input						
5-50	Term. 29 Low Frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-51	Term. 29 High Frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-52	Term. 29 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
5-53	Term. 29 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
5-54	Pulse Filter Time Constant #29	100 ms	All set-ups	FALSE	-3	Uint16
5-55	Term. 33 Low Frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-56	Term. 33 High Frequency	100 Hz	All set-ups	TRUE	0	Uint32
5-57	Term. 33 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
5-58	Term. 33 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
5-59	Pulse Filter Time Constant #33	100 ms	All set-ups	FALSE	-3	Uint16
5-6* Pulse Output						
5-60	Terminal 27 Pulse Output Variable	[0] No operation	All set-ups	TRUE	-	Uint8
5-62	Pulse Output Max Freq #27	5000 Hz	All set-ups	TRUE	0	Uint32
5-63	Terminal 29 Pulse Output Variable	[0] No operation	All set-ups	TRUE	-	Uint8
5-65	Pulse Output Max Freq #29	5000 Hz	All set-ups	TRUE	0	Uint32
5-66	Terminal X30/6 Pulse Output Variable	[0] No operation	All set-ups	TRUE	-	Uint8
5-68	Pulse Output Max Freq #X30/6	5000 Hz	All set-ups	TRUE	0	Uint32
5-9* Bus Controlled						
5-90	Digital & Relay Bus Control	0 N/A	All set-ups	TRUE	0	Uint32
5-93	Pulse Out #27 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
5-94	Pulse Out #27 Timeout Preset	0.00 %	1 set-up	TRUE	-2	Uint16
5-95	Pulse Out #29 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
5-96	Pulse Out #29 Timeout Preset	0.00 %	1 set-up	TRUE	-2	Uint16
5-97	Pulse Out #X30/6 Bus Control	0.00 %	All set-ups	TRUE	-2	N2
5-98	Pulse Out #X30/6 Timeout Preset	0.00 %	1 set-up	TRUE	-2	Uint16

6-** Analog In / Out

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
6-0* Analog I/O Mode						
6-00	Live Zero Timeout Time	10 s	All set-ups	TRUE	0	UInt8
6-01	Live Zero Timeout Function	[0] Off	All set-ups	TRUE	-	UInt8
6-02	Fire Mode Live Zero Timeout Function	[0] Off	All set-ups	TRUE	-	UInt8
6-1* Analog Input 53						
6-10	Terminal 53 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-11	Terminal 53 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-12	Terminal 53 Low Current	4.00 mA	All set-ups	TRUE	-5	Int16
6-13	Terminal 53 High Current	20.00 mA	All set-ups	TRUE	-5	Int16
6-14	Terminal 53 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
6-15	Terminal 53 High Ref./Feedb. Value	ExpressionLimit	All set-ups	TRUE	-3	Int32
6-16	Terminal 53 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
6-17	Terminal 53 Live Zero	[1] Enabled	All set-ups	TRUE	-	UInt8
6-2* Analog Input 54						
6-20	Terminal 54 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-21	Terminal 54 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-22	Terminal 54 Low Current	4.00 mA	All set-ups	TRUE	-5	Int16
6-23	Terminal 54 High Current	20.00 mA	All set-ups	TRUE	-5	Int16
6-24	Terminal 54 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
6-25	Terminal 54 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
6-26	Terminal 54 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
6-27	Terminal 54 Live Zero	[1] Enabled	All set-ups	TRUE	-	UInt8
6-3* Analog Input X30/11						
6-30	Terminal X30/11 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-31	Terminal X30/11 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-34	Term. X30/11 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
6-35	Term. X30/11 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
6-36	Term. X30/11 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
6-37	Term. X30/11 Live Zero	[1] Enabled	All set-ups	TRUE	-	UInt8
6-4* Analog Input X30/12						
6-40	Terminal X30/12 Low Voltage	0.07 V	All set-ups	TRUE	-2	Int16
6-41	Terminal X30/12 High Voltage	10.00 V	All set-ups	TRUE	-2	Int16
6-44	Term. X30/12 Low Ref./Feedb. Value	0.000 N/A	All set-ups	TRUE	-3	Int32
6-45	Term. X30/12 High Ref./Feedb. Value	100.000 N/A	All set-ups	TRUE	-3	Int32
6-46	Term. X30/12 Filter Time Constant	0.001 s	All set-ups	TRUE	-3	UInt16
6-47	Term. X30/12 Live Zero	[1] Enabled	All set-ups	TRUE	-	UInt8
6-5* Analog Output 42						
6-50	Terminal 42 Output	null	All set-ups	TRUE	-	UInt8
6-51	Terminal 42 Output Min Scale	0.00 %	All set-ups	TRUE	-2	Int16
6-52	Terminal 42 Output Max Scale	100.00 %	All set-ups	TRUE	-2	Int16
6-53	Terminal 42 Output Bus Control	0.00 %	All set-ups	TRUE	-2	N2
6-54	Terminal 42 Output Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16
6-6* Analog Output X30/8						
6-60	Terminal X30/8 Output	[0] No operation	All set-ups	TRUE	-	UInt8
6-61	Terminal X30/8 Min. Scale	0.00 %	All set-ups	TRUE	-2	Int16
6-62	Terminal X30/8 Max. Scale	100.00 %	All set-ups	TRUE	-2	Int16
6-63	Terminal X30/8 Output Bus Control	0.00 %	All set-ups	TRUE	-2	N2
6-64	Terminal X30/8 Output Timeout Preset	0.00 %	1 set-up	TRUE	-2	UInt16

8-** Communication and Options

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
8-0* General Settings						
8-01	Control Site	null	All set-ups	TRUE	-	UInt8
8-02	Control Source	null	All set-ups	TRUE	-	UInt8
8-03	Control Timeout Time	ExpressionLimit	1 set-up	TRUE	-1	UInt32
8-04	Control Timeout Function	[0] Off	1 set-up	TRUE	-	UInt8
8-05	End-of-Timeout Function	[1] Resume set-up	1 set-up	TRUE	-	UInt8
8-06	Reset Control Timeout	[0] Do not reset	All set-ups	TRUE	-	UInt8
8-07	Diagnosis Trigger	[0] Disable	2 set-ups	TRUE	-	UInt8
8-1* Control Settings						
8-10	Control Profile	[0] FC profile	All set-ups	FALSE	-	UInt8
8-13	Configurable Status Word STW	[1] Profile Default	All set-ups	TRUE	-	UInt8
8-3* FC Port Settings						
8-30	Protocol	null	1 set-up	TRUE	-	UInt8
8-31	Address	ExpressionLimit	1 set-up	TRUE	0	UInt8
8-32	Baud Rate	null	1 set-up	TRUE	-	UInt8
8-33	Parity / Stop Bits	null	1 set-up	TRUE	-	UInt8
8-35	Minimum Response Delay	ExpressionLimit	1 set-up	TRUE	-3	UInt16
8-36	Maximum Response Delay	ExpressionLimit	1 set-up	TRUE	-3	UInt16
8-37	Maximum Inter-Char Delay	ExpressionLimit	1 set-up	TRUE	-5	UInt16
8-4* FC MC protocol set						
8-40	Telegram selection	[1] Standard telegram 1	2 set-ups	TRUE	-	UInt8
8-5* Digital / Bus						
8-50	Coasting Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-52	DC Brake Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-53	Start Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-54	Reverse Select	null	All set-ups	TRUE	-	UInt8
8-55	Set-up Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-56	Preset Reference Select	[3] Logic OR	All set-ups	TRUE	-	UInt8
8-7* BACnet						
8-70	BACnet Device Instance	1 N/A	1 set-up	TRUE	0	UInt32
8-72	MS/TP Max Masters	127 N/A	1 set-up	TRUE	0	UInt8
8-73	MS/TP Max Info Frames	1 N/A	1 set-up	TRUE	0	UInt16
8-74	"I-Am" Service	[0] Send at power-up	1 set-up	TRUE	-	UInt8
8-75	Initialization Password	ExpressionLimit	1 set-up	TRUE	0	VisStr[20]
8-8* FC Port Diagnostics						
8-80	Bus Message Count	0 N/A	All set-ups	TRUE	0	UInt32
8-81	Bus Error Count	0 N/A	All set-ups	TRUE	0	UInt32
8-82	Slave Messages Rcvd	0 N/A	All set-ups	TRUE	0	UInt32
8-83	Slave Error Count	0 N/A	All set-ups	TRUE	0	UInt32
8-84	Slave Messages Sent	0 N/A	All set-ups	TRUE	0	UInt32
8-85	Slave Timeout Errors	0 N/A	All set-ups	TRUE	0	UInt32
8-89	Diagnostics Count	0 N/A	1 set-up	TRUE	0	Int32
8-9* Bus Jog						
8-90	Bus Jog 1 Speed	100 RPM	All set-ups	TRUE	67	UInt16
8-91	Bus Jog 2 Speed	200 RPM	All set-ups	TRUE	67	UInt16
8-94	Bus Feedback 1	0 N/A	1 set-up	TRUE	0	N2
8-95	Bus Feedback 2	0 N/A	1 set-up	TRUE	0	N2
8-96	Bus Feedback 3	0 N/A	1 set-up	TRUE	0	N2

11-** LonWorks

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
11-0* LonWorks ID						
11-00	Neuron ID	0 N/A	All set-ups	TRUE	0	OctStr[6]
11-1* LON Functions						
11-10	Drive Profile	[0] VSD profile	All set-ups	TRUE	-	UInt8
11-15	LON Warning Word	0 N/A	All set-ups	TRUE	0	UInt16
11-17	XIF Revision	0 N/A	All set-ups	TRUE	0	VisStr[5]
11-18	LonWorks Revision	0 N/A	All set-ups	TRUE	0	VisStr[5]
11-2* LON Param. Access						
11-21	Store Data Values	[0] Off	All set-ups	TRUE	-	UInt8

13-** Smart Logic Controller

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
13-0* SLC Settings						
13-00	SL Controller Mode	null	2 set-ups	TRUE	-	UInt8
13-01	Start Event	null	2 set-ups	TRUE	-	UInt8
13-02	Stop Event	null	2 set-ups	TRUE	-	UInt8
13-03	Reset SLC	[0] Do not reset SLC	All set-ups	TRUE	-	UInt8
13-1* Comparators						
13-10	Comparator Operand	null	2 set-ups	TRUE	-	UInt8
13-11	Comparator Operator	null	2 set-ups	TRUE	-	UInt8
13-12	Comparator Value	ExpressionLimit	2 set-ups	TRUE	-3	Int32
13-2* Timers						
13-20	SL Controller Timer	ExpressionLimit	1 set-up	TRUE	-3	TimD
13-4* Logic Rules						
13-40	Logic Rule Boolean 1	null	2 set-ups	TRUE	-	UInt8
13-41	Logic Rule Operator 1	null	2 set-ups	TRUE	-	UInt8
13-42	Logic Rule Boolean 2	null	2 set-ups	TRUE	-	UInt8
13-43	Logic Rule Operator 2	null	2 set-ups	TRUE	-	UInt8
13-44	Logic Rule Boolean 3	null	2 set-ups	TRUE	-	UInt8
13-5* States						
13-51	SL Controller Event	null	2 set-ups	TRUE	-	UInt8
13-52	SL Controller Action	null	2 set-ups	TRUE	-	UInt8

14-** Special Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
14-0* Inverter Switching						
14-00	Switching Pattern	null	All set-ups	TRUE	-	UInt8
14-01	Switching Frequency	null	All set-ups	TRUE	-	UInt8
14-03	Overmodulation	[1] On	All set-ups	FALSE	-	UInt8
14-04	PWM Random	[0] Off	All set-ups	TRUE	-	UInt8
14-1* Mains On/Off						
14-10	Mains Failure	[0] No function	All set-ups	FALSE	-	UInt8
14-11	Mains Voltage at Mains Fault	ExpressionLimit	All set-ups	TRUE	0	UInt16
14-12	Function at Mains Imbalance	[0] Trip	All set-ups	TRUE	-	UInt8
14-2* Reset Functions						
14-20	Reset Mode	null	All set-ups	TRUE	-	UInt8
14-21	Automatic Restart Time	10 s	All set-ups	TRUE	0	UInt16
14-22	Operation Mode	[0] Normal operation	All set-ups	TRUE	-	UInt8
14-23	Typecode Setting	null	2 set-ups	FALSE	-	UInt8
14-25	Trip Delay at Torque Limit	60 s	All set-ups	TRUE	0	UInt8
14-26	Trip Delay at Inverter Fault	ExpressionLimit	All set-ups	TRUE	0	UInt8
14-28	Production Settings	[0] No action	All set-ups	TRUE	-	UInt8
14-29	Service Code	0 N/A	All set-ups	TRUE	0	Int32
14-3* Current Limit Ctrl.						
14-30	Current Lim Cont, Proportional Gain	100 %	All set-ups	FALSE	0	UInt16
14-31	Current Lim Contr, Integration Time	0.020 s	All set-ups	FALSE	-3	UInt16
14-32	Current Lim Ctrl, Filter Time	26.0 ms	All set-ups	TRUE	-4	UInt16
14-4* Energy Optimizing						
14-40	VT Level	66 %	All set-ups	FALSE	0	UInt8
14-41	AEO Minimum Magnetization	ExpressionLimit	All set-ups	TRUE	0	UInt8
14-42	Minimum AEO Frequency	10 Hz	All set-ups	TRUE	0	UInt8
14-43	Motor Cos-Phi	ExpressionLimit	All set-ups	TRUE	-2	UInt16
14-5* Environment						
14-50	RFI 1	[1] On	1 set-up	FALSE	-	UInt8
14-52	Fan Control	[0] Auto	All set-ups	TRUE	-	UInt8
14-53	Fan Monitor	[1] Warning	All set-ups	TRUE	-	UInt8
14-55	Output Filter	[0] No Filter	1 set-up	FALSE	-	UInt8
14-59	Actual Number of Inverter Units	ExpressionLimit	1 set-up	FALSE	0	UInt8
14-6* Auto Derate						
14-60	Function at Overtemperature	[0] Trip	All set-ups	TRUE	-	UInt8
14-61	Function at Inverter Overload	[0] Trip	All set-ups	TRUE	-	UInt8
14-62	Inv. Overload Derate Current	95 %	All set-ups	TRUE	0	UInt16

15-** Adjustable Frequency Drive Information

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
15-0* Operating Data						
15-00	Operating Hours	0 h	All set-ups	FALSE	74	UInt32
15-01	Running Hours	0 h	All set-ups	FALSE	74	UInt32
15-02	kWh Counter	0 kWh	All set-ups	FALSE	75	UInt32
15-03	Power-ups	0 N/A	All set-ups	FALSE	0	UInt32
15-04	Over Temps	0 N/A	All set-ups	FALSE	0	UInt16
15-05	Over Volts	0 N/A	All set-ups	FALSE	0	UInt16
15-06	Reset kWh Counter	[0] Do not reset	All set-ups	TRUE	-	UInt8
15-07	Reset Running Hours Counter	[0] Do not reset	All set-ups	TRUE	-	UInt8
15-08	Number of Starts	0 N/A	All set-ups	FALSE	0	UInt32
15-1* Data Log Settings						
15-10	Logging Source	0	2 set-ups	TRUE	-	UInt16
15-11	Logging Interval	ExpressionLimit	2 set-ups	TRUE	-3	TimD
15-12	Trigger Event	[0] FALSE	1 set-up	TRUE	-	UInt8
15-13	Logging Mode	[0] Log always	2 set-ups	TRUE	-	UInt8
15-14	Samples Before Trigger	50 N/A	2 set-ups	TRUE	0	UInt8
15-2* Historic Log						
15-20	Historic Log: Event	0 N/A	All set-ups	FALSE	0	UInt8
15-21	Historic Log: Value	0 N/A	All set-ups	FALSE	0	UInt32
15-22	Historic Log: Time	0 ms	All set-ups	FALSE	-3	UInt32
15-23	Historic Log: Date and Time	ExpressionLimit	All set-ups	FALSE	0	TimeOfDay
15-3* Alarm Log						
15-30	Alarm Log: Error Code	0 N/A	All set-ups	FALSE	0	UInt8
15-31	Alarm Log: Value	0 N/A	All set-ups	FALSE	0	Int16
15-32	Alarm Log: Time	0 s	All set-ups	FALSE	0	UInt32
15-33	Alarm Log: Date and Time	ExpressionLimit	All set-ups	FALSE	0	TimeOfDay
15-4* Drive Identification						
15-40	FC Type	0 N/A	All set-ups	FALSE	0	VisStr[6]
15-41	Power Section	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-42	Voltage	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-43	Software Version	0 N/A	All set-ups	FALSE	0	VisStr[5]
15-44	Ordered Typecode String	0 N/A	All set-ups	FALSE	0	VisStr[40]
15-45	Actual Typecode String	0 N/A	All set-ups	FALSE	0	VisStr[40]
15-46	Adj Freq Dr Ordering No.	0 N/A	All set-ups	FALSE	0	VisStr[8]
15-47	Power Card Ordering No.	0 N/A	All set-ups	FALSE	0	VisStr[8]
15-48	LCP ID Num.	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-49	SW ID Control Card	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-50	SW ID Power Card	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-51	Adj Freq Dr Serial No.	0 N/A	All set-ups	FALSE	0	VisStr[10]
15-53	Power Card Serial Number	0 N/A	All set-ups	FALSE	0	VisStr[19]
15-6* Option Ident						
15-60	Option Mounted	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-61	Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-62	Option Ordering No	0 N/A	All set-ups	FALSE	0	VisStr[8]
15-63	Option Serial No	0 N/A	All set-ups	FALSE	0	VisStr[18]
15-70	Option in Slot A	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-71	Slot A Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-72	Option in Slot B	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-73	Slot B Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-74	Option in Slot C0	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-75	Slot C0 Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-76	Option in Slot C1	0 N/A	All set-ups	FALSE	0	VisStr[30]
15-77	Slot C1 Option SW Version	0 N/A	All set-ups	FALSE	0	VisStr[20]
15-9* Parameter Info						
15-92	Defined Parameters	0 N/A	All set-ups	FALSE	0	UInt16
15-93	Modified Parameters	0 N/A	All set-ups	FALSE	0	UInt16
15-98	Drive Identification	0 N/A	All set-ups	FALSE	0	VisStr[40]
15-99	Parameter Metadata	0 N/A	All set-ups	FALSE	0	UInt16

16-** Data Readouts

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
16-0* General Status						
16-00	Control Word	0 N/A	All set-ups	FALSE	0	V2
16-01	Reference [Unit]	0.000 ReferenceFeedbackUnit	All set-ups	FALSE	-3	Int32
16-02	Reference %	0.0 %	All set-ups	FALSE	-1	Int16
16-03	Status Word	0 N/A	All set-ups	FALSE	0	V2
16-05	Main Actual Value [%]	0.00 %	All set-ups	FALSE	-2	N2
16-09	Custom Readout	0.00 CustomReadoutUnit	All set-ups	FALSE	-2	Int32
16-1* Motor Status						
16-10	Power [kW]	0.00 kW	All set-ups	FALSE	1	Int32
16-11	Power [hp]	0.00 hp	All set-ups	FALSE	-2	Int32
16-12	Motor voltage	0.0 V	All set-ups	FALSE	-1	UInt16
16-13	Frequency	0.0 Hz	All set-ups	FALSE	-1	UInt16
16-14	Motor Current	0.00 A	All set-ups	FALSE	-2	Int32
16-15	Frequency [%]	0.00 %	All set-ups	FALSE	-2	N2
16-16	Torque [Nm]	0.0 Nm	All set-ups	FALSE	-1	Int32
16-17	Speed [RPM]	0 RPM	All set-ups	FALSE	67	Int32
16-18	Motor Thermal	0 %	All set-ups	FALSE	0	UInt8
16-22	Torque [%]	0 %	All set-ups	FALSE	0	Int16
16-26	Power Filtered [kW]	0.000 kW	All set-ups	FALSE	0	Int32
16-27	Power Filtered [hp]	0.000 hp	All set-ups	FALSE	-3	Int32
16-3* Drive Status						
16-30	DC Link Voltage	0 V	All set-ups	FALSE	0	UInt16
16-32	Brake Energy /s	0.000 kW	All set-ups	FALSE	0	UInt32
16-33	Brake Energy /2 min	0.000 kW	All set-ups	FALSE	0	UInt32
16-34	Heatsink Temp.	0 °C	All set-ups	FALSE	100	UInt8
16-35	Inverter Thermal	0 %	All set-ups	FALSE	0	UInt8
16-36	Inv. Nom. Current	ExpressionLimit	All set-ups	FALSE	-2	UInt32
16-37	Inv. Max. Current	ExpressionLimit	All set-ups	FALSE	-2	UInt32
16-38	SL Controller State	0 N/A	All set-ups	FALSE	0	UInt8
16-39	Control Card Temp.	0 °C	All set-ups	FALSE	100	UInt8
16-40	Logging Buffer Full	[0] No	All set-ups	TRUE	-	UInt8
16-49	Current Fault Source	0 N/A	All set-ups	TRUE	0	UInt8
16-5* Ref. & Feedb.						
16-50	External Reference	0.0 N/A	All set-ups	FALSE	-1	Int16
16-52	Feedback [Unit]	0.000 ProcessCtrlUnit	All set-ups	FALSE	-3	Int32
16-53	Digi Pot Reference	0.00 N/A	All set-ups	FALSE	-2	Int16
16-54	Feedback 1 [Unit]	0.000 ProcessCtrlUnit	All set-ups	FALSE	-3	Int32
16-55	Feedback 2 [Unit]	0.000 ProcessCtrlUnit	All set-ups	FALSE	-3	Int32
16-56	Feedback 3 [Unit]	0.000 ProcessCtrlUnit	All set-ups	FALSE	-3	Int32
16-58	PID Output [%]	0.0 %	All set-ups	TRUE	-1	Int16
16-6* Inputs & Outputs						
16-60	Digital Input	0 N/A	All set-ups	FALSE	0	UInt16
16-61	Terminal 53 Switch Setting	[0] Current	All set-ups	FALSE	-	UInt8
16-62	Analog Input 53	0.000 N/A	All set-ups	FALSE	-3	Int32
16-63	Terminal 54 Switch Setting	[0] Current	All set-ups	FALSE	-	UInt8
16-64	Analog Input 54	0.000 N/A	All set-ups	FALSE	-3	Int32
16-65	Analog Output 42 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
16-66	Digital Output [bin]	0 N/A	All set-ups	FALSE	0	Int16
16-67	Pulse Input #29 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
16-68	Pulse Input #33 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
16-69	Pulse Output #27 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
16-70	Pulse Output #29 [Hz]	0 N/A	All set-ups	FALSE	0	Int32
16-71	Relay Output [bin]	0 N/A	All set-ups	FALSE	0	Int16
16-72	Counter A	0 N/A	All set-ups	TRUE	0	Int32
16-73	Counter B	0 N/A	All set-ups	TRUE	0	Int32
16-75	Analog In X30/11	0.000 N/A	All set-ups	FALSE	-3	Int32
16-76	Analog In X30/12	0.000 N/A	All set-ups	FALSE	-3	Int32
16-77	Analog Out X30/8 [mA]	0.000 N/A	All set-ups	FALSE	-3	Int16
16-8* Fieldbus & FC Port						
16-80	Fieldbus CTW 1	0 N/A	All set-ups	FALSE	0	V2
16-82	Fieldbus REF 1	0 N/A	All set-ups	FALSE	0	N2
16-84	Comm. Option Status	0 N/A	All set-ups	FALSE	0	V2
16-85	FC Port CTW 1	0 N/A	All set-ups	FALSE	0	V2
16-86	FC Port REF 1	0 N/A	All set-ups	FALSE	0	N2
16-9* Diagnosis Readouts						
16-90	Alarm Word	0 N/A	All set-ups	FALSE	0	UInt32
16-91	Alarm word 2	0 N/A	All set-ups	FALSE	0	UInt32
16-92	Warning Word	0 N/A	All set-ups	FALSE	0	UInt32
16-93	Warning word 2	0 N/A	All set-ups	FALSE	0	UInt32
16-94	Ext. Status Word	0 N/A	All set-ups	FALSE	0	UInt32
16-95	Ext. Status Word 2	0 N/A	All set-ups	FALSE	0	UInt32
16-96	Maintenance Word	0 N/A	All set-ups	FALSE	0	UInt32

18-** Info & Readouts

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
18-0* Maintenance Log						
18-00	Maintenance Log: Item	0 N/A	All set-ups	FALSE	0	UInt8
18-01	Maintenance Log: Action	0 N/A	All set-ups	FALSE	0	UInt8
18-02	Maintenance Log: Time	0 s	All set-ups	FALSE	0	UInt32
18-03	Maintenance Log: Date and Time	ExpressionLimit	All set-ups	FALSE	0	TimeOf-Day
18-1* Fire Mode Log						
18-10	Fire Mode Log: Event	0 N/A	All set-ups	FALSE	0	UInt8
18-11	Fire Mode Log: Time	0 s	All set-ups	FALSE	0	UInt32
18-12	Fire Mode Log: Date and Time	ExpressionLimit	All set-ups	FALSE	0	TimeOf-Day
18-3* Inputs & Outputs						
18-30	Analog Input X42/1	0.000 N/A	All set-ups	FALSE	-3	Int32
18-31	Analog Input X42/3	0.000 N/A	All set-ups	FALSE	-3	Int32
18-32	Analog Input X42/5	0.000 N/A	All set-ups	FALSE	-3	Int32
18-33	Analog Out X42/7 [V]	0.000 N/A	All set-ups	FALSE	-3	Int16
18-34	Analog Out X42/9 [V]	0.000 N/A	All set-ups	FALSE	-3	Int16
18-35	Analog Out X42/11 [V]	0.000 N/A	All set-ups	FALSE	-3	Int16
18-5* Ref. & Feedb.						
18-50	Sensorless Readout [unit]	0.000 SensorlessUnit	All set-ups	FALSE	-3	Int32

20-** FC Closed-loop

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
20-0* Feedback						
20-00	Feedback 1 Source	[2] Analog input 54	All set-ups	TRUE	-	UInt8
20-01	Feedback 1 Conversion	[0] Linear	All set-ups	FALSE	-	UInt8
20-02	Feedback 1 Source Unit	null	All set-ups	TRUE	-	UInt8
20-03	Feedback 2 Source	[0] No function	All set-ups	TRUE	-	UInt8
20-04	Feedback 2 Conversion	[0] Linear	All set-ups	FALSE	-	UInt8
20-05	Feedback 2 Source Unit	null	All set-ups	TRUE	-	UInt8
20-06	Feedback 3 Source	[0] No function	All set-ups	TRUE	-	UInt8
20-07	Feedback 3 Conversion	[0] Linear	All set-ups	FALSE	-	UInt8
20-08	Feedback 3 Source Unit	null	All set-ups	TRUE	-	UInt8
20-12	Reference/Feedback Unit	null	All set-ups	TRUE	-	UInt8
20-13	Minimum Reference/Feedb.	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-14	Maximum Reference/Feedb.	100.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-2* Feedback/Setpoint						
20-20	Feedback Function	[3] Minimum	All set-ups	TRUE	-	UInt8
20-21	Setpoint 1	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-22	Setpoint 2	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-23	Setpoint 3	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
20-3* Feedb. Adv. Conv.						
20-30	Refrigerant	[0] R22	All set-ups	TRUE	-	UInt8
20-31	User-defined Refrigerant A1	10.0000 N/A	All set-ups	TRUE	-4	UInt32
20-32	User-defined Refrigerant A2	-2250.00 N/A	All set-ups	TRUE	-2	Int32
20-33	User-defined Refrigerant A3	250.000 N/A	All set-ups	TRUE	-3	UInt32
20-34	Fan 1 Area [m2]	0.500 m2	All set-ups	TRUE	-3	UInt32
20-35	Fan 1 Area [in2]	750 in2	All set-ups	TRUE	0	UInt32
20-36	Fan 2 Area [m2]	0.500 m2	All set-ups	TRUE	-3	UInt32
20-37	Fan 2 Area [in2]	750 in2	All set-ups	TRUE	0	UInt32
20-38	Air Density Factor [%]	100 %	All set-ups	TRUE	0	UInt32
20-6* Sensorless						
20-60	Sensorless Unit	null	All set-ups	TRUE	-	UInt8
20-69	Sensorless Information	0 N/A	All set-ups	TRUE	0	VisStr[25]
20-7* PID Autotuning						
20-70	Closed-loop Type	[0] Auto	2 set-ups	TRUE	-	UInt8
20-71	PID Performance	[0] Normal	2 set-ups	TRUE	-	UInt8
20-72	PID Output Change	0.10 N/A	2 set-ups	TRUE	-2	UInt16
20-73	Minimum Feedback Level	-999999.000 ProcessCtrlUnit	2 set-ups	TRUE	-3	Int32
20-74	Maximum Feedback Level	999999.000 ProcessCtrlUnit	2 set-ups	TRUE	-3	Int32
20-79	PID Autotuning	[0] Disabled	All set-ups	TRUE	-	UInt8
20-8* PID Basic Settings						
20-81	PID Normal/ Inverse Control	[0] Normal	All set-ups	TRUE	-	UInt8
20-82	PID Start Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	UInt16
20-83	PID Start Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	UInt16
20-84	On Reference Bandwidth	5 %	All set-ups	TRUE	0	UInt8
20-9* PID Controller						
20-91	PID Anti Windup	[1] On	All set-ups	TRUE	-	UInt8
20-93	PID Proportional Gain	0.50 N/A	All set-ups	TRUE	-2	UInt16
20-94	PID Integral Time	20.00 s	All set-ups	TRUE	-2	UInt32
20-95	PID Differentiation Time	0.00 s	All set-ups	TRUE	-2	UInt16
20-96	PID Diff. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	UInt16

21-** Ext. Closed-loop

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
21-0* Ext. CL Autotuning						
21-00	Closed-loop Type	[0] Auto	2 set-ups	TRUE	-	UInt8
21-01	PID Performance	[0] Normal	2 set-ups	TRUE	-	UInt8
21-02	PID Output Change	0.10 N/A	2 set-ups	TRUE	-2	UInt16
21-03	Minimum Feedback Level	-999999.000 N/A	2 set-ups	TRUE	-3	Int32
21-04	Maximum Feedback Level	999999.000 N/A	2 set-ups	TRUE	-3	Int32
21-09	PID Autotuning	[0] Disabled	All set-ups	TRUE	-	UInt8
21-1* Ext. CL 1 Ref./Fb.						
21-10	Ext. 1 Ref./Feedback Unit	[1] %	All set-ups	TRUE	-	UInt8
21-11	Ext. 1 Minimum Reference	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
21-12	Ext. 1 Maximum Reference	100.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
21-13	Ext. 1 Reference Source	[0] No function	All set-ups	TRUE	-	UInt8
21-14	Ext. 1 Feedback Source	[0] No function	All set-ups	TRUE	-	UInt8
21-15	Ext. 1 Setpoint	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
21-17	Ext. 1 Reference [Unit]	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
21-18	Ext. 1 Feedback [Unit]	0.000 ExtPID1Unit	All set-ups	TRUE	-3	Int32
21-19	Ext. 1 Output [%]	0 %	All set-ups	TRUE	0	Int32
21-2* Ext. CL 1 PID						
21-20	Ext. 1 Normal/Inverse Control	[0] Normal	All set-ups	TRUE	-	UInt8
21-21	Ext. 1 Proportional Gain	0.01 N/A	All set-ups	TRUE	-2	UInt16
21-22	Ext. 1 Integral Time	10000.00 s	All set-ups	TRUE	-2	UInt32
21-23	Ext. 1 Differentiation Time	0.00 s	All set-ups	TRUE	-2	UInt16
21-24	Ext. 1 Dif. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	UInt16
21-3* Ext. CL 2 Ref./Fb.						
21-30	Ext. 2 Ref./Feedback Unit	[1] %	All set-ups	TRUE	-	UInt8
21-31	Ext. 2 Minimum Reference	0.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
21-32	Ext. 2 Maximum Reference	100.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
21-33	Ext. 2 Reference Source	[0] No function	All set-ups	TRUE	-	UInt8
21-34	Ext. 2 Feedback Source	[0] No function	All set-ups	TRUE	-	UInt8
21-35	Ext. 2 Setpoint	0.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
21-37	Ext. 2 Reference [Unit]	0.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
21-38	Ext. 2 Feedback [Unit]	0.000 ExtPID2Unit	All set-ups	TRUE	-3	Int32
21-39	Ext. 2 Output [%]	0 %	All set-ups	TRUE	0	Int32
21-4* Ext. CL 2 PID						
21-40	Ext. 2 Normal/Inverse Control	[0] Normal	All set-ups	TRUE	-	UInt8
21-41	Ext. 2 Proportional Gain	0.01 N/A	All set-ups	TRUE	-2	UInt16
21-42	Ext. 2 Integral Time	10000.00 s	All set-ups	TRUE	-2	UInt32
21-43	Ext. 2 Differentiation Time	0.00 s	All set-ups	TRUE	-2	UInt16
21-44	Ext. 2 Dif. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	UInt16
21-5* Ext. CL 3 Ref./Fb.						
21-50	Ext. 3 Ref./Feedback Unit	[1] %	All set-ups	TRUE	-	UInt8
21-51	Ext. 3 Minimum Reference	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-52	Ext. 3 Maximum Reference	100.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-53	Ext. 3 Reference Source	[0] No function	All set-ups	TRUE	-	UInt8
21-54	Ext. 3 Feedback Source	[0] No function	All set-ups	TRUE	-	UInt8
21-55	Ext. 3 Setpoint	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-57	Ext. 3 Reference [Unit]	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-58	Ext. 3 Feedback [Unit]	0.000 ExtPID3Unit	All set-ups	TRUE	-3	Int32
21-59	Ext. 3 Output [%]	0 %	All set-ups	TRUE	0	Int32
21-6* Ext. CL 3 PID						
21-60	Ext. 3 Normal/Inverse Control	[0] Normal	All set-ups	TRUE	-	UInt8
21-61	Ext. 3 Proportional Gain	0.01 N/A	All set-ups	TRUE	-2	UInt16
21-62	Ext. 3 Integral Time	10000.00 s	All set-ups	TRUE	-2	UInt32
21-63	Ext. 3 Differentiation Time	0.00 s	All set-ups	TRUE	-2	UInt16
21-64	Ext. 3 Dif. Gain Limit	5.0 N/A	All set-ups	TRUE	-1	UInt16

22-** Application Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
22-0* Miscellaneous						
22-00	External Interlock Delay	0 s	All set-ups	TRUE	0	Uint16
22-01	Power Filter Time	0.50 s	2 set-ups	TRUE	-2	Uint16
22-2* No-Flow Detection						
22-20	Low Power Auto Set-up	[0] OFF	All set-ups	FALSE	-	Uint8
22-21	Low Power Detection	[0] Disabled	All set-ups	TRUE	-	Uint8
22-22	Low Speed Detection	[0] Disabled	All set-ups	TRUE	-	Uint8
22-23	No-Flow Function	[0] OFF	All set-ups	TRUE	-	Uint8
22-24	No-Flow Delay	10 s	All set-ups	TRUE	0	Uint16
22-26	Dry Pump Function	[0] OFF	All set-ups	TRUE	-	Uint8
22-27	Dry Pump Delay	10 s	All set-ups	TRUE	0	Uint16
22-3* No-Flow Power Tuning						
22-30	No-Flow Power	0.00 kW	All set-ups	TRUE	1	Uint32
22-31	Power Correction Factor	100 %	All set-ups	TRUE	0	Uint16
22-32	Low Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-33	Low Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-34	Low Speed Power [kW]	ExpressionLimit	All set-ups	TRUE	1	Uint32
22-35	Low Speed Power [HP]	ExpressionLimit	All set-ups	TRUE	-2	Uint32
22-36	High Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-37	High Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-38	High Speed Power [kW]	ExpressionLimit	All set-ups	TRUE	1	Uint32
22-39	High Speed Power [HP]	ExpressionLimit	All set-ups	TRUE	-2	Uint32
22-4* Sleep Mode						
22-40	Minimum Run Time	10 s	All set-ups	TRUE	0	Uint16
22-41	Minimum Sleep Time	10 s	All set-ups	TRUE	0	Uint16
22-42	Wake-up Speed [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-43	Wake-up Speed [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-44	Wake-up Ref./FB Difference	10 %	All set-ups	TRUE	0	Int8
22-45	Setpoint Boost	0 %	All set-ups	TRUE	0	Int8
22-46	Maximum Boost Time	60 s	All set-ups	TRUE	0	Uint16
22-5* End of Curve						
22-50	End of Curve Function	[0] OFF	All set-ups	TRUE	-	Uint8
22-51	End of Curve Delay	10 s	All set-ups	TRUE	0	Uint16
22-6* Broken Belt Detection						
22-60	Broken Belt Function	[0] OFF	All set-ups	TRUE	-	Uint8
22-61	Broken Belt Torque	10 %	All set-ups	TRUE	0	Uint8
22-62	Broken Belt Delay	10 s	All set-ups	TRUE	0	Uint16
22-7* Short Cycle Protection						
22-75	Short Cycle Protection	[0] Disabled	All set-ups	TRUE	-	Uint8
		start_to_start_min_on_time				
22-76	Interval between Starts	(P2277)	All set-ups	TRUE	0	Uint16
22-77	Minimum Run Time	0 s	All set-ups	TRUE	0	Uint16
22-78	Minimum Run Time Override	[0] Disabled	All set-ups	FALSE	-	Uint8
22-79	Minimum Run Time Override Value	0.000 ProcessCtrlUnit	All set-ups	TRUE	-3	Int32
22-8* Flow Compensation						
22-80	Flow Compensation	[0] Disabled	All set-ups	TRUE	-	Uint8
22-81	Square-linear Curve Approximation	100 %	All set-ups	TRUE	0	Uint8
22-82	Work Point Calculation	[0] Disabled	All set-ups	TRUE	-	Uint8
22-83	Speed at No-Flow [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-84	Speed at No-Flow [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-85	Speed at Design Point [RPM]	ExpressionLimit	All set-ups	TRUE	67	Uint16
22-86	Speed at Design Point [Hz]	ExpressionLimit	All set-ups	TRUE	-1	Uint16
22-87	Pressure at No-Flow Speed	0.000 N/A	All set-ups	TRUE	-3	Int32
22-88	Pressure at Rated Speed	999999.999 N/A	All set-ups	TRUE	-3	Int32
22-89	Flow at Design Point	0.000 N/A	All set-ups	TRUE	-3	Int32
22-90	Flow at Rated Speed	0.000 N/A	All set-ups	TRUE	-3	Int32

23-** Time-based Functions

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
23-0* Timed Actions						
23-00	ON Time	ExpressionLimit	2 set-ups	TRUE	0	TimeOf- DayWo- Date
23-01	ON Action	[0] DISABLED	2 set-ups	TRUE	-	UInt8
23-02	OFF Time	ExpressionLimit	2 set-ups	TRUE	0	TimeOf- DayWo- Date
23-03	OFF Action	[0] DISABLED	2 set-ups	TRUE	-	UInt8
23-04	Occurrence	[0] All days	2 set-ups	TRUE	-	UInt8
23-1* Maintenance						
23-10	Maintenance Item	[1] Motor bearings	1 set-up	TRUE	-	UInt8
23-11	Maintenance Action	[1] Lubricate	1 set-up	TRUE	-	UInt8
23-12	Maintenance Time Base	[0] Disabled	1 set-up	TRUE	-	UInt8
23-13	Maintenance Time Interval	1 h	1 set-up	TRUE	74	UInt32
23-14	Maintenance Date and Time	ExpressionLimit	1 set-up	TRUE	0	TimeOfDay
23-1* Maintenance Reset						
23-15	Reset Maintenance Word	[0] Do not reset	All set-ups	TRUE	-	UInt8
23-16	Maintenance Text	0 N/A	1 set-up	TRUE	0	VisStr[20]
23-5* Energy Log						
23-50	Energy Log Resolution	[5] Last 24 Hours	2 set-ups	TRUE	-	UInt8
23-51	Period Start	ExpressionLimit	2 set-ups	TRUE	0	TimeOfDay
23-53	Energy Log	0 N/A	All set-ups	TRUE	0	UInt32
23-54	Reset Energy Log	[0] Do not reset	All set-ups	TRUE	-	UInt8
23-6* Trending						
23-60	Trend Variable	[0] Power [kW]	2 set-ups	TRUE	-	UInt8
23-61	Continuous Bin Data	0 N/A	All set-ups	TRUE	0	UInt32
23-62	Timed Bin Data	0 N/A	All set-ups	TRUE	0	UInt32
23-63	Timed Period Start	ExpressionLimit	2 set-ups	TRUE	0	TimeOfDay
23-64	Timed Period Stop	ExpressionLimit	2 set-ups	TRUE	0	TimeOfDay
23-65	Minimum Bin Value	ExpressionLimit	2 set-ups	TRUE	0	UInt8
23-66	Reset Continuous Bin Data	[0] Do not reset	All set-ups	TRUE	-	UInt8
23-67	Reset Timed Bin Data	[0] Do not reset	All set-ups	TRUE	-	UInt8
23-8* Payback Counter						
23-80	Power Reference Factor	100 %	2 set-ups	TRUE	0	UInt8
23-81	Energy Cost	1.00 N/A	2 set-ups	TRUE	-2	UInt32
23-82	Investment	0 N/A	2 set-ups	TRUE	0	UInt32
23-83	Energy Savings	0 kWh	All set-ups	TRUE	75	Int32
23-84	Cost Savings	0 N/A	All set-ups	TRUE	0	Int32

24-** Application Functions 2

Par. No. #	Parameter description	Default value	4-set-up	Change during operation	Conversion index	Type
24-0* Fire Mode						
24-00	Fire Mode Function	[0] Disabled	2 set-ups	TRUE	-	UInt8
24-01	Fire Mode Configuration	[0] Open-loop	All set-ups	TRUE	-	UInt8
24-02	Fire Mode Unit	null	All set-ups	TRUE	-	UInt8
24-03	Fire Mode Min Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
24-04	Fire Mode Max Reference	ExpressionLimit	All set-ups	TRUE	-3	Int32
24-05	Fire Mode Preset Reference	0.00 %	All set-ups	TRUE	-2	Int16
24-06	Fire Mode Reference Source	[0] No function	All set-ups	TRUE	-	UInt8
24-07	Fire Mode Feedback Source	[0] No function	All set-ups	TRUE	-	UInt8
24-09	Fire Mode Alarm Handling	[1] Trip, Critical Alarms	2 set-ups	FALSE	-	UInt8
24-1* Drive Bypass						
24-10	Drive Bypass Function	[0] Disabled	2 set-ups	TRUE	-	UInt8
24-11	Drive Bypass Delay Time	0 s	2 set-ups	TRUE	0	UInt16
24-9* Multi-Motor Funct.						
24-90	Missing Motor Function	[0] Off	All set-ups	TRUE	-	UInt8
24-91	Missing Motor Coefficient 1	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-92	Missing Motor Coefficient 2	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-93	Missing Motor Coefficient 3	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-94	Missing Motor Coefficient 4	0.0000 N/A	All set-ups	TRUE	-3	Int32
24-95	Locked Rotor Function	[0] Off	All set-ups	TRUE	-	UInt8
24-96	Locked Rotor Coefficient 1	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-97	Locked Rotor Coefficient 2	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-98	Locked Rotor Coefficient 3	0.0000 N/A	All set-ups	TRUE	-4	Int32
24-99	Locked Rotor Coefficient 4	0.0000 N/A	All set-ups	TRUE	-3	Int32

Index

■

"i-am" Service 8-74..... 4-99

,

, 0-4* 4-16

1

1-3* Adv. Motor Data 4-25

A

Abbreviations	2-2
Ac Brake Max. Current 2-16.....	4-37
Access To Main Menu W/o Password 0-61.....	4-19
Access To Personal Menu W/o Password 0-66.....	4-19
Active Set-up 0-10.....	4-5
Actual Typecode String 15-45.....	4-137
Additional Non-working Days 0-83.....	4-21
Additional Working Days 0-82.....	4-21
Address 8-31.....	4-96
Adj Freq Dr Ordering No. 15-46.....	4-137
Adj Freq Dr Serial No. 15-51.....	4-138
Adjustable Frequency Drive Closed-loop	4-153
Aeo Minimum Magnetization 14-41.....	4-127
[Air Density Factor %] 20-38.....	4-164
Alarm Log	4-136
Alarm Log: Date And Time 15-33.....	4-136
Alarm Log: Error Code 15-30.....	4-136
Alarm Log: Time 15-32.....	4-136
Alarm Log: Value 15-31.....	4-136
Alarm Word	5-5
Alarm Word 16-90.....	4-148
Alarm Word 2 16-91.....	4-149
Alarm/warning Code List	5-2
Alarms And Warnings	5-1
Analog In X30/11 16-75.....	4-147
Analog In X30/12 16-76.....	4-147
Analog Input 53 16-62.....	4-145
Analog Input 54 16-64.....	4-146
Analog Inputs	2-4
[Analog Out X30/8 Ma] 16-77.....	4-147
[Analog Output 42 Ma] 16-65.....	4-146
Auto Derate	4-129
Auto Energy Optimization Compressor	4-22
Auto Energy Optimization Vt	4-23
[Auto On] Key On Lcp 0-42.....	4-17
Automatic Motor Adaptation (ama) 1-29.....	4-25
Automatic Restart Time 14-21.....	4-124

B

Bacnet	4-99
Bacnet Device Instance 8-70.....	4-99
Brake Check 2-15.....	4-36
Brake Control	5-9
Brake Energy /2 Min 16-33.....	4-142
Brake Energy /s 16-32.....	4-142

Brake Function 2-10.....	4-35
Brake Power Limit (kw) 2-12.....	4-35
Brake Power Monitoring 2-13.....	4-36
Brake Resistor (ohm) 2-11.....	4-35
Braking Energy	2-5
Break-away Torque	2-4
Broken Belt Delay 22-62.....	4-191
Broken Belt Detection	4-190
Broken Belt Function 22-60.....	4-191
Broken Belt Torque 22-61.....	4-191
Bus Controlled	4-82
Bus Error Count 8-81.....	4-100
Bus Feedback 1 8-94.....	4-101
Bus Feedback 2 8-95.....	4-101
Bus Feedback 3 8-96.....	4-101
Bus Jog 1 Speed 8-90.....	4-101
Bus Jog 2 Speed 8-91.....	4-101
Bus Message Count 8-80.....	4-100
[Bypass Speed From Hz] 4-61.....	4-50
[Bypass Speed From Rpm] 4-60.....	4-50
[Bypass Speed To Hz] 4-63.....	4-50
[Bypass Speed To Rpm] 4-62.....	4-50

C

Changes Made	3-9
Changing A Data Value	3-17
Changing A Group Of Numeric Data Values	3-17
Changing A Text Value	3-17
Changing Data	3-16
Changing Parameter Data	3-8
Clock Fault 0-79.....	4-21
Clock Settings, 0-7*	4-20
Closed-loop Type 20-70.....	4-166, 4-170
Coast Inverse	3-10
Coasting	2-3, 3-6
Coasting Select 8-50.....	4-97
Comm. Option Status 16-84.....	4-148
Communication Option	5-11
Comparator Operand 13-10.....	4-109
Comparator Operator 13-11.....	4-109
Comparator Value 13-12.....	4-110
Configurable Status Word Stw 8-13.....	4-95
Configuration	4-95
Configuration Mode 1-00.....	4-22
Continuous Bin Data 23-61.....	4-205
Control Card Temp. 16-39.....	4-143
Control Profile 8-10.....	4-95
Control Site 8-01.....	4-92
Control Source 8-02.....	4-93
Control Timeout Function 8-04.....	4-93
Control Timeout Time 8-03.....	4-93
Control Word 16-00.....	4-140
Cooling	4-31
Copyright, Limitation Of Liability And Revision Rights	2-1
Cost Savings 23-84.....	4-208
Counter A 16-72.....	4-147
Counter B 16-73.....	4-147
Current Fault Source 16-49.....	4-143
Current Lim Cont, Proportional Gain 14-30.....	4-126

Current Lim Contr, Integration Time 14-31.....	4-127
Current Lim Ctrl, Filter Time 14-32.....	4-127
Current Limit 4-18.....	4-48
Current Limit Control.....	4-126
Custom Readout 16-09.....	4-140
Custom Readout Max Value 0-32.....	4-15
Custom Readout Min Value 0-31.....	4-15
Custom Readout Unit 0-30.....	4-13

D

Data Log Settings.....	4-132
Date And Time 0-70.....	4-20
Date And Time Readout 0-89.....	4-22
Date Format 0-71.....	4-20
Dc Brake Current 2-01.....	4-34
[Dc Brake Cut-in Speed Hz] 2-04.....	4-35
[Dc Brake Cut-in Speed Rpm] 2-03.....	4-34
Dc Brake Select 8-52.....	4-97
Dc Braking Time 2-02.....	4-34
Dc Hold/preheat Current 2-00.....	4-34
Dc Link.....	5-8
Dc Link Voltage 16-30.....	4-142
Default Settings.....	6-1
Default Settings.....	3-18
Defined Parameters 15-92.....	4-139
Definitions.....	2-3
Diagnosis Trigger 8-07.....	4-94
Digi Pot Reference 16-53.....	4-144
Digital & Relay Bus Control 5-90.....	4-82
Digital Input 16-60.....	4-144
Digital Inputs, 5-1* Continued.....	4-54, 4-57
[Digital Output Bin] 16-66.....	4-146
Display Line 1.1 Small 0-20.....	4-7
Display Line 1.3 Small, 0-22.....	4-12
Display Line 2 Large, 0-23.....	4-12
Display Text 1 0-37.....	4-15
Display Text 2 0-38.....	4-15
Display Text 3 0-39.....	4-16
Disposal Instructions.....	1-5
Domain 11-01.....	4-102
Drive Bypass Delay Time 24-11.....	4-214
Drive Bypass Function 24-10.....	4-213
[Drive Bypass] Key On Lcp 0-45.....	4-18
Drive Identification.....	4-136, 4-139
Drive Information.....	4-130
Drive Profile 11-10.....	4-102
Dst/summertime 0-74.....	4-20
Dst/summertime End 0-77.....	4-21
Dst/summertime Start 0-76.....	4-21

E

Electrical Ratings.....	1-4
Electronic Waste.....	1-5
End-of-timeout Function 8-05.....	4-94
Energy Cost 23-81.....	4-208
Energy Log.....	4-199, 4-202
Energy Log Resolution 23-50.....	4-201
Energy Optimization.....	4-127
Energy Savings 23-83.....	4-208



Index

Environment	4-128
Etr	4-142
Example Of Changing Parameter Data	3-8
Ext. 1 Dif. Gain Limit 21-24.....	4-176
Ext. 1 Differentiation Time 21-23.....	4-176
Ext. 1 Feedback Source 21-14.....	4-174
[Ext. 1 Feedback Unit] 21-18.....	4-175
Ext. 1 Integral Time 21-22.....	4-176
Ext. 1 Maximum Reference 21-12.....	4-173
Ext. 1 Minimum Reference 21-11.....	4-173
Ext. 1 Normal/inverse Control 21-20.....	4-175
[Ext. 1 Output %] 21-19.....	4-175
Ext. 1 Proportional Gain 21-21.....	4-175
Ext. 1 Ref./feedback Unit 21-10.....	4-172
Ext. 1 Reference Source 21-13.....	4-174
[Ext. 1 Reference Unit] 21-17.....	4-175
Ext. 1 Setpoint 21-15.....	4-175
Ext. 2 Dif. Gain Limit 21-44.....	4-180
Ext. 2 Differentiation Time 21-43.....	4-180
Ext. 2 Feedback Source 21-34.....	4-178
[Ext. 2 Feedback Unit] 21-38.....	4-179
Ext. 2 Integral Time 21-42.....	4-180
Ext. 2 Maximum Reference 21-32.....	4-178
Ext. 2 Minimum Reference 21-31.....	4-178
Ext. 2 Normal/inverse Control 21-40.....	4-180
[Ext. 2 Output %] 21-39.....	4-179
Ext. 2 Proportional Gain 21-41.....	4-180
Ext. 2 Ref./feedback Unit 21-30.....	4-176
Ext. 2 Reference Source 21-33.....	4-178
[Ext. 2 Reference Unit] 21-37.....	4-179
Ext. 2 Setpoint 21-35.....	4-179
Ext. 3 Dif. Gain Limit 21-64.....	4-184
Ext. 3 Differentiation Time 21-63.....	4-183
Ext. 3 Feedback Source 21-54.....	4-182
[Ext. 3 Feedback Unit] 21-58.....	4-183
Ext. 3 Integral Time 21-62.....	4-183
Ext. 3 Maximum Reference 21-52.....	4-182
Ext. 3 Minimum Reference 21-51.....	4-181
Ext. 3 Normal/inverse Control 21-60.....	4-183
[Ext. 3 Output %] 21-59.....	4-183
Ext. 3 Proportional Gain 21-61.....	4-183
Ext. 3 Ref./feedback Unit 21-50.....	4-180
Ext. 3 Reference Source 21-53.....	4-182
[Ext. 3 Reference Unit] 21-57.....	4-183
Ext. 3 Setpoint 21-55.....	4-183
Ext. Status Word 16-94.....	4-149
Ext. Status Word 2 16-95.....	4-149
Extended CI Autotuning	4-170
Extended Status Word	5-7
Extended Status Word 2	5-7
External Interlock Delay 22-00.....	4-184
External Reference 16-50.....	4-143
F	
[Fan 1 Area In2] 20-35.....	4-164
[Fan 1 Area M2] 20-34.....	4-164
[Fan 2 Area In2] 20-37.....	4-164
[Fan 2 Area M2] 20-36.....	4-164
Fan Control 14-52.....	4-128

Fan Monitor 14-53.....	4-128
Fault Messages	5-8
Fc Port Ctw 1 16-85.....	4-148
Fc Port Ref 1 16-86.....	4-148
Fc Type 15-40.....	4-136
Feedback	4-153
Feedback & Setpoint	4-160
Feedback 1 Conversion 20-01.....	4-154
Feedback 1 Source 20-00.....	4-153
Feedback 1 Source Unit 20-02.....	4-154
[Feedback 1 Unit] 16-54.....	4-144
Feedback 2 Conversion 20-04.....	4-156
Feedback 2 Source 20-03.....	4-156
Feedback 2 Source Unit 20-05.....	4-156
[Feedback 2 Unit] 16-55.....	4-144
Feedback 3 Conversion 20-07.....	4-158
Feedback 3 Source 20-06.....	4-157
Feedback 3 Source Unit 20-08.....	4-158
[Feedback 3 Unit] 16-56.....	4-144
Feedback Adv. Conversion	4-163
Feedback Function 20-20.....	4-160
[Feedback Unit] 16-52.....	4-144
Fieldbus Ctw 1 16-80.....	4-148
Fieldbus Ref 1 16-82.....	4-148
Fire Mode Alarm Handling 24-09.....	4-211
Fire Mode Function 24-00.....	4-210
Fire Mode Live Zero Timeout Function 6-02.....	4-84
Fire Mode Log: Date And Time 18-12.....	4-152
Fire Mode Log: Event 18-10.....	4-152
Fire Mode Log: Time 18-11.....	4-152
Fire Mode Max Reference 24-04.....	4-211
Fire Mode Preset Reference 24-05.....	4-211
Fire Mode Reference Source 24-06.....	4-211
Flying Start 1-73.....	4-29
Freeze Output	2-3
Frequency 16-13.....	4-141
[Frequency %] 16-15.....	4-141
Function At Inverter Overload 14-61.....	4-130
Function At Mains Imbalance 14-12.....	4-123
Function At Overtemperature 14-60.....	4-129
Function At Stop 1-80.....	4-30
Function Relay 5-40.....	4-74
Function Set-ups	3-10

G

General Settings, 1-0*	4-22
Graphical Display	3-1

H

[Hand On] Key On Lcp 0-40.....	4-16
Heatsink Temp. 16-34.....	4-142
High Speed Load Compensation 1-61.....	4-28
Historic Log	4-135
Historic Log: Date And Time 15-23.....	4-136
Historic Log: Event 15-20.....	4-135
Historic Log: Time 15-22.....	4-135
Historic Log: Value 15-21.....	4-135
How To Operate The Graphical	3-1

I

Initialization	3-18
Initialization Password 8-75.....	4-100
Installation At High Altitudes	1-2
Interval Between Starts 22-76.....	4-192
Inv. Max. Current 16-37.....	4-143
Inv. Nom. Current 16-36.....	4-142
Inv. Overload Derate Current 14-62.....	4-130
Inverter Thermal 16-35.....	4-142
Investment 23-82.....	4-208
Iron Loss Resistance (rfe) 1-36.....	4-26

J

Jog	2-3
Jog Ramp Time 3-80.....	4-44
[Jog Speed Hz] 3-11.....	4-38
[Jog Speed Rpm] 3-19.....	4-41

K

Kty Sensor	5-9
Kwh Counter 15-02.....	4-131

L

Language 0-01.....	4-2
Language Package 1	4-2
Language Package 2	4-2
Lcp Copy 0-50.....	4-18
Lcp Id Num. 15-48.....	4-137
Leds	3-1, 3-3
Lg-0# Maintenance Log	4-151
Line Power On/off	4-121
Line Power Supply	2-7
Literature	2-2
Live Zero Timeout Function 6-01.....	4-83
Live Zero Timeout Time 6-00.....	4-83
Local Mode Unit 0-05.....	4-4
Local Reference	4-3
Logging Buffer Full 16-40.....	4-143
Logging Interval 15-11.....	4-133
Logging Mode 15-13.....	4-134
Logging Source 15-10.....	4-132
Loggings	3-9
Logic Rule Boolean 1 13-40.....	4-110
Logic Rule Boolean 2 13-42.....	4-113
Logic Rule Boolean 3 13-44.....	4-115
Logic Rule Operator 1 13-41.....	4-113
Logic Rule Operator 2 13-43.....	4-115
Lon Warning Word 11-15.....	4-102
Lonworks	4-102
Lonworks Revision 11-18.....	4-103
Low Speed Detection 22-22.....	4-186
Low Speed Load Compensation 1-60.....	4-28

M

[Main Actual Value %] 16-05.....	4-140
Main Menu - Adjustable Frequency Drive Information - Group 15	4-130
Main Menu Mode	3-5, 3-8
Main Menu Mode	3-15

Main Menu Password 0-60.....	4-19
Main Menu Structure	4-1
Main Reactance	4-25
Main Reactance (xh) 1-35.....	4-26
Mains Failure 14-10.....	4-121
Mains Voltage At Mains Fault 14-11.....	4-123
Maintenance Action 23-11.....	4-198
Maintenance Date And Time 23-14.....	4-199
Maintenance Item 23-10.....	4-197
Maintenance Log: Action 18-01.....	4-151
Maintenance Log: Date And Time 18-03.....	4-151
Maintenance Log: Item 18-00.....	4-151
Maintenance Log: Time 18-02.....	4-151
Maintenance Text 23-16.....	4-199
Maintenance Time Base 23-12.....	4-198
Maintenance Time Interval 23-13.....	4-199
Maintenance Word 16-96.....	4-149
Manual Initialization	3-18
Max Output Frequency 4-19.....	4-48
Maximum Boost Time 22-46.....	4-190
Maximum Feedback Level 20-74.....	4-166, 4-171
Maximum Inter-char Delay 8-37.....	4-97
Maximum Limit 3-93.....	4-45
Maximum Reference 3-03.....	4-37
Maximum Reference/feedb. 20-14.....	4-159
Maximum Response Delay 8-36.....	4-96
[Min Speed For Function At Stop Hz] 1-82.....	4-30
[Min Speed For Function At Stop Rpm] 1-81.....	4-30
[Min Speed Normal Magnetizing Hz] 1-52.....	4-28
[Min Speed Normal Magnetizing Rpm] 1-51.....	4-27
Minimum Aeo Frequency 14-42.....	4-127
Minimum Bin Value 23-65.....	4-206
Minimum Feedback Level 20-73.....	4-166, 4-171
Minimum Limit 3-94.....	4-45
Minimum Reference 3-02.....	4-37
Minimum Reference/feedb. 20-13.....	4-159
Minimum Response Delay 8-35.....	4-96
Minimum Run Time 22-40.....	4-189, 4-192
Minimum Sleep Time 22-41.....	4-189
Missing Motor Phase Function 4-58.....	4-50
Modified Parameters 15-93.....	4-139
Motor Cos-phi 14-43.....	4-127
Motor Current 1-24.....	4-24, 4-141
Motor External Fan 1-91.....	4-32
Motor Frequency 1-23.....	4-24
Motor Magnetization At Zero Speed 1-50.....	4-27
Motor Nominal Speed 1-25.....	4-24
Motor Poles 1-39.....	4-27
[Motor Power Hp] 1-21.....	4-23
[Motor Power Kw] 1-20.....	4-23
Motor Protection	4-31
Motor Rotation Check 1-28.....	4-24
Motor Speed Direction 4-10.....	4-46
[Motor Speed High Limit Hz] 4-14.....	4-47
[Motor Speed High Limit Rpm] 4-13.....	4-47
[Motor Speed Low Limit Hz] 4-12.....	4-47
[Motor Speed Low Limit Rpm] 4-11.....	4-47
Motor Speed Unit 0-02.....	4-3
Motor Status	4-141

Motor Thermal 16-18.....	4-142
Motor Thermal Protection 1-90.....	4-31
Motor Voltage 16-12.....	4-141
Motor Voltage 1-22.....	4-23
Ms/tp Max Info Frames 8-73.....	4-99
Ms/tp Max Masters 8-72.....	4-99
My Personal Menu	3-8, 4-12

N

Neuron Id 11-00.....	4-102
No Operation	3-10
No Trip At Inverter Overload	4-129
Node Id 11-03.....	4-102
No-flow Delay 22-24.....	4-186
No-flow Function 22-23.....	4-186
Number Of Starts 15-08.....	4-132

O

Occurrence 23-04.....	4-195
Off Action 23-03.....	4-194
Off Delay, Relay 5-42.....	4-77
Off Time 23-02.....	4-194
[Off/reset] Key On Lcp 0-44.....	4-17
[Off] Key On Lcp 0-41.....	4-16
On Action 23-01.....	4-193
On Delay, Relay 5-41.....	4-77
On Reference Bandwidth 20-84.....	4-167
On Time 23-00.....	4-192
Operating Hours 15-00.....	4-130
Operating Mode	4-3
Operating State At Power-up 0-04.....	4-3
Operation Mode 14-22.....	4-124
Option Ident.	4-138
Option In Slot A 15-70.....	4-138
Option In Slot B 15-72.....	4-138
Option In Slot C0 15-74.....	4-139
Option In Slot C1 15-76.....	4-139
Option Mounted 15-60.....	4-138
Option Ordering No 15-62.....	4-138
Option Serial No 15-63.....	4-138
Option Sw Version 15-61.....	4-138
Ordered Typecode String 15-44.....	4-137
Over Temps 15-04.....	4-131
Over Volts 15-05.....	4-131
Overmodulation 14-03.....	4-121
Over-voltage Control 2-17.....	4-37

P

Parameter Data	3-8
Parameter Info	4-139
Parameter Metadata 15-99.....	4-139
Parameter Selection	3-16
Parameter Set-up	3-8
Parity / Stop Bits 8-33.....	4-96
Period Start 23-51.....	4-201
Personal Menu Password 0-65.....	4-19
Pid Anti Windup 20-91.....	4-168
Pid Autotuning	4-165
Pid Autotuning 20-79.....	4-167, 4-171

Pid Basic Settings	4-167
Pid Controller	4-168
Pid Diff. Gain Limit 20-96.....	4-169
Pid Differentiation Time 20-95.....	4-169
Pid Integral Time 20-94.....	4-168
Pid Normal/ Inverse Control 20-81.....	4-167
[Pid Output %] 16-58.....	4-144
Pid Output Change 20-72.....	4-166, 4-171
Pid Performance 20-71.....	4-166, 4-171
Pid Proportional Gain 20-93.....	4-168
[Pid Start Speed Hz] 20-83.....	4-167
[Pid Start Speed Rpm] 20-82.....	4-167
Power Card Ordering No. 15-47.....	4-137
Power Card Serial Number 15-53.....	4-138
[Power Hp] 16-11.....	4-141
[Power Kw] 16-10.....	4-141
Power Reference Factor 23-80.....	4-208
Power Restore 3-92.....	4-45
Power Section 15-41.....	4-137
Power-ups 15-03.....	4-131
Preset Reference 3-10.....	4-38
Preset Reference Select 8-56.....	4-99
Preset Relative Reference 3-14.....	4-39
Production Settings 14-28.....	4-126
Programming Set-up 0-11.....	4-5
Protection Mode	2-8
Protocol 8-30.....	4-95
Pulse Filter Time Constant #29 5-54.....	4-78
Pulse Filter Time Constant #33 5-59.....	4-79
[Pulse Input #29 Hz] 16-67.....	4-146
[Pulse Input #33 Hz] 16-68.....	4-146
Pulse Out #27 Bus Control 5-93.....	4-82
Pulse Out #27 Timeout Preset 5-94.....	4-82
Pulse Out #29 Bus Control 5-95.....	4-82
Pulse Out #29 Timeout Preset 5-96.....	4-82
Pulse Out #x30/6 Bus Control 5-97.....	4-82
Pulse Out #x30/6 Timeout Preset 5-98.....	4-82
[Pulse Output #27 Hz] 16-69.....	4-146
[Pulse Output #29 Hz] 16-70.....	4-146
Pulse Output Max Freq #27 5-62.....	4-80
Pulse Output Max Freq #29 5-65.....	4-81
Pulse Output Max Freq #x30/6 5-68.....	4-81
Pwm Random 14-04.....	4-121

Q

Quick Menu	3-4
Quick Menu Mode	3-4, 3-8
Quick Stop S-ramp Ratio At Decel. End 3-84.....	4-44
Quick Transfer Of Parameter Settings Between Multiple Adjustable Frequency Drives	3-7

R

Ramp 1 Ramp-down Time 3-42.....	4-42
Ramp 1 Ramp-up Time 3-41.....	4-42
Ramp 1 S-ramp Ratio At Accel. End 3-46.....	4-42
Ramp 1 S-ramp Ratio At Accel. Start 3-45.....	4-42
Ramp 1 S-ramp Ratio At Decel. End 3-48.....	4-43
Ramp 1 S-ramp Ratio At Decel. Start 3-47.....	4-43
Ramp 1 Type 3-40.....	4-42
Ramp 2 Ramp-down Time 3-52.....	4-43



Index

Ramp 2 Ramp-up Time 3-51.....	4-43
Ramp 2 S-ramp Ratio At Accel. End 3-56.....	4-43
Ramp 2 S-ramp Ratio At Accel. Start 3-55.....	4-43
Ramp 2 S-ramp Ratio At Decel. End 3-58.....	4-44
Ramp 2 S-ramp Ratio At Decel. Start 3-57.....	4-43
Ramp Delay 3-95.....	4-45
Ramp Time 3-91.....	4-45
Rated Motor Speed	2-3
Rcd	2-6
Readout And Programming Of Indexed Parameters	3-17
Readout: Linked Set-ups 0-13.....	4-7
Readout: Prog. Set-ups / Channel 0-14.....	4-7
Reference % 16-02.....	4-140
Reference 1 Source 3-15.....	4-39
Reference 2 Source 3-16.....	4-40
Reference 3 Source 3-17.....	4-41
Reference Function 3-04.....	4-38
Reference Site 3-13.....	4-39
[Reference Unit] 16-01.....	4-140
Refrigerant 20-30.....	4-163
Regional Settings 0-03.....	4-3
[Relay Output Bin] 16-71.....	4-147
Relay Outputs	4-66
Reset Continuous Bin Data 23-66.....	4-206
Reset Control Timeout 8-06.....	4-94
Reset Energy Log 23-54.....	4-202
Reset Kwh Counter 15-06.....	4-131
Reset Maintenance Word 23-15.....	4-199
Reset Mode 14-20.....	4-123
Reset Running Hours Counter 15-07.....	4-131
Reset Slc 13-03.....	4-108
Reset Timed Bin Data 23-67.....	4-206
[Reset] Key On Lcp 0-43.....	4-17
Resonance Dampening 1-64.....	4-29
Resonance Dampening Time Constant 1-65.....	4-29
Reverse Select 8-54.....	4-98
Rfi 1 14-50.....	4-128
Running Hours 15-01.....	4-131

S

Safety Note	1-1
Safety Precautions	2-7
Safety Regulations	1-2
Samples Before Trigger 15-14.....	4-134
Semi-auto Bypass Set-up 4-64.....	4-51
Serial Communication	2-4
Service Code 14-29.....	4-126
Setpoint 1 20-21.....	4-162
Setpoint 2 20-22.....	4-162
Setpoint 3 20-23.....	4-162
Setpoint Boost 22-45.....	4-190
Set-up Copy 0-51.....	4-19
Set-up Select 8-55.....	4-98
Short Cycle Protection	4-191
SI Controller Action 13-52.....	4-118
SI Controller Event 13-51.....	4-117
SI Controller Mode 13-00.....	4-104
SI Controller State 16-38.....	4-143
SI Controller Timer 13-20.....	4-110

Slave Error Count 8-83.....	4-100
Slave Messages Rcvd 8-82.....	4-100
Slave Messages Sent 8-84.....	4-100
Slave Timeout Errors 8-85.....	4-100
Sleep Mode	4-186
Slip Compensation 1-62.....	4-29
Slip Compensation Time Constant 1-63.....	4-29
Slot A Option Sw Version 15-71.....	4-138
Slot B Option Sw Version 15-73.....	4-138
Slot C0 Option Sw Version 15-75.....	4-139
Slot C1 Option Sw Version 15-77.....	4-139
Software Version 15-43.....	4-137
Special Functions	4-120
[Speed Rpm] 16-17.....	4-141
Start Delay 1-71.....	4-29
Start Event 13-01.....	4-105
Start Select 8-53.....	4-98
Stator Leakage Reactance	4-25
Stator Resistance (rs) 1-30.....	4-26
Status	3-4
Status Messages	3-1
Status Word 16-03.....	4-140
Step Size 3-90.....	4-45
Step-by-step	3-17
Stop Event 13-02.....	4-106
Subnet Id 11-02.....	4-102
Sw Id Control Card 15-49.....	4-137
Sw Id Power Card 15-50.....	4-137
Switching Frequency 14-01.....	4-120
Switching Pattern 14-00.....	4-120
Synchronous Motor Speed	2-3

T

Telegram Selection 8-40.....	4-97
Term X30/6 Digi Out (mcb 101) 5-32.....	4-71
Term X30/7 Digi Out (mcb 101) 5-33.....	4-73
Term. 29 High Frequency 5-51.....	4-78
Term. 29 High Ref./feedb. Value 5-53.....	4-78
Term. 29 Low Frequency 5-50.....	4-78
Term. 29 Low Ref./feedb. Value 5-52.....	4-78
Term. 33 High Frequency 5-56.....	4-79
Term. 33 High Ref./feedb. Value 5-58.....	4-79
Term. 33 Low Frequency 5-55.....	4-78
Term. 33 Low Ref./feedb. Value 5-57.....	4-79
Term. X30/11 Filter Time Constant 6-36.....	4-87
Term. X30/11 High Ref./feedb. Value 6-35.....	4-87
Term. X30/11 Live Zero 6-37.....	4-87
Term. X30/11 Low Ref./feedb. Value 6-34.....	4-87
Term. X30/12 Filter Time Constant 6-46.....	4-88
Term. X30/12 High Ref./feedb. Value 6-45.....	4-88
Term. X30/12 Live Zero 6-47.....	4-88
Term. X30/12 Low Ref./feedb. Value 6-44.....	4-88
Terminal 18 Digital Input 5-10.....	4-60
Terminal 27 Mode 5-01.....	4-51
Terminal 27 Pulse Output Variable 5-60.....	4-80
Terminal 29 Digital Input 5-13.....	4-61
Terminal 29 Mode 5-02.....	4-52
Terminal 29 Pulse Output Variable 5-63.....	4-80
Terminal 32 Digital Input 5-14.....	4-62

Terminal 42 Output 6-50.....	4-89
Terminal 42 Output Bus Control 6-53.....	4-91
Terminal 42 Output Max Scale 6-52.....	4-90
Terminal 42 Output Min Scale 6-51.....	4-90
Terminal 42 Output Timeout Preset 6-54.....	4-91
Terminal 53 Filter Time Constant 6-16.....	4-85
Terminal 53 High Current 6-13.....	4-85
Terminal 53 High Ref./feedb. Value 6-15.....	4-85
Terminal 53 High Voltage 6-11.....	4-84
Terminal 53 Live Zero 6-17.....	4-85
Terminal 53 Low Current 6-12.....	4-84
Terminal 53 Low Ref./feedb. Value 6-14.....	4-85
Terminal 53 Low Voltage 6-10.....	4-84
Terminal 53 Switch Setting 16-61.....	4-145
Terminal 54 Filter Time Constant 6-26.....	4-86
Terminal 54 High Current 6-23.....	4-86
Terminal 54 High Ref./feedb. Value 6-25.....	4-86
Terminal 54 High Voltage 6-21.....	4-86
Terminal 54 Live Zero 6-27.....	4-86
Terminal 54 Low Current 6-22.....	4-86
Terminal 54 Low Ref./feedb. Value 6-24.....	4-86
Terminal 54 Low Voltage 6-20.....	4-85
Terminal 54 Switch Setting 16-63.....	4-146
Terminal X30/11 High Voltage 6-31.....	4-87
Terminal X30/11 Low Voltage 6-30.....	4-87
Terminal X30/12 High Voltage 6-41.....	4-88
Terminal X30/12 Low Voltage 6-40.....	4-88
Terminal X30/2 Digital Input 5-16.....	4-63
Terminal X30/3 Digital Input 5-17.....	4-64
Terminal X30/4 Digital Input 5-18.....	4-65
Terminal X30/6 Pulse Output Variable 5-66.....	4-81
Terminal X30/8 Max. Scale 6-62.....	4-92
Terminal X30/8 Min. Scale 6-61.....	4-92
Terminal X30/8 Output 6-60.....	4-91
Terminal X30/8 Output Bus Control 6-63.....	4-92
Terminal X30/8 Output Timeout Preset 6-64.....	4-92
Thermal Load	4-27, 4-142
Thermistor	4-31
Thermistor	2-6
Thermistor Source 1-93.....	4-33
This Set-up Linked To 0-12.....	4-5
Time Format 0-72.....	4-20
Timed Actions	4-192
Timed Bin Data 23-62.....	4-205
Timed Period Start 23-63.....	4-205
Timed Period Stop 23-64.....	4-206
[Torque %] 16-22.....	4-142
Torque Characteristics 1-03.....	4-22
Torque Limit Generator Mode 4-17.....	4-47
Torque Limit Motor Mode 4-16.....	4-47
[Torque Nm] 16-16.....	4-141
Trend Variable 23-60.....	4-204
Trending	4-203
Trigger Event 15-12.....	4-133
Trip At Motor Speed Low Limit	4-30
Trip Delay At Inverter Fault 14-26.....	4-126
Trip Delay At Torque Limit 14-25.....	4-126
Trip Reset	4-123
[Trip Speed Low Hz] 1-87.....	4-31

[Trip Speed Low Rpm] 1-86.....	4-31
Troubleshooting	5-1
Typecode Setting 14-23.....	4-125

U

User-defined Refrigerant A1 20-31.....	4-163
User-defined Refrigerant A2 20-32.....	4-163
User-defined Refrigerant A3 20-33.....	4-163

V

Voltage 15-42.....	4-137
Vt Level 14-40.....	4-127
Vvcplus	2-6

W

Wake-up Ref./fb Difference 22-44.....	4-190
[Wake-up Speed Hz] 22-43.....	4-190
[Wake-up Speed Rpm] 22-42.....	4-189
Warning Against Unintended Start	1-2
Warning Current High 4-51.....	4-49
Warning Current Low 4-50.....	4-48
Warning Feedback High 4-57.....	4-49
Warning Feedback Low 4-56.....	4-49
Warning Reference High 4-55.....	4-49
Warning Reference Low 4-54.....	4-49
Warning Speed High 4-53.....	4-49
Warning Word	5-6
Warning Word 16-92.....	4-149
Warning Word 2 16-93.....	4-149, 5-6
Working Days 0-81.....	4-21

X

Xif Revision 11-17.....	4-103
-------------------------	-------



www.trane.com

For more information, contact your local Trane office or e-mail us at comfort@trane.com

Literature order number	BAS-SVP04B-EN
Date	November 2009
Substitutes	BAS-SVP04A-EN

Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice.

